

3GPP TS 38.306 V17.5.0 (2023-06)

Technical Specification

**3rd Generation Partnership Project;
Technical Specification Group Radio Access Network;
NR;
User Equipment (UE) radio access capabilities
(Release 17)**



The present document has been developed within the 3rd Generation Partnership Project (3GPP™) and may be further elaborated for the purposes of 3GPP. The present document has not been subject to any approval process by the 3GPP Organizational Partners and shall not be implemented. This Specification is provided for future development work within 3GPP only. The Organizational Partners accept no liability for any use of this Specification. Specifications and Reports for implementation of the 3GPP™ system should be obtained via the 3GPP Organizational Partners' Publications Offices.

3GPP

Postal address

3GPP support office address

650 Route des Lucioles - Sophia Antipolis
Valbonne - FRANCE
Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Internet

<http://www.3gpp.org>

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© 2023, 3GPP Organizational Partners (ARIB, ATIS, CCSA, ETSI, TSDSI, TTA, TTC).
All rights reserved.

UMTS™ is a Trade Mark of ETSI registered for the benefit of its members
3GPP™ is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners
LTE™ is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners
GSM® and the GSM logo are registered and owned by the GSM Association

Contents

Foreword.....	5
1 Scope.....	6
2 References.....	6
3 Definitions, symbols and abbreviations.....	7
3.1 Definitions.....	7
3.2 Symbols.....	8
3.3 Abbreviations.....	8
4 UE radio access capability parameters.....	9
4.1 Supported max data rate.....	9
4.1.1 General.....	9
4.1.2 Supported max data rate for DL/UL.....	9
4.1.3 Void.....	10
4.1.4 Total layer 2 buffer size for DL/UL.....	10
4.1.5 Supported max data rate for SL.....	11
4.1.6 Total layer 2 buffer size for NR SL.....	11
4.2 UE Capability Parameters.....	12
4.2.1 Introduction.....	12
4.2.2 General parameters.....	14
4.2.3 SDAP Parameters.....	17
4.2.4 PDCP Parameters.....	18
4.2.5 RLC parameters.....	21
4.2.6 MAC parameters.....	22
4.2.7 Physical layer parameters.....	27
4.2.7.1 <i>BandCombinationList</i> parameters.....	27
4.2.7.2 <i>BandNR</i> parameters.....	34
4.2.7.2a <i>SharedSpectrumChAccessParamsPerBand</i>	87
4.2.7.2b <i>FR2-2-AccessParamsPerBand</i>	93
4.2.7.3 <i>CA-ParametersEUTRA</i>	97
4.2.7.4 <i>CA-ParametersNR</i>	98
4.2.7.5 <i>FeatureSetDownlink</i> parameters.....	130
4.2.7.6 <i>FeatureSetDownlinkPerCC</i> parameters.....	137

Release 17

4.2.7.7	<i>FeatureSetUplink</i> parameters.....	143
4.2.7.8	<i>FeatureSetUplinkPerCC</i> parameters.....	155
4.2.7.9	<i>MRDC-Parameters</i>	158
4.2.7.10	<i>Phy-Parameters</i>	162
4.2.7.11	Other PHY parameters.....	177
4.2.7.12	<i>NRDC-Parameters</i>	180
4.2.7.13	<i>CarrierAggregationVariant</i>	182
4.2.7.14	<i>Phy-ParametersSharedSpectrumChAccess</i>	183
4.2.8	Void.....	185
4.2.9	<i>MeasAndMobParameters</i>	186
4.2.9a	<i>MeasAndMobParametersMRDC</i>	196
4.2.10	Inter-RAT parameters.....	199
4.2.10.1	Void.....	199
4.2.10.2	Void.....	199
4.2.11	Void.....	199
4.2.12	Void.....	199
4.2.13	IMS Parameters.....	199
4.2.14	RRC buffer size.....	200
4.2.15	IAB Parameters.....	200
4.2.15.1	Mandatory IAB-MT features.....	200
4.2.15.2	General Parameters.....	206
4.2.15.3	SDAP Parameters.....	206
4.2.15.4	PDCP Parameters.....	206
4.2.15.5	BAP Parameters.....	206
4.2.15.6	MAC Parameters.....	207
4.2.15.7	Physical layer parameters.....	207
4.2.15.7.1	BandNR parameters.....	207
4.2.15.7.2	Phy-Parameters.....	208
4.2.15.8	<i>MeasAndMobParameters</i> Parameters.....	210
4.2.15.9	MR-DC Parameters.....	210
4.2.15.10	NRDC Parameters.....	210
4.2.16	Sidelink Parameters.....	211
4.2.16.1	Sidelink Parameters in NR.....	211
4.2.16.1.1	Sidelink General Parameters.....	211
4.2.16.1.2	Sidelink PDCP Parameters.....	211

Release 17

4.2.16.1.3	Sidelink RLC Parameters.....	211
4.2.16.1.4	Sidelink MAC Parameters.....	212
4.2.16.1.5	Other PHY parameters.....	212
4.2.16.1.6	<i>BandSidelink</i> Parameters.....	213
4.2.16.1.7	<i>BandCombinationListSidelinkEUTRA-NR</i> Parameters.....	222
4.2.16.2	Sidelink Parameters in E-UTRA.....	225
4.2.16.2.1	<i>BandSideLinkEUTRA</i> parameters.....	226
4.2.17	SON parameters.....	226
4.2.18	UE-based performance measurement parameters.....	227
4.2.19	High speed parameters.....	228
4.2.20	Application layer measurement parameters.....	229
4.2.21	RedCap Parameters.....	229
4.2.21.1	Definition of RedCap UE.....	229
4.2.21.2	General parameters.....	230
4.2.21.3	PDCP parameters.....	230
4.2.21.4	RLC parameters.....	230
4.2.21.5	MeasAndMobParameters.....	231
4.2.21.6	Physical layer parameters.....	231
4.2.21.6.1	<i>BandNR</i> parameters.....	231
5	Optional features without UE radio access capability parameters.....	231
5.1	PWS features.....	231
5.2	UE receiver features.....	231
5.3	RRC connection.....	232
5.4	Other features.....	232
5.5	Sidelink Features.....	233
5.6	RRM measurement features.....	233
5.7	MDT and SON features.....	234
5.8	Extended DRX features.....	234
5.9	Sidelink Relay Features.....	234
5.10	MBS features.....	235

Release 17

6	Conditionally mandatory features without UE radio access capability parameters.....	236
7	Void.....	236
8	UE Capability Constraints.....	236
Annex A (normative): Differentiation of capabilities.....		238
A.1:	TDD/FDD differentiation of capabilities in TDD-FDD CA.....	238
A.2:	FR1/FR2 differentiation of capabilities in FR1-FR2 CA.....	239
A.3:	TDD/FDD differentiation of capabilities for sidelink.....	240
A.4:	Sidelink capabilities applicable to Uu and PC5.....	241
A.5:	General differentiation of capabilities in Cross-Carrier operation.....	244
Annex B (informative): UE capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations.....		246
Annex C (informative): Change history.....		248

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document defines the NR UE Radio Access Capability Parameters.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
- [2] 3GPP TS 38.101-1: "NR; User Equipment (UE) radio transmission and reception Part 1: Range 1 Standalone".
- [3] 3GPP TS 38.101-2: "NR; User Equipment (UE) radio transmission and reception Part 2: Range 2 Standalone".
- [4] 3GPP TS 38.101-3: "NR; User Equipment (UE) radio transmission and reception Part 3: Range 1 and Range 2 Interworking operation with other radios".
- [5] 3GPP TS 38.133: "NR; Requirements for support of radio resource management".
- [6] 3GPP TS 38.211: "NR; Physical channels and modulation".
- [7] 3GPP TS 37.340: "Evolved Universal Terrestrial Radio Access (E-UTRA) and NR Multi-connectivity".
- [8] 3GPP TS 38.321: "NR; Medium Access Control (MAC) protocol specification".
- [9] 3GPP TS 38.331: "NR; Radio Resource Control (RRC) protocol specification".
- [10] 3GPP TS 38.212: "NR; Multiplexing and channel coding".
- [11] 3GPP TS 38.213: "NR; Physical layer procedures for control".
- [12] 3GPP TS 38.214: "NR; Physical layer procedures for data".
- [13] 3GPP TS 38.215: "NR; Physical layer measurements".
- [14] 3GPP TS 36.101: "Evolved Universal Terrestrial Radio Access (E-UTRA) radio transmission and reception".
- [15] 3GPP TS 36.306: "Evolved Universal Terrestrial Radio Access (E-UTRA) User Equipment (UE) radio access capabilities".
- [16] 3GPP TS 38.323: "NR; Packet Data Convergence Protocol (PDCP) specification".
- [17] 3GPP TS 36.331: "Evolved Universal Terrestrial Radio Access (E-UTRA) Radio Resource Control (RRC); Protocol Specification".
- [18] 3GPP TS 38.101-4: "NR; User Equipment (UE) radio transmission and reception Part 4: Performance requirements".

Release 17

- [19] 3GPP TS 36.213: "Evolved Universal Terrestrial Radio Access (E-UTRA); Physical layer procedures".
- [20] 3GPP TS 25.306: "UE radio access capabilities".
- [21] 3GPP TS 38.304: "User Equipment (UE) procedures in Idle mode and RRC Inactive state".
- [22] 3GPP TS 37.355: "LTE Positioning Protocol (LPP)".
- [23] 3GPP TS 38.340: "NR; Backhaul Adaptation Protocol (BAP) specification".
- [24] 3GPP TR 38.822: "NR; User Equipment (UE) feature list".
- [25] 3GPP TS 37.324: "E-UTRA and NR; Service Data Adaptation Protocol (SDAP) specification"
- [26] 3GPP TS 38.314: "NR; Layer 2 Measurements".
- [27] 3GPP TS 36.133: "Evolved Universal Terrestrial Radio Access (E-UTRA); Requirements for support of radio resource management".
- [28] 3GPP TS 38.300: "NR; NR and NG-RAN Overall Description; Stage-2".
- [29] 3GPP TS 26.247: "Transparent end-to-end Packet-switched Streaming Service (PSS); Progressive Download and Dynamic Adaptive Streaming over HTTP (3GP-DASH)".
- [30] 3GPP TS 26.114: "IP Multimedia Subsystem (IMS); Multimedia Telephony; Media handling and interaction".
- [31] 3GPP TS 26.118: "Virtual Reality (VR) profiles for streaming applications".
- [32] 3GPP TS 37.213: "Physical layer procedures for shared spectrum channel access".
- [33] 3GPP TS 38.401: "NG-RAN; Architecture description".
- [34] 3GPP TS 38.101-5: "NR; User Equipment (UE) radio transmission and reception; Part 5: Satellite access Radio Frequency (RF) and performance requirements".
- [35] 3GPP TS 38.104: "NR; Base Station (BS) radio transmission and reception".

3 Definitions, symbols and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

Fallback band combination: A Uu band combination that would result from another Uu band combination (parent band combination) by releasing at least one SCell or uplink configuration of SCell, or SCG, or SUL. A PC5 band combination that would result from another PC5 band combination (parent band combination) by releasing at least one sidelink carrier. An intra-band non-contiguous band combination is not considered to be a fallback band combination of an intra-band contiguous band combination. A fallback band combination supports the same channel bandwidth(s) for each carrier as its parent band combination(s).

Fallback per band feature set: A feature set per band that has same or lower capabilities than the reported capabilities from the reported feature set per band for a given band.

Fallback per CC feature set: A feature set per CC that has same or lower capabilities than the capabilities of UE (e.g. supported MIMO layers, BW, modulation order) while keeping the numerology the same from the reported feature set per CC for a given carrier per band. The *supportedMinBandwidthDL/supportedMinBandwidthUL* defines the lower bound of the bandwidth supported by the UE.

RedCap UE: The UE with reduced capabilities as specified in clause 4.2.21.1.

Switching SCell (sSCell): The SCell configured with cross-carrier scheduling to PCell/PSCell.

3.2 Symbols

For the purposes of the present document, the following symbols apply:

MaxDLDataRate:	Maximum DL data rate
MaxDLDataRate_MN:	Maximum DL data rate in the MN
MaxDLDataRate_SN:	Maximum DL data rate in the SN
MaxULDataRate:	Maximum UL data rate
MaxSLtxDataRate:	Maximum SL data rate in transmission
MaxSLrxDataRate:	Maximum SL data rate in reception

3.3 Abbreviations

For the purposes of the present document, the abbreviations given in TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in TR 21.905 [1].

A-CSI	Aperiodic-CSI
BAP	Backhaul Adaptation Protocol
BC	Band Combination
BPS	Body Proximity Sensing
BT	Bluetooth
CCS	Cross Carrier Scheduling
CMR	Channel Measurement Resource
CPAC	Conditional PSCell Addition/Change
DAPS	Dual Active Protocol Stack
DL	Downlink
EHC	Ethernet Header Compression
FS	Feature Set
FSPC	Feature Set Per Component-carrier
GSO	Geosynchronous Orbit
HSDN	High Speed Dedicated Network
IAB-MT	Integrated Access Backhaul Mobile Termination
MAC	Medium Access Control
MHI	Mobility History Information
MBS	Multicast/Broadcast Service
MCG	Master Cell Group
MN	Master Node
MRB	MBS Radio Bearer
MR-DC	Multi-Radio Dual Connectivity
mTRP	Multiple TRP
MUSIM	Multi-Universal Subscriber Identity Module
NCJT	Non-Coherent Joint Transmission
NCSG	Network Controlled Small Gap
NGSO	Non-Geosynchronous Orbit
NTN	Non-Terrestrial Network
P-CSI	Periodic CSI
PDCP	Packet Data Convergence Protocol
QoE	Quality of Experience
RLC	Radio Link Control
RTT	Round Trip Time
SCG	Secondary Cell Group
SDAP	Service Data Adaptation Protocol
SN	Secondary Node
sTRP	Serving TRP
TRP	Transmit/Receive Point
UDC	Uplink Data Compression
UL	Uplink
WLAN	Wireless Local Area Network

4 UE radio access capability parameters

4.1 Supported max data rate

4.1.1 General

The DL, UL and SL max data rate supported by the UE is calculated by band or band combinations supported by the UE. A UE supporting NR (NR SA, MR-DC) shall support the calculated DL and UL max data rate defined in 4.1.2. A UE supporting NR sidelink communication shall support the calculated SL max data rate defined in 4.1.5.

4.1.2 Supported max data rate for DL/UL

For NR, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

$$\text{data rate (in Mbps)} = 10^{-6} \cdot \sum_{j=1}^J \left(v_{\text{Layers}}^{(j)} \cdot Q_m^{(j)} \cdot f^{(j)} \cdot R_{\text{max}} \cdot \frac{N_{\text{PRB}}^{BW^{(j)},\mu} \cdot 12}{T_s^\mu} \cdot (1 - OH^{(j)}) \right)$$

wherein

J is the number of aggregated component carriers in a band or band combination

$R_{\text{max}} = 948/1024$

For the j -th CC,

$v_{\text{Layers}}^{(j)}$ is the maximum number of supported layers given by *maxNumberMIMO-LayersPDSCH* for downlink and maximum of *maxNumberMIMO-LayersCB-PUSCH* and *maxNumberMIMO-LayersNonCB-PUSCH* for uplink.

$Q_m^{(j)}$ is the maximum supported modulation order given by *supportedModulationOrderDL* for downlink and *supportedModulationOrderUL* for uplink.

$f^{(j)}$ is the scaling factor given by *scalingFactor* or *scalingFactor-1024QAM-FR1* and can take the values 1, 0.8, 0.75, and 0.4.

μ is the numerology (as defined in TS 38.211 [6])

T_s^μ is the average OFDM symbol duration in a subframe for numerology μ , i.e. $T_s^\mu = \frac{10^{-3}}{14 \cdot 2^\mu}$.

Note that normal cyclic prefix is assumed.

$N_{\text{PRB}}^{BW^{(j)},\mu}$ is the maximum RB allocation in bandwidth $BW^{(j)}$ with numerology μ , as defined in 5.3 TS 38.101-1 [2], 5.3 TS 38.101-2 [3], and 5.3 TS 38.101-5 [34], where $BW^{(j)}$ is the UE supported maximum bandwidth in the given band or band combination.

$OH^{(j)}$ is the overhead and takes the following values

0.14, for frequency range FR1 for DL

0.18, for frequency range FR2 for DL

0.08, for frequency range FR1 for UL

0.10, for frequency range FR2 for UL

NOTE 1: Only one of the UL or SUL carriers (the one with the higher data rate) is counted for a cell operating SUL.

NOTE 2: For UL Tx switching between carriers, only the supported MIMO layer combination across carriers that results in the highest combined data rate is counted for the carriers in the supported maximum UL data rate.

Release 17

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations. For the CCs where UE supports *pdsch-1024QAM-2MIMO-FR1-r17* for the concerned band, data rate shall be derived as maximum what UE would support if using 1024 QAM (when *mcs-Table-r17* or *mcs-TableDCI-1-2-r17* is configured) or 256 QAM.

For single carrier NR SA operation, the UE shall support a data rate for the carrier that is no smaller than the data rate computed using the above formula, with $J=1$ CC and component $v_{Layers}^{(j)} \cdot Q_m^{(j)} \cdot f_{\square}^{(j)}$ is no smaller than 4.

NOTE 3: As an example, the value 4 in the component above can correspond to $v_{Layers}^{(j)}=1$, $Q_m^{(j)}=4$ and $f_{\square}^{(j)}=1$.

For EUTRA in case of MR-DC, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

$$\text{Data rate (in Mbps)} = 10^{-3} * \sum_{j=1}^J TBS_j \cdot 10^{-3} \cdot \sum_{j=1}^J TBS_j$$

wherein

J is the number of aggregated EUTRA component carriers in MR-DC band combination

TBS_j is the total maximum number of DL-SCH transport block bits received or the total maximum number of UL-SCH transport block bits transmitted, within a 1ms TTI for j -th CC, as derived from TS36.213 [19] based on the UE supported maximum MIMO layers for the j -th CC, and based on the maximum modulation order for the j -th CC and number of PRBs based on the bandwidth of the j -th CC according to indicated UE capabilities.

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For MR-DC, the approximate maximum data rate is computed as the sum of the approximate maximum data rates from NR and EUTRA.

4.1.3 Void

4.1.4 Total layer 2 buffer size for DL/UL

The total layer 2 buffer size is defined as the sum of the number of bytes that the UE is capable of storing in the RLC transmission windows and RLC reception and reassembly windows and also in PDCP reordering windows for all radio bearers.

The required total layer 2 buffer size in MR-DC is the maximum value of the calculated values based on the following equations:

- $MaxULDataRate_MN * RLCRTT_MN + MaxULDataRate_SN * RLCRTT_SN + MaxDLDataRate_SN * RLCRTT_SN + MaxDLDataRate_MN * (RLCRTT_SN + X2/Xn\ delay + Queuing\ in\ SN)$
- $MaxULDataRate_MN * RLCRTT_MN + MaxULDataRate_SN * RLCRTT_SN + MaxDLDataRate_MN * RLCRTT_MN + MaxDLDataRate_SN * (RLCRTT_MN + X2/Xn\ delay + Queuing\ in\ MN)$

Otherwise it is calculated by $MaxDLDataRate * RLC\ RTT + MaxULDataRate * RLC\ RTT$.

NOTE: Additional L2 buffer required for preprocessing of data is not taken into account in above formula.

The required total layer 2 buffer size is determined as the maximum total layer 2 buffer size of all the calculated ones for each band combination and the applicable Feature Set combination in the supported MR-DC or NR band combinations. The RLC RTT for NR cell group corresponds to the smallest SCS numerology supported in the band combination and the applicable Feature Set combination.

wherein

$X2/Xn\ delay + Queuing\ in\ SN = 25ms$ if SCG is NR, and $55ms$ if SCG is EUTRA

$X2/Xn\ delay + Queuing\ in\ MN = 25ms$ if MCG is NR, and $55ms$ if MCG is EUTRA

Release 17

RLC RTT for EUTRA cell group = 75ms

RLC RTT for NR cell group is defined in Table 4.1.4-1

Table 4.1.4-1: RLC RTT for NR cell group per SCS

SCS (kHz)	RLC RTT (ms)
15KHz	50
30KHz	40
60KHz	30
120KHz	20
480KHz	20
960KHz	20

4.1.5 Supported max data rate for SL

For NR sidelink, the approximate data rate is computed as follows.

$$\text{data rate (in Mbps)} = 10^{-6} \cdot v_{Layers} \cdot Q_m \cdot f \cdot R_{max} \cdot \frac{N_{PRB}^{BW, \mu} \cdot 12}{T_s^\mu} \cdot (1 - OH)$$

wherein

$$R_{max} = 948/1024,$$

v_{Layers} is the the maximum number of supported layers for sidelink transmission (or reception) given by UE capability on supporting rank 2 PSSCH transmission and *rankTwoReception*,

Q_m is the maximum supported modulation order between 6 or 8 given by *sl-Tx-256QAM* and *sl-Rx-256QAM*,
 f is the scaling factor for sidelink transmission and reception given by *scalingFactorTxSidelink* and *scalingFactorRxSidelink* respectively, as specified in TS 36.331 [17] and TS 38.331 [9], and can take the values 1, 0.8, 0.75, and 0.4.

μ is the numerology (as defined in TS 38.211 [6])

T_s^μ is the average OFDM symbol duration in a subframe for numerology μ , i.e. $T_s^\mu = \frac{10^{-3}}{14 \cdot 2^\mu}$. Note

that normal cyclic prefix is assumed.

$N_{PRB}^{BW, \mu}$ is the maximum possible RB allocation in bandwidth BW for PSSCH, where BW is the UE supported maximum bandwidth in the given band or band combination,

OH is the overhead and takes the following values

0.217, for frequency range FR1 for SL

0.25, for frequency range FR2 for SL

4.1.6 Total layer 2 buffer size for NR SL

The total layer 2 buffer size for NR sidelink communication is defined as the sum of the number of bytes that the UE is capable of storing in the RLC transmission windows and RLC reception and reassembly windows and also in PDCP reordering windows for all radio bearers for NR sidelink communication.

The required total layer 2 buffer size for NR sidelink communication is the maximum value of the calculated values based on the following equations:

$$\text{MaxSLtxDataRate} * \text{RLC RTT} + \text{MaxSLrxDataRate} * \text{RLC RTT}.$$

NOTE: Additional L2 buffer required for preprocessing of data is not taken into account in above formula.

The required total layer 2 buffer size for NR sidelink communication is determined as the maximum total layer 2 buffer size of all the calculated ones for each band combination and the applicable Feature Set combination in the supported NR sidelink band combinations. The RLC RTT for NR sidelink communication corresponds to the smallest SCS numerology supported in the band combination and the applicable Feature Set combination.

Release 17

wherein

RLC RTT for NR sidelink communication is defined in Table 4.1.6-1

Table 4.1.6-1: RLC RTT for NR sidelink communication per SCS

SCS (kHz)	RLC RTT (ms)
15KHz	200
30KHz	100
60KHz	50
120KHz	25

4.2 UE Capability Parameters

4.2.1 Introduction

The following clauses define the UE radio access capability parameters. Only parameters for which there is the possibility for UEs to signal different values are considered as UE radio access capability parameters. Therefore, mandatory features without capability parameters that are the same for all UEs are not listed here.

The network needs to respect the signalled UE radio access capability parameters when configuring the UE and when scheduling the UE.

For capabilities that required to be set consistently for all FDD-FR1 bands (i.e. capabilities that are supposed to be per UE), the UE shall also set capability values for all SUL bands with same values for FDD-FR1 bands if SUL band is supported by the UE.

The UE may support different functionalities between FDD and TDD, and/or between FR1 and FR2. The UE shall indicate the UE capabilities as follows. In the table of UE capability parameter in subsequent clauses, "Yes" in the column by "FDD-TDD DIFF" and "FR1-FR2 DIFF" indicates the UE capability field can have a different value for between FDD and TDD or between FR1 and FR2 and "No" indicates if it cannot. "(Incl FR2-2 DIFF)" in the column by "FR1-FR2 DIFF" indicates the UE capability field can have a different value for between FR2-1 and FR2-2. Regarding to the per UE capabilities that are FDD/TDD differentiated (i.e. capabilities indicated as "Yes" in the column by "FDD-TDD DIFF"), the corresponding capabilities indicated by the FDD capability is applied to SUL if SUL band is supported by the UE. "FD" in the column indicates to refer the associated field description. "FR1 only" or "FR2 only" in the column indicates the associated feature is only supported in FR1 or FR2 and "TDD only" indicates the associated feature is only supported in TDD and not applicable to SUL carriers. "N/A" in the column indicates it is not applicable to the feature (e.g. the signalling supports the UE to have different values between FDD and TDD or between FR1 and FR2).

- 1> set all fields of UE-NR/MRDC-Capability except fdd-Add-UE-NR/MRDC/Sidelink-Capabilities, tdd-Add-UE-NR/MRDC/Sidelink-Capabilities, fr1-Add-UE-NR/MRDC-Capabilities and fr2-Add-UE-NR/MRDC-Capabilities, to include the values applicable for all duplex mode(s) and frequency range(s) that the UE supports;
- 1> if UE supports both FDD (or SUL) and TDD and if (some of) the UE capability fields have a different value for FDD (or SUL) and TDD
 - 2> if for FDD (and, if the UE supports SUL, for SUL), the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability/SidelinkParameters:
 - 3> include field fdd-Add-UE-NR/MRDC/Sidelink-Capabilities and set it to include fields reflecting the additional functionality applicable for FDD;
 - 2> if for TDD, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability/SidelinkParameters:
 - 3> include field tdd-Add-UE-NR/MRDC/Sidelink-Capabilities and set it to include fields reflecting the additional functionality applicable for TDD;
- 1> if UE supports both FR1 and FR2 and if (some of) the UE capability fields have a different value for FR1 and FR2:

Release 17

- 2> if for FR1, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
 - 3> include field fr1-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FR1;
- 2> if for FR2, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
 - 3> include field fr2-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FR2;

NOTE 1: The fields which indicate "shall be set to 1" or "shall be set to *supported*" in the following tables means these features are purely mandatory and are assumed they are the same as mandatory without capability signalling.

NOTE 2: For the case where the UE is allowed to support different functionality between FDD and TDD and between FR1 and FR2 according to the specification, the UE capability indication is clarified in Annex B.

For optional features, the UE radio access capability parameter indicates whether the feature has been implemented and successfully tested. For mandatory features with the UE radio access capability parameter, the parameter indicates whether the feature has been successfully tested. In the table of UE capability parameter in subsequent clauses, "Yes" in the column by "M" indicates the associated feature is mandatory and "No" indicates the associated feature is optional. "CY" in the column indicates the associated feature is conditional mandatory and the condition is described in the field description and the associated feature is considered mandatory with capability parameter, when the described condition is satisfied. "FD" in the column indicates to refer the associated field description. Some parameters in subsequent clauses are not related to UE features and in the case, "N/A" is indicated in the column.

UE capability parameters have hierarchical structure. In the table of UE capability parameter in subsequent clauses, "Per" indicates the level the associated parameter is included. "UE" in the column indicates the associated parameter is signalled per UE, "Band" indicates it is signalled per band, "BC" indicates it is signalled per band combination, "FS" indicates it is signalled per feature set (per band per band combination), "FSPC" indicates it is signalled per feature set per component carrier (per CC per band per band combination), and "FD" in the column indicates to refer the associated field description.

NOTE 3: Unless otherwise specified, for dependent capabilities with prerequisite capability in a finer granularity, the UE should indicate support of the prerequisite capability in at least one finer granularity. And the dependent capability is supported only in the finer granularity where the prerequisite capability is supported, e.g. a UE indicating support of *supportNewDMRS-Port-r16* (dependent capability which is defined per band) should indicate at least one band combination where *singleDCI-SDM-scheme-r16* (prerequisite capability which is defined per feature set) is supported in the corresponding band. In this case, *supportNewDMRS-Port-r16* is considered supported only in the corresponding band of the band combination where *singleDCI-SDM-scheme-r16* is supported.

Release 17

4.2.2 General parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
accessStratumRelease Indicates the access stratum release the UE supports as specified in TS 38.331 [9].	UE	Yes	No	No
crossCarrierSchedulingConfigurationRelease-r17 Indicates whether the UE supports using <i>crossCarrierSchedulingConfigRelease</i> to release the configurations configured by <i>crossCarrierSchedulingConfig</i> .	UE	No	No	No
delayBudgetReporting Indicates whether the UE supports delay budget reporting as specified in TS 38.331 [9].	UE	No	No	No
dl-DedicatedMessageSegmentation-r16 Indicates whether the UE supports reception of segmented DL RRC messages.	UE	No	No	No
drx-Preference-r16 Indicates whether the UE supports providing its preference of a cell group on DRX parameters for power saving in RRC_CONNECTED, as specified in TS 38.331 [9].	UE	No	No	No
gNB-SideRTT-BasedPDC-r17 Indicates whether the UE supports gNB-side RTT-based PDC, as specified in TS 38.300 [28]. A UE supporting this feature shall also support <i>rtt-BasedPDC-CSI-RS-ForTracking-r17</i> and/or <i>rtt-BasedPDC-PRS-r17</i> .	UE	No	No	No
inactiveState Indicates whether the UE supports RRC_INACTIVE as specified in TS 38.331 [9].	UE	Yes	No	No
inactiveStateNTN-r17 Indicates whether the UE supports RRC_INACTIVE in NTN as specified in TS 38.331 [9]. It is mandated if the UE indicates the support of <i>nonTerrestrialNetwork-r17</i> .	UE	CY	No	No
inactiveStatePO-Determination-r17 Indicates whether the UE supports to use the same <i>i_s</i> to determine PO in RRC_INACTIVE state as in RRC_IDLE state.	UE	No	No	No
inDeviceCoexInd-r16 Indicates whether the UE supports IDC (In-Device Coexistence) assistance information as specified in TS 38.331 [9].	UE	No	No	No
maxBW-Preference-r16, maxBW-Preference-r17 Indicates whether the UE supports providing its preference of a cell group on the maximum aggregated bandwidth for power saving in RRC_CONNECTED, as specified in TS 38.331 [9].	UE	No	No	Yes (Incl FR2-2 DIFF)
maxCC-Preference-r16 Indicates whether the UE supports providing its preference of a cell group on the maximum number of secondary component carriers for power saving in RRC_CONNECTED, as specified in TS 38.331 [9].	UE	No	No	No
maxMIMO-LayerPreference-r16, maxMIMO-LayerPreference-r17 Indicates whether the UE supports providing its preference of a cell group on the maximum number of MIMO layers for power saving in RRC_CONNECTED, as specified in TS 38.331 [9].	UE	No	No	Yes (Incl FR2-2 DIFF)
maxMRB-Add-r17 Indicates the additional maximum number of MRBs that the UE supports for MBS multicast reception as specified in TS 38.331 [9].	UE	No	No	No
mcgRLF-RecoveryViaSCG-r16 Indicates whether the UE supports recovery from MCG RLF via split SRB1 (if supported) and via SRB3 (if supported) as specified in TS 38.331[9].	UE	No	No	No
minSchedulingOffsetPreference-r16 Indicates whether the UE supports providing its preference on the minimum scheduling offset for cross-slot scheduling of the cell group for power saving in RRC_CONNECTED, as specified in TS 38.331 [9].	UE	No	No	No
mpsPriorityIndication-r16 Indicates whether the UE supports <i>mpsPriorityIndication</i> on RRC release with redirect as defined in TS 38.331 [9].	UE	No	No	No
musim-GapPreference-r17 Indicates whether the UE supports providing MUSIM assistance information with MUSIM gap preference and related MUSIM gap configuration, as defined in TS 38.331 [9]. UE supporting this feature supports 3 periodic gaps and 1 aperiodic gap.	UE	No	No	No
musimLeaveConnected-r17 Indicates whether the UE supports providing MUSIM assistance information with indication of leaving RRC_CONNECTED state as defined in TS 38.331 [9].	UE	No	No	No

Release 17

nonTerrestrialNetwork-r17 Indicates whether the UE supports NR NTN access. If the UE indicates this capability the UE shall support the following NTN essential features, e.g., timer extension in MAC/RLC/PDCP layers and RACH adaptation to handle long RTT, acquiring NTN specific SIB and more than one TAC per PLMN broadcast in one cell.	UE	No	No	No
ntn-ScenarioSupport-r17 Indicates whether the UE supports the NTN features in GSO scenario or NGSO scenario. If a UE does not include this field but includes <i>nonTerrestrialNetwork-r17</i> , the UE supports the NTN features for both GSO and NGSO scenarios, and also supports mobility between GSO and NGSO scenarios.	UE	No	No	No
onDemandSIB-Connected-r16 Indicates whether the UE supports the on-demand request procedure of SIB(s) or posSIB(s) while in RRC_CONNECTED, as specified in TS 38.331 [9].	UE	No	No	No
overheatingInd Indicates whether the UE supports overheating assistance information.	UE	No	No	No
pei-SubgroupingSupportBandList-r17 Indicates whether the UE supports receiving paging early indication in DCI format 2_7 as specified in TS38.304 [21] for a list of frequency band. The UE shall support UEID based subgrouping for a frequency band if it indicates supporting of paging early indication reception for the frequency band. The set of OFDM symbols within a slot where UE can monitor the PEI PDCCH in Type 2A CSS is the same as the requirement for paging PDCCH in Type 2 CSS for IDLE and INACTIVE mode UEs.	UE	No	No	No
partialFR2-FallbackRX-Req Indicates whether the UE meets only a partial set of the UE minimum receiver requirements for the eligible FR2 fallback band combinations as defined in Clause 4.2 of TS 38.101-2 [3] and Clause 4.2 of TS 38.101-3 [4]. If not indicated, the UE shall meet all the UE minimum receiver requirements for all the FR2 fallback combinations in TS 38.101-2 [3] and TS 38.101-3 [4]. The UE shall support configuration of any of the FR2 fallback band combinations regardless of the presence or the absence of this field.	UE	No	No	No
ra-SDT-r17 Indicates whether the UE supports transmission of data and/or signalling over allowed radio bearers in RRC_INACTIVE state via Random Access procedure (i.e., RA-SDT) with 4-step RA type and if UE supports <i>twoStepRACH-r16</i> , with 2-step RA type, as specified in TS 38.331 [9].	UE	No	No	No
ra-SDT-NTN-r17 Indicates whether the UE supports transmission of data and/or signalling over allowed radio bearers in RRC_INACTIVE state in NTN via Random Access procedure (i.e., RA-SDT) with 4-step RA type and if UE supports <i>twoStepRACH-r16</i> for NTN, with 2-step RA type, as specified in TS 38.331 [9]. A UE supporting this feature shall also indicate the support of <i>nonTerrestrialNetwork-r17</i> .	UE	No	No	No
redirectAtResumeByNAS-r16 Indicates whether the UE supports reception of <i>redirectedCarrierInfo</i> in an <i>RRCRelease</i> message in response to an <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> which is triggered by the NAS layer, as specified in TS 38.331 [9].	UE	No	No	No
reducedCP-Latency Indicates whether the UE supports reduced control plane latency as defined in TS 38.331 [9].	UE	No	No	No
referenceTimeProvision-r16 Indicates whether the UE supports provision of <i>referenceTimeInfo</i> in <i>DLInformationTransfer</i> message and in SIB9 and reference time information preference indication via assistance information, as specified in TS 38.331 [9].	UE	No	No	No
releasePreference-r16 Indicates whether the UE supports providing its preference assistance information to transition out of RRC_CONNECTED for power saving, as specified in TS 38.331 [9].	UE	No	No	No
resumeWithStoredMCG-SCells-r16 Indicates whether the UE supports not deleting the stored MCG SCell configuration when initiating the resume procedure.	UE	No	No	No
resumeWithStoredSCG-r16 Indicates whether the UE supports not deleting the stored SCG configuration when initiating resume. The UE which indicates support for <i>resumeWithStoredSCG-r16</i> shall also indicate support for <i>resumeWithSCG-Config-r16</i> .	UE	No	No	No
resumeWithSCG-Config-r16 Indicates whether the UE supports (re-)configuration of an SCG during the resume procedure.	UE	No	No	No

Release 17

sliceInfoforCellReselection-r17 Indicates whether the UE supports slice-based cell reselection information in SIB and on RRC release for slice-based cell reselection in RRC_IDLE and RRC_INACTIVE as defined in TS 38.304 [21].	UE	No	No	No
splitSRB-WithOneUL-Path Indicates whether the UE supports UL transmission via MCG path and DL reception via either MCG path or SCG path, as specified for the split SRB in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in <i>UE-MRDC-CapabilityAddXDD-Mode</i>).	UE	No	No	No
splitDRB-withUL-Both-MCG-SCG Indicates whether the UE supports UL transmission via both MCG path and SCG path for the split DRB as specified in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in <i>UE-MRDC-CapabilityAddXDD-Mode</i>).	UE	Yes	No	No
srb3 Indicates whether the UE supports direct SRB between the SN and the UE as specified in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in <i>UE-MRDC-CapabilityAddXDD-Mode</i>). This field is not applied to NE-DC.	UE	Yes	No	No
srb-SDT-NTN-r17 Indicates whether the UE supports the usage of signalling radio bearer SRB2 over RA-SDT or CG-SDT in NTN, as specified in TS 38.331 [9]. A UE supporting this feature shall also indicate support of <i>ra-SDT-NTN-r17</i> , or <i>cg-SDT-r17</i> in NTN bands. A UE supporting this feature shall also indicate the support of <i>nonTerrestrialNetwork-r17</i> .	UE	No	No	No
srb-SDT-r17 Indicates whether the UE supports the usage of signalling radio bearer SRB2 over RA-SDT or CG-SDT, as specified in TS 38.331 [9]. A UE supporting this feature shall also indicate support of <i>ra-SDT-r17</i> or <i>cg-SDT-r17</i> .	UE	No	No	No
ul-GapFR2-Pattern-r17 Indicates FR2 UL gap pattern(s) supported by the UE for NR SA, for NR-DC without FR2-FR2 band combination, for NE-DC, and for (NG)EN-DC, if UE supports a band in FR2. The leading / leftmost bit (bit 0) corresponds to the FR2 UL gap pattern 0, the next bit corresponds to the FR2 UL gap pattern 1, as specified in TS 38.133 [5] and so on. The UE shall set at least one of the bits to 1 for FR2 UL gap pattern 1 and 3, if the UE indicates support for <i>ul-GapFR2-r17</i> in an FR2 band.	UE	CY	No	FR2 only
ul-RRC-Segmentation-r16 Indicates whether the UE supports uplink RRC segmentation of <i>UECapabilityInformation</i> as specified in TS 38.331 [9].	UE	No	No	No

4.2.3 SDAP Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF
as-ReflectiveQoS Indicates whether the UE supports AS reflective QoS.	UE	No	No

Release 17

4.2.4 PDCP Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF
continueEHC-Context-r16 Indicates that the UE supports EHC context continuation operation where the UE keeps the established EHC context(s) upon PDCP re-establishment, as specified in TS 38.323 [16].	UE	No	No
continueROHC-Context Defines whether the UE supports ROHC context continuation operation where the UE does not reset the current ROHC context upon PDCP re-establishment, as specified in TS 38.323 [16].	UE	No	No
ehc-r16 Indicates that the UE supports Ethernet header compression and decompression using EHC protocol, as specified in TS 38.323 [16]. The UE indicating this capability and indicating support for at least one ROHC profile, shall support simultaneous configuration of EHC and ROHC on different DRBs/multicast MRBs.	UE	No	No
extendedDiscardTimer-r16 Indicates whether the UE supports the additional values of PDCP discard timer. The supported additional values are 0.5ms, 1ms, 2ms, 4ms, 6ms and 8ms, as specified in TS 38.331 [9].	UE	No	No
jointEHC-ROHC-Config-r16 Indicates whether the UE supports simultaneous configuration of EHC and ROHC protocols for the same DRB/multicast MRB.	UE	No	No
maxNumberROHC-ContextSessions Defines the maximum number of ROHC header compression context sessions supported by the UE across all DRBs and multicast MRBs, excluding context sessions that leave all headers uncompressed.	UE	No	No
maxNumberEHC-Contexts-r16 Defines the maximum number of Ethernet header compression contexts supported by the UE across all DRBs and multicast MRBs and across UE's EHC compressor and EHC decompressor. The indicated number defines the number of contexts in addition to CID = "all zeros" as specified in TS 38.323 [16].	UE	No	No
outOfOrderDelivery Indicates whether UE supports out of order delivery of data to upper layers by PDCP.	UE	No	No
pdcp-DuplicationMCG-OrSCG-DRB Indicates whether the UE supports CA-based PDCP duplication over MCG or SCG DRB as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationMoreThanTwoRLC-r16 Defines whether the UE supports PDCP duplication with more than two RLC entities as specified in TS 38.323 [16]. The UE supporting this feature supports secondary RLC entity(ies) activation and deactivation based on duplication RLC Activation/Deactivation MAC CE as specified in TS 38.321 [8]. A UE supporting this feature shall also support <i>pdcp-DuplicationMCG-OrSCG-DRB</i> , <i>pdcp-DuplicationSplitDRB</i> , <i>pdcp-DuplicationSplitSRB</i> and <i>pdcp-DuplicationSRB</i> .	UE	No	No
pdcp-DuplicationSplitDRB Indicates whether the UE supports PDCP duplication over split DRB as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSplitSRB Indicates whether the UE supports PDCP duplication over split SRB1/2 as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSRB Indicates whether the UE supports CA-based PDCP duplication over SRB1/2 and/or, if (NG)EN-DC is supported, SRB3 as specified in TS 38.323 [16].	UE	No	No
shortSN Indicates whether the UE supports 12 bit length of PDCP sequence number.	UE	Yes	No

Release 17

<p>supportedROHC-Profiles Defines which ROHC profiles from the list below are supported by the UE:</p> <ul style="list-style-type: none"> - 0x0000 ROHC No compression (RFC 5795) - 0x0001 ROHC RTP/UDP/IP (RFC 3095, RFC 4815) - 0x0002 ROHC UDP/IP (RFC 3095, RFC 4815) - 0x0003 ROHC ESP/IP (RFC 3095, RFC 4815) - 0x0004 ROHC IP (RFC 3843, RFC 4815) - 0x0006 ROHC TCP/IP (RFC 6846) - 0x0101 ROHC RTP/UDP/IP (RFC 5225) - 0x0102 ROHC UDP/IP (RFC 5225) - 0x0103 ROHC ESP/IP (RFC 5225) - 0x0104 ROHC IP (RFC 5225) <p>A UE that supports one or more of the listed ROHC profiles shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795). An IMS voice capable UE shall indicate support of ROHC profiles 0x0000, 0x0001, 0x0002 and be able to compress and decompress headers of PDCP SDUs at a PDCP SDU rate corresponding to supported IMS voice codecs.</p>	UE	No	No
<p>udc-r17 Indicates whether the UE supports the uplink data compression operation as specified in TS 38.323 [16]. The capability signalling comprises of the following parameters:</p> <ul style="list-style-type: none"> - <i>standardDictionary-r17</i> indicates whether the UE supports UL data compression with SIP static dictionary as defined in TS 38.323 [16]. - <i>operatorDictionary-r17</i> indicates whether the UE supports UL data compression with operator defined dictionary. In this release, the UE can only support one operator defined dictionary. If the UE supports operator defined dictionary, the UE shall report <i>versionOfDictionary-r17</i> and <i>associatedPLMN-ID-r17</i> of the stored operator defined dictionary as defined in TS 38.331 [9]. This parameter is not required to be present if the UE is in VPLMN. The <i>associatedPLMN-ID-r17</i> is only associated to the operator defined dictionary which has no relationship with UE's HPLMN ID. - <i>continueUDC-r17</i> indicates whether the UE supports continuation of uplink data compression protocol operation where the UE does not reset the buffer upon PDCP re-establishment, as specified in TS 38.323 [16]. - <i>supportOfBufferSize-r17</i> indicates which compression buffer size the UE supports as specified in TS 38.323 [16]. Value kbyte4 means the UE supports 4096 bytes for compression buffer per UDC DRB. Value kbyte8 means the UE supports 8192 bytes for compression buffer per UDC DRB. <p>A UE that supports the uplink data compression operation shall support 2048 bytes for compression buffer per UDC DRB and support up to 2 UDC DRBs.</p>	UE	No	No
<p>uplinkOnlyROHC-Profiles Indicates the ROHC profile(s) that are supported in uplink-only ROHC operation by the UE.</p> <ul style="list-style-type: none"> - 0x0006 ROHC TCP (RFC 6846) <p>A UE that supports uplink-only ROHC profile(s) shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795).</p>	UE	No	No

4.2.5 RLC parameters

Definitions for parameters	Per	M	FDD-TDD DIFF
am-WithShortSN Indicates whether the UE supports AM DRB with 12 bit length of RLC sequence number.	UE	Yes	No
extendedT-PollRetransmit-r16 Indicates whether the UE supports the additional values of <i>T-PollRetransmit timer</i> . The supported additional values are 1ms, 2ms, 3ms and 4ms, as specified in TS 38.331 [9].	UE	No	No
extendedT-StatusProhibit-r16 Indicates whether the UE supports the additional values of <i>T-StatusProhibit timer</i> . The supported additional values are 1ms, 2ms, 3ms and 4ms, as specified in TS 38.331 [9].	UE	No	No
um-WithLongSN Indicates whether the UE supports UM DRB with 12 bit length of RLC sequence number.	UE	Yes	No
um-WithShortSN Indicates whether the UE supports UM DRB with 6 bit length of RLC sequence number.	UE	Yes	No

Release 17

4.2.6 MAC parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
autonomousTransmission-r16 Indicates whether the UE supports autonomous transmission of the MAC PDU generated for a deprioritized configured uplink grant as specified in TS 38.321 [8]. A UE supporting this feature shall also support <i>lch-priorityBasedPrioritization-r16</i> .	UE	No	No	No
directMCG-SCellActivation-r16, directMCG-SCellActivation-r17 Indicates whether the UE supports direct NR MCG SCell activation, as specified in TS 38.321 [8], upon SCell addition, upon reconfiguration with sync of the MCG, as specified in TS 38.331 [9].	UE	No	No	Yes (Incl FR2-2 DIFF)
directMCG-SCellActivationResume-r16, directMCG-SCellActivationResume-r17 Indicates whether the UE supports direct NR MCG SCell activation, as specified in TS 38.321 [8], upon reception of an <i>RRCResume</i> message, as specified in TS 38.331 [9].	UE	No	No	Yes (Incl FR2-2 DIFF)
directSCG-SCellActivation-r16, directSCG-SCellActivation-r17 Indicates whether the UE supports direct NR SCG SCell activation, as specified in TS 38.321 [8], upon SCell addition and upon reconfiguration with sync of the SCG, both performed via an <i>RRCReconfiguration</i> message received via SRB3 or contained in an <i>RRC(Connection)Reconfiguration</i> message received via SRB1, as specified in TS 38.331 [9] and TS 36.331 [17]. A UE indicating support of <i>directSCG-SCellActivation-r16</i> shall indicate support of EN-DC or support of NGEN-DC as specified in TS 36.331 [17] or support of NR-DC as specified in TS 38.331 [9].	UE	No	No	Yes (Incl FR2-2 DIFF)
directSCG-SCellActivationResume-r16, directSCG-SCellActivationResume-r17 Indicates whether the UE supports direct NR SCG SCell activation, as specified in TS 38.321 [8]: - upon reception of an <i>RRCReconfiguration</i> included in an <i>RRCCONNECTIONResume</i> message, as specified in TS 38.331 [9] and TS 36.331 [17], if the UE indicates support of EN-DC or NGEN-DC, and support of <i>resumeWithSCG-Config-r16</i> as specified in TS 36.331 [17], - upon reception of an <i>RRCReconfiguration</i> included in an <i>RRCResume</i> message, as specified in TS 38.331 [9], if the UE indicates support of NR-DC and of <i>resumeWithSCG-Config-r16</i> as specified in TS 38.331 [9]. A UE indicating support of <i>directSCG-SCellActivationResume-r16</i> shall indicate support of EN-DC or NGEN-DC and support of <i>resumeWithSCG-Config-r16</i> as specified in TS 36.331 [17] or indicate support of NR-DC and of <i>resumeWithSCG-Config-r16</i> as specified in TS 38.331 [9].	UE	No	No	Yes (Incl FR2-2 DIFF)
drx-Adaptation-r16, drx-Adaptation-r17 Indicates whether the UE supports DRX adaptation comprised of the following functional components: - Configured <i>ps-Offset</i> for the detection of DCI format 2_6 with CRC scrambling by <i>ps-RNTI</i> and reported <i>MinTimeGap</i> before the start of <i>drx-onDurationTimer</i> of Long DRX - Indication of UE whether or not to start <i>drx-onDurationTimer</i> for the next Long DRX cycle by detection of DCI format 2_6 - Configured UE wakeup or not when DCI format 2_6 is not detected at all monitoring occasions outside Active Time - Configured periodic CSI report apart from L1-RSRP (<i>ps-TransmitOtherPeriodicCSI</i>) when impacted by DCI format 2_6 that <i>drx-onDurationTimer</i> does not start for the next Long DRX cycle - Configured periodic L1-RSRP report (<i>ps-TransmitPeriodicL1-RSRP</i>) when impacted by DCI format 2_6 that <i>drx-onDurationTimer</i> does not start for the next Long DRX cycle The capability signalling includes the minimum time gap between the end of the slot of last DCI format 2_6 monitoring occasion and the beginning of the slot where the UE would start the <i>drx-onDurationTimer</i> of Long DRX for each SCS. The value <i>s1</i> indicates 1 slot. The value <i>s2</i> indicates 2 slots, and so on. Support of this feature is reported for licensed and unlicensed bands, respectively. When this field is reported, either of <i>sharedSpectrumChAccess-r16</i> or <i>non-SharedSpectrumChAccess-r16</i> shall be reported, at least.	UE	No	No	Yes (Incl FR2-2 DIFF)

Release 17

enhancedSkipUplinkTxConfigured-r16 Indicates whether the UE supports skipping UL transmission for a configured uplink grant only if no data is available for transmission and no UCI is multiplexed on the corresponding PUSCH of the uplink grant as specified in TS 38.321 [8].	UE	No	Yes	No
enhancedSkipUplinkTxDynamic-r16 Indicates whether the UE supports skipping UL transmission for an uplink grant addressed to a C-RNTI only if no data is available for transmission and no UCI is multiplexed on the corresponding PUSCH of the uplink grant as specified in TS 38.321 [8].	UE	No	Yes	No
enhancedUuDRX-forSidelink-r17 Indicates whether UE supports sidelink related Uu-DRX mechanisms for PDCCH monitoring. This field is only applicable if the UE supports <i>sl-TransmissionMode1-r16</i> .	UE	No	No	No
extendedDRX-CycleInactive-r17 Indicates whether UE supports the extended DRX in RRC_INACTIVE with values of 256, 512 and 1024 radio frames as specified in TS 38.331 [9]. The UE may indicate support for extended DRX in RRC_INACTIVE only if it supports extended DRX in RRC_IDLE.	UE	No	No	No
harq-FeedbackDisabled-r17 Indicates whether the UE supports disabled HARQ feedback for downlink transmission. A UE supporting this feature shall also indicate the support of <i>nonTerrestrialNetwork-r17</i> .	UE	No	No	No
intraCG-Prioritization-r17 Indicates whether the UE supports the HARQ process ID selection based on LCH priority as specified in TS 38.321 [8]. A UE supporting this feature shall also support <i>jointPrioritizationCG-Retx-Timer-r17</i> .	UE	No	No	No
jointPrioritizationCG-Retx-Timer-r17 Indicates whether the UE supports simultaneous configuration of LCH based prioritization and <i>cg-RetransmissionTimer-r16</i> as specified in TS 38.321 [8]. A UE supporting this feature shall also support <i>lch-priorityBasedPrioritization-r16</i> and <i>configuredGrantWithReTx-r16</i> .	UE	No	No	No
lastTransmissionUL-r17 Indicates whether the UE supports starting the <i>drx-HARQ-RTT-TimerUL</i> after the end of the last transmission within a bundle as specified in TS 38.321 [8].	UE	No	No	No
lch-PriorityBasedPrioritization-r16 Indicates whether the UE supports prioritization between overlapping grants and between scheduling request and overlapping grants based on LCH priority as specified in TS 38.321 [8].	UE	No	No	No
lch-ToConfiguredGrantMapping-r16 Indicates whether the UE supports restricting data transmission from a given LCH to a configured (sub-) set of configured grant configurations (see <i>allowedCG-List-r16</i> in <i>LogicalChannelConfig</i> in TS 38.331 [9]) as specified in TS 38.321 [8].	UE	No	No	No
lch-ToGrantPriorityRestriction-r16 Indicates whether the UE supports restricting data transmission from a given LCH to a configured (sub-) set of dynamic grant priority levels (see <i>allowedPHY-PriorityIndex-r16</i> in <i>LogicalChannelConfig</i> in TS 38.331 [9]) as specified in TS 38.321 [8].	UE	No	No	No
lch-ToSCellRestriction Indicates whether the UE supports restricting data transmission from a given LCH to a configured (sub-) set of serving cells (see <i>allowedServingCells</i> in <i>LogicalChannelConfig</i>). A UE supporting <i>pdcp-DuplicationMCG-OrSCG-DRB</i> or <i>pdcp-DuplicationSRB</i> (see <i>PDCP-Config</i>) shall also support <i>lch-ToSCellRestriction</i> .	UE	No	No	No
lcp-Restriction Indicates whether UE supports the selection of logical channels for each UL grant based on RRC configured restriction using RRC parameters <i>allowedSCS-List</i> , <i>maxPUSCH-Duration</i> , and <i>configuredGrantType1Allowed</i> as specified in TS 38.321 [8].	UE	No	No	No
logicalChannelSR-DelayTimer Indicates whether the UE supports the <i>logicalChannelSR-DelayTimer</i> as specified in TS 38.321 [8].	UE	No	Yes	No
longDRX-Cycle Indicates whether UE supports long DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes	No
mg-ActivationCommPRS-Meas-r17 Indicates whether UE supports preconfiguration of MGs in RRC signalling for PRS measurements and the use of DL MAC CE from the gNB, as specified in TS 38.321 [8], to activate/deactivate the preconfigured MG for PRS measurements.	UE	No	No	No

Release 17

mg-ActivationRequestPRS-Meas-r17 Indicates whether UE supports preconfiguration of MGs in RRC signalling for PRS measurements and supports the use of UL MAC CE, as specified in TS38.321 [8], to request the activation/deactivation of the preconfigured MG for PRS measurements. The UE can include this field only if the UE supports <i>mg-ActivationCommPRS-Meas-r17</i> .	UE	No	No	No
multipleConfiguredGrants Indicates whether UE supports more than one configured grant configurations (including both Type 1 and Type 2) in a cell group. For each cell, the UE supports at most one configured grant per BWP and the maximum number of configured grant configurations per cell group is 2. If absent, for each configured cell group, the UE only supports one configured grant configuration on one serving cell.	UE	No	Yes	No
multipleSR-Configurations Indicates whether the UE supports 8 SR configurations per PUCCH cell group as specified in TS 38.321 [8].	UE	No	Yes	No
recommendedBitRate Indicates whether the UE supports the bit rate recommendation message from the gNB to the UE as specified in TS 38.321 [8].	UE	No	No	No
recommendedBitRateMultiplier-r16 Indicates whether the UE supports the bit rate multiplier for recommended bit rate MAC CE as specified in TS 38.321 [8], clause 6.1.3.20. This field is only applicable if the UE supports <i>recommendedBitRate</i> .	UE	No	No	No
recommendedBitRateQuery Indicates whether the UE supports the bit rate recommendation query message from the UE to the gNB as specified in TS 38.321 [8]. This field is only applicable if the UE supports <i>recommendedBitRate</i> .	UE	No	No	No
secondaryDRX-Group-r16 Indicates whether UE supports secondary DRX group as specified in TS 38.321 [8].	UE	No	Yes	No
shortDRX-Cycle Indicates whether UE supports short DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes	No
simultaneousSR-PUSCH-DiffPUCCH-groups-r17 Indicates whether the UE supports simultaneous transmission of SR and PUSCH in different PUCCH groups as specified in TS 38.321 [8].	UE	No	No	No
singlePHR-P-r16 Indicates whether UE supports the P bit in single PHR MAC CE as specified in TS 38.321 [8].	UE	No	No	No
skipUplinkTxDynamic Indicates whether the UE supports skipping of UL transmission for an uplink grant indicated on PDCCH if no data is available for transmission as specified in TS 38.321 [8].	UE	No	Yes	No
spCell-BFR-CBRA-r16 Indicates whether the UE supports sending BFR MAC CE for SpCell BFR as specified in TS 38.321 [8].	UE	No	No	No
srs-ResourceId-Ext-r16 Indicates whether the UE supports the extended 6-bit (Positioning) SRS resource ID in SP Positioning SRS Activation/Deactivation MAC CE, as specified in TS 38.321 [8].	UE	No	No	No
sr-TriggeredBy-TA-Report-r17 Indicates whether the UE supports triggering of SR when a TA report is triggered and there are no available UL-SCH resources. A UE supporting this feature shall also indicate the support of <i>nonTerrestrialNetwork-r17</i> .	UE	No	No	No
survivalTime-r17 Indicates whether the UE supports services with survival time requirement using configured grant resource and PDCP duplication, as specified in TS 38.321 [8]. A UE supporting this feature shall support <i>pdcp-DuplicationMCG-orSCG-DRB</i> or <i>pdcp-DuplicationSplitDRB</i> . A UE supporting this feature shall also support <i>configuredUL-GrantType1-v1650</i> or <i>configuredUL-GrantType2-v1650</i> .	UE	No	No	No
tdd-MPE-P-MPR-Reporting-r16 Indicates whether the UE supports P-MPR reporting for Maximum Permissible Exposure, as specified in TS38.321 [8].	UE	No	TDD only	FR2 only
ul-LBT-FailureDetectionRecovery-r16 Indicates whether the UE supports consistent uplink LBT detection and recovery, as specified in TS 38.321 [8], for cells operating with shared spectrum channel access. This field applies to all serving cells with which the UE is configured with shared spectrum channel access.	UE	No	No	No
uplink-Harq-ModeB-r17 Indicates whether the UE supports HARQ Mode B and the corresponding LCP restrictions for uplink transmission. A UE supporting this feature shall also indicate the support of <i>nonTerrestrialNetwork-r17</i> .	UE	No	No	No

Release 17

4.2.7 Physical layer parameters

4.2.7.1 *BandCombinationList* parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
featureSetCombinationDAPS-r16 Indicates the feature set that the UE supports for DAPS handover on the NR band combination by FeatureSetCombinationId. A UE shall include this field if intra-frequency or inter-frequency DAPS handover is supported for this band combination. For a band entry where it indicates the support for intra-frequency DAPS handover, the UE shall include at least two CCs and shall support intra-frequency DAPS handover between any CC pair within the same band entry. If the number of CCs within a band combination is more than one and if inter-frequency DAPS handover is supported, UE shall support inter-frequency DAPS handover between every CC pair in the same or different band entries in the band combination, except for the CC pair within a band entry with bandwidth class A. A feature set including <i>intraFreqDAPS-r16</i> can only be referred to by <i>featureSetCombinationDAPS-r16</i> , not by <i>featureSetCombination</i> . A feature set without <i>intraFreqDAPS-r16</i> is only applied to inter-freq DAPS handover if it is referred to by <i>featureSetCombinationDAPS</i> . Both feature sets with and without <i>intraFreqDAPS-r16</i> can be referred to by the same <i>featureSetCombinationDAPS</i> -	BC	N/A	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
scalingFactorTxSidelink-r16, scalingFactorRxSidelink-r16 Indicates, for a particular Uu band combination, the scaling factor for the PC5 band combination(s) on which the UE supports transmission/reception of PC5 simultaneous with Uu uplink/downlink respectively (as indicated by supportedTxBandCombListPerBC-Sidelink-r16 / supportedRxBandCombListPerBC-Sidelink-r16). The leading / leftmost value corresponds to the first band combination included in BandCombinationListSidelinkEUTRA-NR which is indicated with value 1 by supportedTxBandCombListPerBC-Sidelink-r16 / supportedRxBandCombListPerBC-Sidelink-r16, the next value corresponds to the second band combination included in BandCombinationListSidelinkEUTRA-NR which is indicated with value 1 by supportedTxBandCombListPerBC-Sidelink-r16 / supportedRxBandCombListPerBC-Sidelink-r16 and so on. For each value of ScalingFactorSidelink-r16, value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on.	BC	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
srs-SwitchingAffectedBandsListNR-r17 Indicates which other bands in the band combination are affected by the SRS switch and the dropping rules / timelines apply to the indicated bands when SRS carrier switching on target CC and other UL on source CC are overlapped in the same symbol. UE indicating support of this feature shall indicate support of <i>srs-CarrierSwitch</i> . NOTE: For each "source-target" pair (as indicated by <i>srs-SwitchingTimesListNR</i>), the UE can indicate which other bands in the band combination are affected by the SRS switch.	BC	No	N/A	N/A
SRS-SwitchingTimeNR Indicates the interruption time on DL/UL reception within a NR band pair during the RF retuning for switching between a carrier on one band and another (PUSCH-less) carrier on the other band to transmit SRS. <i>switchingTimeDL/switchingTimeUL</i> : n0us represents 0 us, n30us represents 30us, and so on. <i>switchingTimeDL/switchingTimeUL</i> is mandatory present if switching between the NR band pair is supported, otherwise the field is absent. It is signalled per pair of bands per band combination.	FD	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
SRS-SwitchingTimeEUTRA Indicates the interruption time on DL/UL reception within a EUTRA band pair during the RF retuning for switching between a carrier on one band and another (PUSCH-less) carrier on the other band to transmit SRS. <i>switchingTimeDL/switchingTimeUL</i> : n0 represents 0 OFDM symbols, n0dot5 represents 0.5 OFDM symbols, n1 represents 1 OFDM symbol and so on. <i>switchingTimeDL/switchingTimeUL</i> is mandatory present if switching between the EUTRA band pair is supported, otherwise the field is absent. It is signalled per pair of bands per band combination.	FD	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF								
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A								
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A								
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A								
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A								
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A								
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A								
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A								
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A								
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A								
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A								
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A								
srs-TxSwitch, srs-TxSwitch-v1610 Defines whether UE supports SRS for DL CSI acquisition as defined in clause 6.2.1.2 of TS 38.214 [12]. The capability signalling comprises of the following parameters: <ul style="list-style-type: none"> - <i>supportedSRS-TxPortSwitch</i> indicates SRS Tx port switching pattern supported by the UE, which is mandatory with capability signalling. The indicated UE antenna switching capability of 'xTyR' corresponds to a UE, capable of SRS transmission on 'x' antenna ports over total of 'y' antennas, where 'y' corresponds to all or subset of UE receive antennas, where 2T4R is two pairs of antennas. <i>supportedSRS-TxPortSwitch-v1610</i>, which is optional to report, indicates downgrading configuration of SRS Tx port switching pattern. If the UE indicates the support of downgrading configuration of SRS Tx port switching pattern using <i>supportedSRS-TxPortSwitch-v1610</i>, the UE shall report the values for this as below, based on what is reported in <i>supportedSRS-TxPortSwitch</i>. <table border="0" style="margin-left: 40px;"> <tr> <td style="text-align: center;"><i>supportedSRS-TxPortSwitch</i></td> <td style="text-align: center;"><i>supportedSRS-TxPortSwitch-v1610</i></td> </tr> <tr> <td style="text-align: center;"><i>t1r2</i></td> <td style="text-align: center;"><i>t1r1-t1r2</i></td> </tr> <tr> <td style="text-align: center;"><i>t1r4</i></td> <td style="text-align: center;"><i>t1r1-t1r2-t1r4</i></td> </tr> <tr> <td style="text-align: center;"><i>t2r4</i></td> <td style="text-align: center;"><i>t1r1-t1r2-t2r2-t2r4</i></td> </tr> </table> 	<i>supportedSRS-TxPortSwitch</i>	<i>supportedSRS-TxPortSwitch-v1610</i>	<i>t1r2</i>	<i>t1r1-t1r2</i>	<i>t1r4</i>	<i>t1r1-t1r2-t1r4</i>	<i>t2r4</i>	<i>t1r1-t1r2-t2r2-t2r4</i>	BC	FD	N/A	N/A
<i>supportedSRS-TxPortSwitch</i>	<i>supportedSRS-TxPortSwitch-v1610</i>											
<i>t1r2</i>	<i>t1r1-t1r2</i>											
<i>t1r4</i>	<i>t1r1-t1r2-t1r4</i>											
<i>t2r4</i>	<i>t1r1-t1r2-t2r2-t2r4</i>											

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
srs-AntennaSwitchingBeyond4Rx-r17 Indicates whether the UE supports SRS Antenna switching for more than 4 Rx. The capability signalling comprises the following parameters: <ul style="list-style-type: none"> - <i>supportedSRS-TxPortSwitchBeyond4Rx-r17</i> indicates a combination of supported xTyRs. It includes 11-bit bitmap, where starting from the leading / leftmost bit (bit 0), each bit corresponds to {t1r1, t2r2, t1r2, t4r4, t2r4, t1r4, t2r6, t1r6, t4r8, t2r8, t1r8}. For any indicated value, x shall be equal to or smaller than the one associated with the largest y. - <i>entryNumberAffectBeyond4Rx-r17</i> indicates the entry number of the first-listed band with UL in the band combination that affects this DL. - <i>entryNumberSwitchBeyond4Rx-r17</i> indicates the entry number of the first-listed band with UL in the band combination that switches together with this UL. The UE indicating support of this shall indicate support of <i>srs-TxSwitch</i> . <p>NOTE: If reported for the same values of xTyR in <i>supportedSRS-TxPortSwitchBeyond4Rx-r17</i> as reported with <i>supportedSRS-TxPortSwitch/supportedSRS-TxPortSwitch-v1610</i>, the reported values for <i>entryNumberAffectBeyond4Rx-r17</i> and <i>entryNumberSwitchBeyond4Rx-r17</i> are not valid.</p>	BC	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
supportedBandwidthCombinationSet Defines the supported bandwidth combination set for a band combination as defined in TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4]. For NR SA CA, NR-DC, inter-band (NG)EN-DC without intra-band (NG)EN-DC component, inter-band NE-DC without intra-band NE-DC component and intra-band (NG)EN-DC/NE-DC with additional inter-band NR CA component, the field defines the bandwidth combinations for the NR part of the band combination. For intra-band (NG)EN-DC/NE-DC without additional inter-band NR and LTE CA component, the field indicates the supported bandwidth combination set applicable to intra-band (NG)EN-DC/NE-DC band combination. This field is not applicable to source and target cells in intra-frequency DAPS handover. Field encoded as a bit map, where bit N is set to "1" if UE supports Bandwidth Combination Set N for this band combination as defined in the TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4]. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. It is mandatory if <ul style="list-style-type: none"> - the band combination has more than one NR carrier (at least one SCell in an NR cell group); - or is an intra-band (NG)EN-DC/NE-DC combination without additional inter-band NR and LTE CA component; - or both. 	BC	CY	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
supportedBandwidthCombinationSetIntraENDC Defines the supported bandwidth combination set for a band combination that allows configuration of at least one EUTRA serving cell and at least one NR serving cell in the same band, as defined in the TS 38.101-3 [4], table 5.3B.1.2-1 and table 5.3B.1.3-1. <ul style="list-style-type: none"> - For intra-band (NG)EN-DC with additional inter-band CA component(s) of LTE and/or NR, the field defines the bandwidth combinations for the intra-band (NG)EN-DC component. - For intra-band NE-DC with additional inter-band CA component(s) of LTE and/or NR, the field defines the bandwidth combinations for the intra-band NE-DC component. Field encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination as defined in the TS 38.101-3 [4]. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. <ul style="list-style-type: none"> - It is mandatory if the band combination is an intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component. - It is optional if the band combination is an intra-band (NG)EN-DC/NE-DC combination without supporting UL in both the bands of the intra-band (NG)EN-DC/NE-DC UL part. If not included, the network assumes the UE 	BC	CY	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
supportedTxBandCombListPerBC-Sidelink-r16, supportedRxBandCombListPerBC-Sidelink-r16 Indicates, for a particular Uu band combination, the PC5 band combination(s) on which the UE supports transmission/reception of PC5 simultaneously with Uu uplink/downlink respectively. The leading / leftmost bit (bit 0) corresponds to the first band combination included in <i>BandCombinationListSidelinkEUTRA-NR</i> , the next bit corresponds to the second band combination included in <i>BandCombinationListSidelinkEUTRA-NR</i> and so on. with value 1 indicating simultaneous transmission/reception is supported.	BC	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
supportedBandCombListPerBC-SL-RelayDiscovery-r17, supportedBandCombListPerBC-SL-NonRelayDiscovery-r17 Indicates, for a particular Uu band combination, the PC5 Relay discovery and non-Relay discovery band combination(s) on which the UE supports simultaneous transmission/reception of PC5 data (Relay discovery or non-Relay discovery) and Uu uplink/downlink respectively. The leading / leftmost bit (bit 0) corresponds to the first band combination included in <i>supportedBandCombinationListSL-RelayDiscovery-r17/supportedBandCombinationListSL-NonRelayDiscovery-r17</i> , the next bit corresponds to the second band combination included in <i>supportedBandCombinationListSL-RelayDiscovery-r17/supportedBandCombinationListSL-NonRelayDiscovery-r17</i> and so on. with value 1 indicating simultaneous transmission/reception is supported.	BC	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
ULTxSwitchingBandPair-r16, ULTxSwitchingBandPair-v1700 Indicates UE supports dynamic UL 1Tx-2Tx switching in case of inter-band CA, SUL, and (NG)EN-DC, and UL 2Tx-2Tx switching in case of inter-band CA and SUL as defined in TS 38.214 [12], TS 38.101-1 [2] and TS 38.101-3 [4]. The capability signalling comprises of the following parameters: <ul style="list-style-type: none"> - <i>bandIndexUL1-r16</i> and <i>bandIndexUL2-r16</i> indicate the band pair on which UE supports dynamic UL Tx switching. <i>bandindexUL1/bandindexUL2</i> xx refers to the xxth band entry in the band combination. UE shall indicate support for 2-layer UL MIMO capabilities on one of the indicated two bands in each FeatureSet entry supporting UL 1Tx-2Tx switching and indicate support for 2-layer UL MIMO capabilities on both bands in each FeatureSet entry supporting UL 2T-2Tx switching, and only the band where UE supports 2-layer UL MIMO capability can work as carrier2 as defined in TS 38.101-1 [2] and TS 38.101-3 [4]. - <i>uplinkTxSwitchingPeriod-r16</i> indicates the length of UL Tx switching period of 1Tx-2Tx switching per pair of UL bands per band combination when dynamic UL Tx switching is configured, as specified in TS 38.101-1 [2] and TS 38.101-3 [4]. UE shall not report the value n210us for EN-DC band combinations. n35us represents 35 us, n140us represents 140us, and so on, as specified in TS 38.101-1 [2] and TS 38.101-3 [4]. - <i>uplinkTxSwitchingPeriod2T2T-r17</i> indicates the length of UL Tx switching 	BC	FD	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
uplinkTxSwitching-OptionSupport-r16 Indicates which option is supported for dynamic UL 1Tx-2Tx switching for inter-band UL CA and (NG)EN-DC. <i>switchedUL</i> represents option 1 as specified in TS 38.214 [12], <i>dualUL</i> represents option 2 as specified in TS 38.214 [12], <i>both</i> represents both option 1 and option2 as specified in TS 38.214 [12]. UE shall not report the value <i>both</i> for (NG)EN-DC case. The field is mandatory for inter-band UL CA and (NG)EN-DC case where UE supports dynamic UL 1Tx-2Tx switching.	BC	CY	N/A	FR1 only
uplinkTxSwitching-OptionSupport2T2T-r17 Indicates which option is supported for dynamic UL 2Tx-2Tx switching for inter-band UL CA. <i>switchedUL</i> represents option 1 as specified in TS 38.214 [12], <i>dualUL</i> represents option 2 as specified in TS 38.214 [12], <i>both</i> represents both option 1 and option2 as specified in TS 38.214 [12]. The field is mandatory for inter-band UL CA cases where UE supports dynamic UL 2Tx-2Tx switching. The UE indicating support of this feature shall indicate support of at least one common switching option between <i>uplinkTxSwitching-OptionSupport2T2T-r17</i> and <i>uplinkTxSwitching-OptionSupport-r16</i> .	BC	CY	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
uplinkTxSwitching-PowerBoosting-r16 Indicates the support of 3dB boosting on the maximum output power for UE transmission under the operation state in which 2-port transmission can be supported on carrier2 in case of inter-band UL CA case where UE supports dynamic UL Tx switching. A UE shall only indicate this capability in case the UE supports power class 3 for inter-band UL CA for the band combination as defined in TS 38.101-1 [2].	BC	No	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
UplinkTxSwitchingBandParameters-v1700 Contains the UL Tx switching specific band parameters for a given band combination. The capability signalling comprises of the following parameters: - <i>bandIndex-r17</i> indicates a band on which UE supports dynamic UL Tx switching with another band in the band combination. <i>bandIndex</i> xx refers to the xxth band entry in the band combination. - <i>uplinkTxSwitching2T2T-PUSCH-TransCoherence-r17</i> indicates support of the uplink codebook subset for the carrier(s) on a band capable of two antenna connectors on which UE supports dynamic UL 2Tx-2Tx switching with another band in the band combination. UE indicating support of full coherent codebook subset shall also support non-coherent codebook subset. If this field is absent, the per BC UE capability reported in <i>uplinkTxSwitching-PUSCH-TransCoherence-r16</i> is applied, and if this field and <i>uplinkTxSwitching-PUSCH-TransCoherence-r16</i> are both absent, the UE capability reported in <i>pusch-TransCoherence</i> is applied when uplink Tx switching is triggered between last transmitted SRS and scheduled PUSCH transmission, as specified in TS 38.101-1 [2].	BC	No	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	BC	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	BC	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	BC	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. If the band combination includes both FR1 and FR2 bands, a UE indicating support for NR-DC shall support synchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	BC	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/A	N/A
uplinkTxSwitching-PUSCH-TransCoherence-r16 Indicates support of the uplink codebook subset when uplink 1Tx-2Tx switching is triggered between last transmitted SRS and scheduled PUSCH transmission, as specified in TS 38.101-1 [2]. UE indicating support of full coherent codebook subset shall also support non-coherent codebook subset. If the field is absent, the supported uplink codebook subset indicated by <i>pusch-TransCoherence</i> applies when the uplink switching is triggered between last transmitted SRS and scheduled transmission.	BC	No	N/A	FR1 only

Release 17

4.2.7.2 *BandNR parameters*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>activeConfiguredGrant-r16 Indicates whether the UE supports up to 12 configured/active configured grant configurations in a BWP of a serving cell. This field includes the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberConfigsPerBWP-r16</i> indicates the maximum number of configured/active configured grant configurations in a BWP of a serving cell. - <i>maxNumberConfigsAllCC-r16</i> indicates the maximum number of configured/active configured grant configurations across all serving cells in a MAC entity, and across MCG and SCG in case of NR-DC. <p>The UE can include this feature only if the UE indicates support of either <i>configuredUL-GrantType1</i> or <i>configuredUL-GrantType1-v1650</i> and/or <i>configuredUL-GrantType2</i> or <i>configuredUL-GrantType2-v1650</i>.</p> <p>NOTE:</p> <ul style="list-style-type: none"> - For all the reported bands in FR1, a same X1 value is reported for <i>maxNumberConfigsAllCC-r16</i>. For all the reported bands in FR2, a same X2 value is reported for <i>maxNumberConfigsAllCC-r16</i>. - The total number of configured/active configured grant configurations across all serving cells in FR1 is no greater than X1. - The total number of configured/active configured grant configurations across all serving cells in FR2 is no greater than X2. - If the CA have some serving cell(s) in FR1 and some serving cell(s) in FR2, the total number of configured/active configured grant configurations across all serving cells is no greater than max(X1, X2). 	Band	No	N/A	N/A
<p>additionalActiveTCI-StatePDCCH Indicates whether the UE supports one additional active TCI-State for control in addition to the supported number of active TCI-States for PDSCH. The UE can include this field only if <i>maxNumberActiveTCI-PerBWP</i> in <i>tci-StatePDSCH</i> is set to <i>n1</i>. Otherwise, the UE does not include this field.</p>	Band	No	N/A	N/A
<p>aperiodicBeamReport Indicates whether the UE supports aperiodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH. The UE provides the capability for the band number for which the report is provided (where the measurement is performed).</p>	Band	Yes	N/A	N/A
<p>aperiodicCSI-RS-AdditionalBandwidth-r17 Indicates the UE supported TRS bandwidths for fast SCell activation, in addition to 52 RBs, for a 10MHz UE channel bandwidth. This field only applies for the BWPs configured with 52 RBs size and 15kHz SCS, in FDD bands and indicates the values:</p> <p>Value <i>addBW-Set1</i> indicates 28, 32, 36, 40, 44, 48 RBs. Value <i>addBW-Set2</i> indicates 32, 36, 40, 44, 48 RBs.</p> <p>The UE can include this feature only if the UE indicates support of <i>aperiodicCSI-RS-FastScellActivation-r17</i>.</p>	Band	No	FDD only	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>aperiodicCSI-RS-FastScellActivation-r17 Indicates whether the UE supports aperiodic CSI-RS for tracking for fast SCell activation, i.e.,</p> <ol style="list-style-type: none"> 1) Aperiodic CSI-RS for tracking for fast SCell activation is triggered by enhanced SCell activation/deactivation MAC CE; 2) Aperiodic CSI-RS for tracking for fast SCell activation is triggered within the BWP indicated by <i>firstActiveDownlinkBWP-Id</i> for the SCell. <p>This field includes the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberAperiodicCSI-RS-PerCC-r17</i> indicates the maximum number of aperiodic CSI-RS resource set configurations for tracking for fast SCell activation that can be configured to UE per CC in a reported band. Value n8 corresponds to 8, n16 corresponds to 16, and so on. - <i>maxNumberAperiodicCSI-RS-AcrossCCs-r17</i> indicates the maximum number of aperiodic CSI-RS resource set configurations for tracking for fast SCell activation that can be configured to UE across CCs in a reported band. Value n8 corresponds to 8, n16 corresponds to 16, and so on. <p>NOTE:</p> <ul style="list-style-type: none"> - <i>maxNumberAperiodicCSI-RS-PerCC-r17</i> and <i>maxNumberAperiodicCSI-RS-AcrossCCs-r17</i> values refer to the number of RS configurations for fast SCell activation that can be indicated by the MAC CE. - The NZP-CSI-RS configured as RS for tracking for fast SCell activation are not considered when counting the maximum NZP-CSI-RS configurations of CSI-RS and CSI-IM reception for CSI feedback. 	Band	No	N/A	N/A
<p>aperiodicTRS Indicates whether the UE supports DCI triggering aperiodic TRS associated with periodic TRS.</p>	Band	No	N/A	Yes
<p>asymmetricBandwidthCombinationSet Defines the supported asymmetric channel bandwidth combination for the band as defined in the TS 38.101-1 [2]. Field encoded as a bit map, where bit N is set to "1" if UE support asymmetric channel bandwidth combination set N for this band as defined in the TS 38.101-1 [2]. The leading / leftmost bit (bit 0) corresponds to the asymmetric channel bandwidth combination set 1, the next bit corresponds to the asymmetric channel bandwidth combination set 2 and so on. UE shall support asymmetric channel bandwidth combination set 0. If the field is absent, the UE supports asymmetric channel bandwidth combination set 0.</p>	Band	No	N/A	N/A
<p>bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2], TS 38.101-2 [3], and TS 38.101-5 [34].</p>	Band	Yes	N/A	N/A
<p>beamCorrespondenceCSI-RS-based-r16 Indicates whether the UE support for beam correspondence based on CSI-RS has the ability to select its uplink beam based on measurement of CSI-RS. If a UE supports beam correspondence based on CSI-RS, then the network can expect the UE to also fulfil Rel-15 beam correspondence requirements.</p> <p>If UE supports neither <i>beamCorrespondenceSSB-based-r16</i> nor <i>beamCorrespondenceCSI-RS-based-r16</i>, gNB can expect the UE to fulfill beam correspondence based on Rel-15 beam correspondence requirements.</p>	Band	No	TDD only	FR2 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>beamCorrespondenceSSB-based-r16</i> Indicates whether the UE support for beam correspondence based on SSB has the ability to select its uplink beam based on measurement of SSB. If a UE supports beam correspondence based on SSB, then the network can expect the UE to also fulfil Rel-15 beam correspondence requirements.</p> <p>If UE supports neither <i>beamCorrespondenceSSB-based-r16</i> nor <i>beamCorrespondenceCSI-RS-based-r16</i>, gNB can expect the UE to fulfil beam correspondence based on Rel-15 beam correspondence requirements.</p>	Band	No	TDD only	FR2 only
<p><i>beamCorrespondenceWithoutUL-BeamSweeping</i> Indicates how UE supports FR2 beam correspondence as specified in TS 38.101-2 [3], clause 6.6. The UE that fulfils the beam correspondence requirement without the uplink beam sweeping (as specified in TS 38.101-2 [3], clause 6.6) shall set the field to <i>supported</i>. The UE that fulfils the beam correspondence requirement with the uplink beam sweeping (as specified in TS 38.101-2 [3], clause 6.6) shall not report this field.</p>	Band	Yes	N/A	FR2 only
<p><i>beamManagementSSB-CSI-RS</i> Defines support of SS/PBCH and CSI-RS based RSRP measurements. The capability comprises signalling of</p> <ul style="list-style-type: none"> - <i>maxNumberSSB-CSI-RS-ResourceOneTx</i> indicates maximum total number of configured one port NZP CSI-RS resources and SS/PBCH blocks that are supported by the UE to measure L1-RSRP as specified in TS 38.215 [13] within a slot and across all serving cells (see NOTE). On FR2, it is mandatory to report ≥ 8; On FR1, it is mandatory with capability signalling to report ≥ 8. - <i>maxNumberCSI-RS-Resource</i> indicates maximum total number of configured NZP-CSI-RS resources that are supported by the UE to measure L1-RSRP as specified in TS 38.215 [13] across all serving cells (see NOTE). It is mandated to report at least n8 for FR1. - <i>maxNumberCSI-RS-ResourceTwoTx</i> indicates maximum total number of two ports NZP CSI-RS resources that are supported by the UE to measure L1-RSRP as specified in TS 38.215 [13] within a slot and across all serving cells (see NOTE). - <i>supportedCSI-RS-Density</i> indicates density of one RE per PRB for one port NZP CSI-RS resource for RSRP reporting, if supported. On FR2, it is mandatory to report either "three" or "oneAndThree"; On FR1, it is mandatory with capability signalling to report either "three" or "oneAndThree". - <i>maxNumberAperiodicCSI-RS-Resource</i> indicates maximum number of configured aperiodic CSI-RS resources across all serving cells (see NOTE). For FR1 and FR2, the UE is mandated to report at least n4. <p>NOTE: If the UE sets a value other than <i>n0</i> in an FR1 band, it shall set that same value in all FR1 bands. If the UE sets a value other than <i>n0</i> in an FR2 band, it shall set that same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells.</p>	Band	Yes	N/A	FD

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>beamReportTiming, beamReportTiming-v1710 Indicates the number of OFDM symbols between the end of the last symbol of SSB/CSI-RS and the start of the first symbol of the transmission channel containing beam report. The UE provides the capability for the band number for which the report is provided (where the measurement is performed). The UE includes this field for each supported sub-carrier spacing.</p>	Band	Yes	N/A	N/A
<p>beamSwitchTiming, beamSwitchTiming-v1710 Indicates the minimum number of OFDM symbols between the DCI triggering of aperiodic CSI-RS and aperiodic CSI-RS transmission. The number of OFDM symbols is measured from the end of the last symbol containing the indication to the start of the first symbol of CSI-RS. The UE includes this field for each supported sub-carrier spacing.</p> <p>NOTE: <i>beamSwitchTiming</i> of value (<i>sym224</i> or <i>sym336</i> for 60kHz and 120kHz SCS, <i>sym896</i> or <i>sym1344</i> for 480kHz SCS and <i>sym1792</i> or <i>sym2688</i> for 960kHz SCS) will be used to determine UE expectation/behaviour for aperiodic CSI-RS for tracking and latency requirements for L1-RSRP reporting as described in clause 5.1.6.1.1 of TS 38.214 [12], while UE behaviour/assumption regarding before or after beam switch timing is unspecified for measuring AP CSI-RS for CSI acquisition (without <i>trs-Info</i> and without repetition) and for beam management (with repetition 'off').</p>	Band	No	N/A	FR2 only
<p>beamSwitchTiming-r16, beamSwitchTiming-r17 Indicates the minimum number of required OFDM symbols (<i>sym224</i>, <i>sym336</i> for 60kHz and 120kHz SCS, <i>sym896</i> or <i>sym1344</i> for 480kHz SCS and <i>sym1792</i> or <i>sym2688</i> for 960kHz SCS) between the DCI triggering aperiodic CSI-RS and the corresponding aperiodic CSI-RS transmission in a CSI-RS resource set configured with repetition 'ON' if <i>enableBeamSwitchTiming-r16</i> is configured.</p> <p>For CSI-RS configured with repetition "off", the UE applies beam switch time of <i>sym48</i> if <i>beamSwitchTiming-r16</i> is reported and <i>enableBeamSwitchTiming-r16</i> is configured. For CSI-RS configured without repetition and without <i>trs-info</i>, the UE applies beam switch time of <i>sym48</i> if <i>beamSwitchTiming-r16</i> is reported and <i>enableBeamSwitchTiming-r16</i> is configured.</p>	Band	No	N/A	FR2 only
<p>bfd-Relaxation-r17 Indicates whether the UE supports BFD relaxation criteria and requirement as specified in TS 38.133 [5]. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>UE indicating support of this feature shall also indicate support of <i>maxNumberCSI-RS-BFD</i>, <i>maxNumberSSB-BFD</i> and <i>maxNumberCSI-RS-SSB-CBD</i>.</p>	Band	No	N/A	N/A
<p>bwp-DiffNumerology Indicates whether the UE supports BWP adaptation up to 4 BWPs with the different numerologies, via DCI and timer. Except for SUL, the UE only supports the same numerology for the active UL and DL BWP. For the UE which is a non-RedCap UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP includes the bandwidth of the CORESET#0 (if CORESET#0 is present) and SSB for PCell and PSCell (if configured). For the UE which is a RedCap UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP may not include the bandwidth of the CORESET#0 (if configured) and SSB for PCell. For SCell(s), the bandwidth of the UE-specific RRC configured DL BWP includes SSB, if there is SSB on SCell(s).</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>bwp-SameNumerology</i> Indicates whether UE supports BWP adaptation (up to 2/4 BWPs) with the same numerology, via DCI and timer. Except for SUL, the UE only supports the same numerology for the active UL and DL BWP. For the UE which is a non-RedCap UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP includes the bandwidth of the CORESET#0 (if CORESET#0 is present) and SSB for PCell and PSCell (if configured). For the UE which is a RedCap UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP may not include the bandwidth of the CORESET#0 (if configured) and SSB for PCell. For SCell(s), the bandwidth of the UE-specific RRC configured DL BWP includes SSB, if there is SSB on SCell(s).</p>	Band	No	N/A	N/A
<p><i>bwp-WithoutRestriction</i> Indicates support of BWP operation without bandwidth restriction. The Bandwidth restriction in terms of DL BWP for PCell and PSCell means that the bandwidth of a UE-specific RRC configured DL BWP may not include the bandwidth of CORESET #0 (if configured) and SSB. For SCell(s), it means that the bandwidth of DL BWP may not include SSB.</p>	Band	No	N/A	N/A
<p><i>cancelOverlappingPUSCH-r16</i> Indicates whether UE supports the cancellation of the (repetition of the) PUSCHs transmission on all other intra-band serving cell(s). The cancellation of the (repetition of the) PUSCH transmission on a the set of intra-band serving cell(s) includes all symbols from the earliest symbol that is overlapping with the first cancelled symbol of the PUSCH on the serving cell for which the DCI format 2_4 is applicable to. If the UE supports this feature, the UE needs to report <i>pa-PhaseDiscontinuityImpacts</i> and <i>ul-CancellationSelfCarrier-r16</i>.</p>	Band	No	N/A	N/A
<p><i>cg-SDT-r17</i> Indicates whether the UE supports transmission of data and/or signalling over allowed radio bearers in RRC_INACTIVE state via configured grant type 1 (i.e. CG-SDT), as specified in TS 38.331 [9]. Except for NTN bands, UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>UE supports multiple CG-SDT configurations when a UE indicates the support of this feature and <i>activeConfiguredGrant-r16</i>; otherwise UE only supports one CG-SDT configuration.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>channelBWs-DL</i> Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the <i>channelBWs-DL</i> (without suffix) for a band or absence of specific <i>scs-XXkHz</i> entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For IAB-MT, to determine whether the IAB-MT supports a channel bandwidth of 100 MHz, the network checks <i>channelBW-DL-IAB-r16</i>. For FR1, the bits in <i>channelBWs-DL</i> (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in <i>channelBWs-DL</i> (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For IAB-MT the third / rightmost bit (for 200MHz) is ignored. To determine whether the IAB-MT supports a channel bandwidth of 200 MHz, the network checks <i>channelBW-DL-IAB-r16</i>. For FR1, the leading/leftmost bit in <i>channelBWs-DL-v1590</i> indicates 70MHz, the second leftmost bit indicates 45MHz, the third leftmost bit indicates 35MHz, the fourth leftmost bit indicates 100MHz and all the remaining bits in <i>channelBWs-DL-v1590</i> shall be set to 0. The fourth leftmost bit (for 100MHz) is not applicable for bands n41, n48, n77, n78, n79 and n90 as defined in TS 38.101-1 [2]. For each band, RedCap UEs shall indicate supporting the maximum of those channel bandwidths that are less than or equal to 20 MHz for FR1 and less than or equal to 100 Mhz for FR2, taking restrictions in TS 38.101-1 [2] and TS 38.101-2 [3] into consideration. For each band, NTN capable UEs shall indicate the supported channel bandwidths for FR1, taking restrictions in TS 38.101-5 [34] into consideration.</p> <p>This feature is applicable only for FR1 and FR2-1 band, otherwise it is absent.</p> <p>NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the <i>supportedSubCarrierSpacingDL</i> and the <i>scs-60kHz</i>. To determine whether the UE supports a channel bandwidth of 90 MHz, the network may ignore this capability and validate instead the <i>channelBW-90mhz</i>, the <i>supportedBandwidthCombinationSet</i> and the <i>supportedBandwidthCombinationSetIntraENDC</i>. To determine whether the UE supports a channel bandwidth of 400 MHz, the network may ignore this capability and validate the <i>supportedBandwidthCombinationSet</i>, the <i>supportedBandwidthCombinationSetIntraENDC</i>, and the <i>supportedBandwidthDL</i>. For serving cell(s) with other channel bandwidths the network validates the <i>channelBWs-DL</i>, the <i>supportedBandwidthCombinationSet</i>, the <i>supportedBandwidthCombinationSetIntraENDC</i>, the <i>asymmetricBandwidthCombinationSet</i> (for a band supporting asymmetric channel bandwidth as defined in clause 5.3.6 of TS 38.101-1 [2]), <i>supportedBandwidthDL</i> and <i>supportedMinBandwidthDL</i>.</p>	Band	Yes	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>channelBWs-DL-SCS-120kHz-FR2-2-r17 Indicates the UE supported channel bandwidths in DL for the SCS 120kHz. The bits in <i>channelBWs-DL-SCS-120kHz-FR2-2</i> starting from the leading / leftmost bit indicate 100 and 400MHz. 100 and 400 MHz are mandatory channel bandwidths if the UE supports 120 kHz SCS (i.e. the bit for 100 and 400MHz shall always be set to 1). UE supporting this feature shall also indicate support of <i>dl-FR2-2-SCS-120kHz-r17</i>.</p> <p>NOTE: To determine whether the UE supports a SCS 120kHz for a given band, the network validates the <i>supportedSubCarrierSpacingDL</i>. To determine the supported carrier bandwidths, the network validates the <i>channelBWs-DL-SCS-120kHz-FR2-2-r17</i>, the <i>supportedBandwidthCombinationSet</i> and the <i>supportedBandwidthDL-v1710</i>.</p>	Band	CY	N/A	N/A
<p>channelBWs-DL-SCS-480kHz-FR2-2-r17 Indicates the UE supported channel bandwidths in DL for the SCS 480kHz. The bits in <i>channelBWs-DL-SCS-480kHz-FR2-2</i> starting from the leading / leftmost bit indicate 400, 800 and 1600MHz. 400 MHz is a mandatory channel bandwidth if the UE supports 480 kHz SCS (i.e. the bit for 400MHz shall always be set to 1). UE supporting this feature shall also indicate support of <i>dl-FR2-2-SCS-480kHz-r17</i>.</p> <p>NOTE: To determine whether the UE supports a SCS 480kHz for a given band, the network validates the <i>supportedSubCarrierSpacingDL</i>. To determine the supported carrier bandwidths, the network validates the <i>channelBWs-DL-SCS-480kHz-FR2-2-r17</i>, the <i>supportedBandwidthCombinationSet</i> and <i>supportedBandwidthDL-v1710</i>.</p>	Band	CY	N/A	N/A
<p>channelBWs-DL-SCS-960kHz-FR2-2-r17 Indicates the UE supported channel bandwidths in DL for the SCS 960kHz. The bits in <i>channelBWs-DL-SCS-960kHz-FR2-2</i> starting from the leading / leftmost bit indicate 400, 800,1600 and 2000MHz. 400 MHz is a mandatory channel bandwidth if the UE supports 960 kHz SCS (i.e. the bit for 400MHz shall always be set to 1). UE supporting this feature shall also indicate support of <i>dl-FR2-2-SCS-960kHz-r17</i>.</p> <p>NOTE: To determine whether the UE supports a SCS 960kHz for a given band, the network validates the <i>supportedSubCarrierSpacingDL</i>. To determine the supported carrier bandwidths, the network validates the <i>channelBWs-DL-SCS-960kHz-FR2-2-r17</i>, the <i>supportedBandwidthCombinationSet</i> and <i>supportedBandwidthDL-v1710</i>.</p>	Band	CY	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the <i>channelBWs-UL</i> (without suffix) for a band or absence of specific <i>scs-XXkHz</i> entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For IAB-MT, to determine whether the IAB-MT supports a channel bandwidth of 100 MHz, the network checks <i>channelBW-UL-IAB-r16</i>. For FR1, the bits in <i>channelBWs-UL</i> (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in <i>channelBWs-UL</i> (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For IAB-MT the third / rightmost bit (for 200MHz) is ignored. To determine whether the IAB-MT supports a channel bandwidth of 200 MHz, the network checks <i>channelBW-UL-IAB-r16</i>. For FR1, the leading/leftmost bit in <i>channelBWs-UL-v1590</i> indicates 70 MHz, the second leftmost bit indicates 45MHz, the third leftmost bit indicates 35MHz, the fourth leftmost bit indicates 100MHz and all the remaining bits in <i>channelBWs-UL-v1590</i> shall be set to 0. The fourth leftmost bit (for 100MHz) is not applicable for bands n41, n48, n77, n78, n79 and n90 as defined in TS 38.101-1 [2]. For each band, RedCap UEs shall indicate supporting the maximum of those channel bandwidths that are less than or equal to 20 MHz for FR1 and less than or equal to 100 Mhz for FR2, taking restrictions in TS 38.101-1 [2] and TS 38.101-2 [3] into consideration. For each band, NTN capable UEs shall indicate the supported channel bandwidths for FR1, taking restrictions in TS 38.101-5 [34] into consideration.</p> <p>This feature is applicable only for FR1 and FR2-1 band, otherwise it is absent.</p> <p>NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the <i>supportedSubCarrierSpacingUL</i> and the <i>scs-60kHz</i>. To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability and validate instead the <i>channelBW-90mhz</i>, the <i>supportedBandwidthCombinationSet</i> and the <i>supportedBandwidthCombinationSetIntraENDC</i>. To determine whether the UE supports a channel bandwidth of 400 MHz, the network may ignore this capability and validate the <i>supportedBandwidthCombinationSet</i>, the <i>supportedBandwidthCombinationSetIntraENDC</i>, and the <i>supportedBandwidthUL</i>. For serving cell(s) with other channel bandwidths the network validates the <i>channelBWs-UL</i>, the <i>supportedBandwidthCombinationSet</i>, the <i>supportedBandwidthCombinationSetIntraENDC</i>, the <i>asymmetricBandwidthCombinationSet</i> (for a band supporting asymmetric channel bandwidth as defined in clause 5.3.6 of TS 38.101-1 [2]), <i>supportedBandwidthUL</i> and <i>supportedMinBandwidthUL</i>.</p>	Band	Yes	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>channelBWs-UL-SCS-120kHz-FR2-2-r17 Indicates the UE supported channel bandwidths in UL for the SCS 120kHz. The bits in <i>channelBWs-UL-SCS-120kHz-FR2-2</i> starting from the leading / leftmost bit indicate 100 and 400MHz. 100 and 400 MHz are mandatory channel bandwidths if the UE supports 120 kHz SCS (i.e. the bit for 100 and 400MHz shall always be set to 1). UE supporting this feature shall also indicate support of <i>ul-FR2-2-SCS-120kHz-r17</i>.</p> <p>NOTE: To determine whether the UE supports a SCS 120kHz for a given band, the network validates the <i>supportedSubCarrierSpacingUL</i>. To determine the supported carrier bandwidths, the network validates the <i>channelBWs-UL-SCS-120kHz-FR2-2-r17</i>, the <i>supportedBandwidthCombinationSet</i> and the <i>supportedBandwidthUL-v1710</i>.</p>	Band	CY	N/A	N/A
<p>channelBWs-UL-SCS-480kHz-FR2-2-r17 Indicates the UE supported channel bandwidths in UL for the SCS 480kHz. The bits in <i>channelBWs-UL-SCS-480kHz-FR2-2</i> starting from the leading / leftmost bit indicate 400, 800 and 1600MHz. 400 MHz is a mandatory channel bandwidth if the UE supports 480 kHz SCS (i.e. the bit for 400MHz shall always be set to 1). UE supporting this feature shall also indicate support of <i>ul-FR2-2-SCS-480kHz-r17</i>.</p> <p>NOTE: To determine whether the UE supports a SCS 480kHz for a given band, the network validates the <i>supportedSubCarrierSpacingUL</i>. To determine the supported carrier bandwidths, the network validates the <i>channelBWs-UL-SCS-480kHz-FR2-2-r17</i>, the <i>supportedBandwidthCombinationSet</i> and <i>supportedBandwidthUL-v1710</i>.</p>	Band	CY	N/A	N/A
<p>channelBWs-UL-SCS-960kHz-FR2-2-r17 Indicates the UE supported channel bandwidths in UL for the SCS 960kHz. The bits in <i>channelBWs-UL-SCS-960kHz-FR2-2</i> starting from the leading / leftmost bit indicate 400, 800, 1600 and 2000MHz.</p> <p>400 MHz is a mandatory channel bandwidth if the UE supports 960 kHz SCS (i.e. the bit for 400MHz shall always be set to 1). UE supporting this feature shall also indicate support of <i>ul-FR2-2-SCS-960kHz-r17</i>.</p> <p>NOTE: To determine whether the UE supports a SCS 960kHz for a given band, the network validates the <i>supportedSubCarrierSpacingUL</i>. To determine the supported carrier bandwidths, the network validates the <i>channelBWs-UL-SCS-960kHz-FR2-2-r17</i>, the <i>supportedBandwidthCombinationSet</i> and <i>supportedBandwidthUL-v1710</i>.</p>	Band	CY	N/A	N/A
<p>channelBW-DL-IAB-r16 Indicates whether the IAB-MT supports channel bandwidth of 100 MHz for a given SCS in FR1 for DL or whether the IAB-MT supports channel bandwidth of 200 MHz for a given SCS in FR2 for DL.</p>	Band	No	N/A	N/A
<p>channelBW-UL-IAB-r16 Indicates whether the IAB-MT supports channel bandwidth of 100 MHz for a given SCS in FR1 for UL or whether the IAB-MT supports channel bandwidth of 200 MHz for a given SCS in FR2 for UL.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>codebookComboParametersAddition-r16</i> Indicates the UE supports the mixed codebook combinations and the corresponding parameters supported by the UE.</p> <p>For mixed codebook types, UE reports support active CSI-RS resources and ports for up to 4 mixed codebook combinations in any slot. The following is the possible mixed codebook combinations:</p> <ul style="list-style-type: none"> - {Type 1 Single Panel, Type 2, Null} - {Type 1 Single Panel, Type 2 with port selection, Null} - {Type 1 Single Panel, eType 2 with R=1, Null} - {Type 1 Single Panel, eType 2 with R=2, Null} - {Type 1 Single Panel, eType 2 with R=1 and port selection, Null} - {Type 1 Single Panel, eType 2 with R=2 and port selection, Null} - {Type 1 Single Panel, Type 2, Type 2 with port selection} - {Type 1 Multi Panel, Type 2, Null} - {Type 1 Multi Panel, Type 2 with port selection, Null} - {Type 1 Multi Panel, eType 2 with R=1, Null} - {Type 1 Multi Panel, eType 2 with R=2, Null} - {Type 1 Multi Panel, eType 2 with R=1 with port selection, Null} - {Type 1 Multi Panel, eType 2 with R=2 with port selection, Null} - {Type 1 Multi Panel, Type 2, Type 2 with port selection} <p>Parameters for each mixed codebook supported by the UE:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceListAdd-r16</i> indicates the list of supported CSI-RS resources in a band by referring to <i>codebookVariantsList</i>. The following parameters are included in <i>codebookVariantsList</i>: <p>For <i>supportedCSI-RS-ResourceListAdd-r16</i> related to the additional codebooks:</p> <ul style="list-style-type: none"> - The minimum of <i>maxNumberTxPortsPerResource</i> is 'p4'; - The minimum value of <i>totalNumberTxPortsPerBand</i> is 4. <p>If a UE reports one or more mixed codebook combinations, then usage of active CSI-RS resources and ports for multiple codebooks in any slot is allowed only within those combinations. For coexisting of mixed codebooks in any slot, gNB needs to consider the mixed codebook combination capability as well as per codebook capability of each codebook type in the mixed codebook combination. UE indicates support of a codebook type in the mixed codebook combination shall indicate support of the individual codebook type in the per band capability.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>codebookParameters Indicates the codebooks and the corresponding parameters supported by the UE.</p> <p>Parameters for type I single panel codebook (type1 singlePanel) supported by the UE, which are mandatory to report:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceList</i>; - a UE shall support a <i>maxNumberTxPortsPerResource</i> minimum value of 4 for codebook type I single panel in FR1 in the case of a single active CSI-resource across all bands in a band combination, regardless of what it reports in <i>supportedCSI-RS-ResourceList</i> with <i>maxNumberTxPortsPerResource</i>; - a UE shall support a <i>maxNumberTxPortsPerResource</i> minimum value of 8 when configured with wideband CSI report for codebook type I single panel in FR1 in the case of a single active CSI-resource across all bands in a band combination, regardless of what it reports in <i>supportedCSI-RS-ResourceList</i> with <i>maxNumberTxPortsPerResource</i>; - a UE shall support a <i>maxNumberTxPortsPerResource</i> minimum value of 2 for codebook type I single panel in FR2 in the case of a single active CSI-resource across all bands in a band combination, regardless of what it reports in <i>supportedCSI-RS-ResourceList</i> with <i>maxNumberTxPortsPerResource</i>. - <i>modes</i> indicates supported codebook modes (mode 1, both mode 1 and mode 2); - <i>maxNumberCSI-RS-PerResourceSet</i> indicates the maximum number of CSI-RS resource in a resource set. <p>Parameters for type I multi-panel codebook (type1 multiPanel) supported by the UE, which are optional:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceList</i>; - <i>modes</i> indicates supported codebook modes (mode 1, mode 2, or both mode 1 and mode 2); - <i>maxNumberCSI-RS-PerResourceSet</i> indicates the maximum number of CSI-RS resource in a resource set; - <i>nrofPanels</i> indicates supported number of panels. <p>Parameters for type II codebook (type2) supported by the UE, which are optional:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceList</i>; - <i>parameterLx</i> indicates the parameter "Lx" in codebook generation where x is an index of Tx ports indicated by <i>maxNumberTxPortsPerResource</i>; - <i>amplitudeScalingType</i> indicates the amplitude scaling type supported by the UE (wideband or both wideband and sub-band); - <i>amplitudeSubsetRestriction</i> indicates whether amplitude subset restriction is supported for the UE. <p>Parameters for type II codebook with port selection (type2-PortSelection) supported by the UE, which are optional:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceList</i>; - <i>parameterLx</i> indicates the parameter "Lx" in codebook generation where x is an index of Tx ports indicated by <i>maxNumberTxPortsPerResource</i>; - <i>amplitudeScalingType</i> indicates the amplitude scaling type supported by the UE (wideband or both wideband and sub-band). <p><i>supportedCSI-RS-ResourceList</i> includes list of the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports 	Band	FD	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>codebookParametersAddition-r16</i> Indicates the UE support of additional codebooks and the corresponding parameters supported by the UE.</p> <p>Codebook etype 2 R=1 support parameter combination 1 to 6 and rank 1 to 2. Parameters for etype 2 R=1 (<i>etype2R1-r16</i>) supported by the UE, which are optional:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceListAdd-r16</i> indicates the list of supported CSI-RS resources in a band by referring to <i>codebookVariantsList</i>. The following parameters are included in <i>codebookVariantsList</i>: <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource of a band; - <i>maxNumberResourcesPerBand</i> indicates the maximum number of resources across all CCs in a band, simultaneously; - <i>totalNumberTxPortsPerBand</i> indicates the total number of Tx ports across all CCs in a band, simultaneously. - <i>paramComb7-8-r16</i> indicates the support of parameter combinations 7-8 for etype 2 R=1 - <i>rank3-4-r16</i> indicates the support of rank 3,4. - <i>amplitudeSubsetRestriction-r16</i> indicates the support of amplitude subset restriction. <p>Parameters for etype 2 R=2 (<i>etype2R2-r16</i>) supported by the UE, which are optional:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceListAdd-r16</i>; <p>UE supporting <i>etype2R2-r16</i> supports also indicates support of <i>etype2R1-r16</i>.</p> <p>Codebook etype 2 R=1 with port selection supports 6 parameter combinations and rank 1,2. Parameters for etype 2 R=1 with port selection (<i>etype2R1-PortSelection-r16</i>) supported by the UE, which are optional:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceListAdd-r16</i>; - <i>rank3-4-r16</i> indicates the support of rank 3,4 <p>Parameters for etype 2 R=2 with port selection (<i>etype2R2-PortSelection-r16</i>) supported by the UE, which are optional:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-ResourceListAdd-r16</i>; <p>UE supporting <i>etype2R2-PortSelection-r16</i> also indicates support of <i>etype2R1-PortSelection-r16</i>.</p> <p>For <i>supportedCSI-RS-ResourceListAdd-r16</i> related to the additional codebooks:</p> <ul style="list-style-type: none"> - The minimum of <i>maxNumberTxPortsPerResource</i> is 'p4'; - The minimum value of <i>totalNumberTxPortsPerBand</i> is 4. 	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>codebookParametersfetype2-r17</i> Indicates the UE support of additional codebooks and the corresponding parameters supported by the UE of Further Enhanced Port-Selection Type II Codebook (FeType-II) as specified in TS 38.214 [12] clause 5.2.2.7.</p> <p>The UE indicating this feature shall include <i>fetype2basic-r17</i> to indicate basic features of FeType-II. This capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - indicates the list of supported CSI-RS resources in a band by referring to <i>codebookVariantsList</i>. The following parameters are included in <i>codebookVariantsList</i>: <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource of a band - <i>maxNumberResourcesPerBand</i> indicates the maximum number of resources across all CCs in a band, simultaneously - <i>totalNumberTxPortsPerBand</i> indicates the total number of Tx ports across all CCs in a band, simultaneously <p>The UE indicating <i>fetype2basic-r17</i> shall support parameter combinations with M=1 and support rank 1 and 2. UE indicating this feature shall also include <i>csi-ReportFramework</i>.</p> <p>The UE optionally includes <i>fetype2R1-r17</i> to indicate whether the UE supports M=2 and R=1 for FeType-II. This capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - indicates the list of supported CSI-RS resources in a band by referring to <i>codebookVariantsList</i>. <p>The UE indicating support of <i>fetype2R1-r17</i> shall also indicate support of <i>fetype2basic-r17</i> and parameter combinations with M=2.</p> <p>The UE optionally includes <i>fetype2R2-r17</i> to indicate whether the UE supports R=2 for FeType-II. This capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - indicates the list of supported CSI-RS resources in a band by referring to <i>codebookVariantsList</i>. <p>UE indicating support of <i>fetype2R2-r17</i> shall also indicate support of <i>fetype2R1-r17</i>.</p> <p>The UE optionally includes <i>fetype2Rank3Rank4-r17</i> to indicate whether the UE supports rank = 3 and rank = 4 for FeType-II. UE indicating support of <i>fetype2Rank3Rank4-r17</i> shall indicate support of <i>fetype2basic-r17</i>.</p> <p>For <i>codebookVariantsList</i> related to the FeType-II:</p> <ul style="list-style-type: none"> - The minimum of <i>maxNumberTxPortsPerResource</i> is 'p4'; - The minimum value of <i>totalNumberTxPortsPerBand</i> is 4. 	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>codebookComboParameterMixedType-r17</i> Indicates the support of active CSI-RS resources and ports for mixed codebook types in any slot. The UE reports support active CSI-RS resources and ports for up to 4 mixed codebook combinations in any slot. The following are the possible mixed codebook combinations {Codebook1, Codebook2, Codebook3}:</p> <ul style="list-style-type: none"> - <i>type1SP-feType2PS-null-r17</i> indicates {Type 1 Single Panel, FeType II PS M=1, NULL} - <i>type1SP-feType2PS-M2R1-null-r17</i> indicates {Type 1 Single Panel, FeType II PS M=2 R=1, NULL} - <i>type1SP-feType2PS-M2R2-null-r17</i> indicates {Type 1 Single Panel, FeType II PS M=2 R=2, NULL} - <i>type1SP-Type2-feType2-PS-M1-r17</i> indicates {Type 1 Single Panel, Type II, FeType II PS M=1} - <i>type1SP-Type2-feType2-PS-M2R1-r17</i> indicates {Type 1 Single Panel, Type II, FeType II PS M=2 R=1} - <i>type1SP-eType2R1-feType2-PS-M1-r17</i> indicates {Type 1 Single Panel, eType II R=1, FeType II PS M=1} - <i>type1SP-eType2R1-feType2-PS-M2R1-r17</i> indicates {Type 1 Single Panel, eType II R=1, FeType II PS M=2 R=1} - <i>type1MP-feType2PS-null-r17</i> indicates {Type 1 Multi Panel, FeType II PS M=1, NULL} - <i>type1MP-feType2PS-M2R1-null-r17</i> indicates {Type 1 Multi Panel, FeType II PS M=2 R=1, NULL} - <i>type1MP-feType2PS-M2R2-null-r17</i> indicates {Type 1 Multi Panel, FeType II PS M=2 R=2, NULL} - <i>type1MP-Type2-feType2-PS-M1-r17</i> indicates {Type 1 Multi Panel, Type II, FeType II PS M=1} - <i>type1MP-Type2-feType2-PS-M2R1-r17</i> indicates {Type 1 Multi Panel, Type II, FeType II PS M=2 R=1} - <i>type1MP-eType2R1-feType2-PS-M1-r17</i> indicates {Type 1 Multi Panel, eType II R=1, FeType II PS M=1} - <i>type1MP-eType2R1-feType2-PS-M2R1-r17</i> indicates {Type 1 Multi Panel, eType II R=1, FeType II PS M=2 R=1} <p>For each mixed codebook supported by the UE, <i>supportedCSI-RS-ResourceListAdd-r16</i> indicates the list of supported CSI-RS resources in a band by referring to <i>codebookVariantsList</i>. The following parameters are included for the supported CSI-RS resource:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource of a band. The minimum of <i>maxNumberTxPortsPerResource</i> is 'p4'; - <i>maxNumberResourcesPerBand</i> indicates the maximum number of resources across all CCs in a band; - <i>totalNumberTxPortsPerBand</i> indicates the total number of Tx ports across all CCs in a band. The minimum value of <i>totalNumberTxPortsPerBand</i> is 4. <p>The UE supporting this feature shall indicate the support of <i>fetype2basic-r17</i>, <i>etype2R1-r16</i>, <i>CodebookComboParametersAddition-r16</i>, <i>supportedCSI-RS-ResourceList</i>, <i>fetype2R1-r17</i>, <i>fetype2R2-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>codebookComboParameterMultiTRP-r17 Indicates the support of active CSI-RS resources and ports in the presence of multi-TRP CSI.</p> <p>Indicates the support of active CSI-RS resources and ports for mixed codebook types in any slot. The UE reports supported active CSI-RS resources and ports for up to 4 mixed codebook combinations. The following are the possible mixed codebook combinations {Codebook1, Codebook2, Codebook3}:</p> <ul style="list-style-type: none"> - <i>nCJT-null-null</i> indicates {NCJT, NULL, NULL} - <i>nCJT1SP-null-null</i> indicates {NCJT+Type 1 SP for sTRP, NULL, NULL} - <i>nCJT-Type2-null-r16</i> indicates {NCJT, Type 2, Null} - <i>nCJT-Type2PS-null-r16</i> indicates {NCJT, Type 2 with port selection, Null} - <i>nCJT-eType2R1-null-r16</i> indicates {NCJT, eType 2 with R=1, Null} - <i>nCJT-eType2R2-null-r16</i> indicates {NCJT, eType 2 with R=2, Null} - <i>nCJT-eType2R1PS-null-r16</i> indicates {NCJT, eType 2 with R=1 and port selection, Null} - <i>nCJT-eType2R2PS-null-r16</i> indicates {NCJT, eType 2 with R=2 and port selection, Null} - <i>nCJT-Type2-Type2PS-r16</i> indicates {NCJT, Type 2, Type 2 with port selection} - <i>nCJT1SP-Type2-null-r16</i> indicates {NCJT+Type 1 SP for sTRP, Type 2, Null} - <i>nCJT1SP-Type2PS-null-r16</i> indicates {NCJT+Type 1 SP for sTRP, Type 2 with port selection, Null} - <i>nCJT1SP-eType2R1-null-r16</i> indicates {NCJT+Type 1 SP for sTRP, eType 2 with R=1, Null} - <i>nCJT1SP-eType2R2-null-r16</i> indicates {NCJT+Type 1 SP for sTRP, eType 2 with R=2, Null} - <i>nCJT1SP-eType2R1PS-null-r16</i> indicates {NCJT+Type 1 SP for sTRP, eType 2 with R=1 and port selection, Null} - <i>nCJT1SP-eType2R2PS-null-r16</i> indicates {NCJT+Type 1 SP for sTRP, eType 2 with R=2 and port selection, Null} - <i>nCJT1SP-Type2-Type2PS-r16</i> indicates {NCJT+Type 1 SP for sTRP, Type 2, Type 2 with port selection} - <i>nCJT-feType2PS-null-r17</i> indicates {NCJT, FeType II PS M=1, NULL} - <i>nCJT-feType2PS-M2R1-null-r17</i> indicates {NCJT, FeType II PS M=2 R=1, NULL} - <i>nCJT-feType2PS-M2R2-null-r17</i> indicates {NCJT, FeType II PS M=2 R=2, NULL} - <i>nCJT-Type2-feType2-PS-M1-r17</i> indicates {NCJT, Type II, FeType II PS M=1} - <i>nCJT-Type2-feType2-PS-M2R1-r17</i> indicates {NCJT, Type II, FeType II PS M=2 R=1} - <i>nCJT-eType2R1-feType2-PS-M1-r17</i> indicates {NCJT, eType II R=1, FeType II PS M=1} - <i>nCJT-eType2R1-feType2-PS-M2R1-r17</i> indicates {NCJT, eType II R=1, FeType II PS M=2 R=1} - <i>nCJT1SP-feType2PS-null-r17</i> indicates {NCJT+Type 1 SP for sTRP, FeType II PS M=1, NULL} - <i>nCJT1SP-feType2PS-M2R1-null-r17</i> indicates {NCJT+Type 1 SP for sTRP, FeType II PS M=2 R=1, NULL} - <i>nCJT1SP-feType2PS-M2R2-null-r17</i> indicates {NCJT+Type 1 SP for sTRP, FeType II PS M=2 R=2, NULL} - <i>nCJT1SP-Type2-feType2-PS-M1-r17</i> indicates {NCJT+Type 1 SP for sTRP, 	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>condHandover-r16 Indicates whether the UE supports conditional handover including execution condition, candidate cell configuration and maximum 8 candidate cells. Except for NTN bands, UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p>	Band	No	N/A	N/A
<p>condHandoverFailure-r16 Indicates whether the UE supports conditional handover during re-establishment procedure when the selected cell is configured as candidate cell for condition handover. Except for NTN bands, UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p>	Band	No	N/A	N/A
<p>condHandoverTwoTriggerEvents-r16 Indicates whether the UE supports 2 trigger events for same execution condition. This feature is mandatory supported if the UE supports <i>condHandover-r16</i>. Except for NTN bands, UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p>	Band	CY	N/A	N/A
<p>condPSCellChange-r16 Indicates whether the UE supports conditional PSCell change including execution condition, candidate cell configuration and maximum 8 candidate cells. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p>	Band	No	N/A	N/A
<p>condPSCellChangeTwoTriggerEvents-r16 Indicates whether the UE supports 2 trigger events for same execution condition. This feature is mandatory supported if the UE supports <i>condPSCellChange-r16</i>. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p>	Band	CY	N/A	N/A
<p>configuredUL-GrantType1-v1650 Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one. This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>configuredUL-GrantType1-r16</i> applies. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>The UE only includes <i>configuredUL-GrantType1-v1650</i> if <i>configuredUL-GrantType1</i> is absent.</p>	Band	No	N/A	N/A
<p>configuredUL-GrantType2-v1650 Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one. This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>configuredUL-GrantType2-r16</i> applies. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>The UE only includes <i>configuredUL-GrantType2-v1650</i> if <i>configuredUL-GrantType2</i> is absent.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>cqi-4-BitsSubbandNTN-SharedSpectrumChAccess-r17 Indicates whether the UE supports CQI reporting with 4 bits per subband for NTN and shared spectrum channel access.</p>	Band	No	N/A	N/A
<p>crossCarrierScheduling-SameSCS Indicates whether the UE supports cross carrier scheduling for the same numerology with carrier indicator field (CIF) in carrier aggregation where numerologies for the scheduling cell and scheduled cell are same.</p>	Band	No	N/A	N/A
<p>csi-ReportFramework Indicates whether the UE supports CSI report framework. This capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberPeriodicCSI-PerBWP-ForCSI-Report</i> indicates the maximum number of periodic CSI report setting per BWP for CSI report; - <i>maxNumberPeriodicCSI-PerBWP-ForBeamReport</i> indicates the maximum number of periodic CSI report setting per BWP for beam report. - <i>maxNumberAperiodicCSI-PerBWP-ForCSI-Report</i> indicates the maximum number of aperiodic CSI report setting per BWP for CSI report; - <i>maxNumberAperiodicCSI-PerBWP-ForBeamReport</i> indicates the maximum number of aperiodic CSI report setting per BWP for beam report; - <i>maxNumberAperiodicCSI-triggeringStatePerCC</i> indicates the maximum number of aperiodic CSI triggering states in <i>CSI-AperiodicTriggerStateList</i> per CC; - <i>maxNumberSemiPersistentCSI-PerBWP-ForCSI-Report</i> indicates the maximum number of semi-persistent CSI report setting per BWP for CSI report; - <i>maxNumberSemiPersistentCSI-PerBWP-ForBeamReport</i> indicates the maximum number of semi-persistent CSI report setting per BWP for beam report; - <i>simultaneousCSI-ReportsPerCC</i> indicates the number of CSI report(s) for which the UE can measure and process reference signals simultaneously in a CC of the band for which this capability is provided. The CSI report comprises periodic, semi-persistent and aperiodic CSI and any latency classes and codebook types. The CSI report in <i>simultaneousCSI-ReportsPerCC</i> includes the beam report and CSI report. <p>The UE is mandated to report <i>csi-ReportFramework</i>.</p>	Band	Yes	N/A	N/A
<p>csi-ReportFrameworkExt-r16 Indicates whether the UE supports the extension of the maximum number of configured aperiodic CSI report settings for all codebook types. The capability signalling comprises the following: <i>maxNumberAperiodicCSI-PerBWP-ForCSI-ReportExt-r16</i> indicates the extended maximum number of aperiodic CSI report setting per BWP for CSI report. If present, the value of <i>maxNumberAperiodicCSI-PerBWP-ForCSI-Report-r16</i> shall replace the corresponding value in <i>csi-ReportFramework</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>csi-RS-ForTracking</i> Indicates support of CSI-RS for tracking (i.e. TRS). This capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxBurstLength</i> indicates the TRS burst length. Value 1 indicates 1 slot and value 2 indicates both of 1 slot and 2 slots. In this release UE is mandated to report value 2; - <i>maxSimultaneousResourceSetsPerCC</i> indicates the maximum number of TRS resource sets per CC which the UE can track simultaneously; - <i>maxConfiguredResourceSetsPerCC</i> indicates the maximum number of TRS resource sets configured to UE per CC. It is mandated to report at least 8 for FR1 and 16 for FR2; - <i>maxConfiguredResourceSetsAllCC</i> indicates the maximum number of TRS resource sets configured to UE across CCs. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. The UE is mandated to report at least 16 for FR1 and 32 for FR2. <p>The UE is mandated to report <i>csi-RS-ForTracking</i>.</p>	Band	Yes	N/A	N/A
<p><i>csi-RS-IM-ReceptionForFeedback</i> Indicates support of CSI-RS and CSI-IM reception for CSI feedback. This capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxConfigNumberNzp-Csi-Rs-PerCC</i> indicates the maximum number of configured NZP-CSI-RS resources per CC; - <i>maxConfigNumberPortsAcrossNzp-Csi-Rs-PerCC</i> indicates the maximum number of ports across all configured NZP-CSI-RS resources per CC; - <i>maxConfigNumberCsi-Im-PerCC</i> indicates the maximum number of configured CSI-IM resources per CC; - <i>maxNumberSimultaneousNzp-Csi-Rs-PerCC</i> indicates the maximum number of simultaneous CSI-RS-resources per CC; - <i>totalNumberPortsSimultaneousNzp-Csi-Rs-PerCC</i> indicates the total number of CSI-RS ports in simultaneous CSI-RS resources per CC. <p>The UE is mandated to report <i>csi-RS-IM-ReceptionForFeedback</i>.</p>	Band	Yes	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>csi-RS-ProcFrameworkForSRS Indicates support of CSI-RS processing framework for SRS. This capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberPeriodicSRS-AssocCSI-RS-PerBWP</i> indicates the maximum number of periodic SRS resources associated with CSI-RS per BWP; - <i>maxNumberAperiodicSRS-AssocCSI-RS-PerBWP</i> indicates the maximum number of aperiodic SRS resources associated with CSI-RS per BWP; - <i>maxNumberSP-SRS-AssocCSI-RS-PerBWP</i> indicates the maximum number of semi-persistent SRS resources associated with CSI-RS per BWP; - <i>simultaneousSRS-AssocCSI-RS-PerCC</i> indicates the number of SRS resources that the UE can process simultaneously in a CC, including periodic, aperiodic and semi-persistent SRS. 	Band	No	N/A	N/A
<p>defaultQCL-PerCORESETPoolIndex-r16 Indicates whether the UE supports default QCL assumption per CORESET pool index using multi-DCI based multi-TRP. The UE that indicates support of this feature shall support <i>multiDCI-MultiTRP-r16</i> and <i>simultaneousReceptionDiffTypeD-r16</i>.</p>	Band	No	N/A	FR2 only
<p>defaultQCL-TwoTCI-r16 Indicates whether the UE supports default QCL assumption with two TCI states using single-DCI based multi-TRP. The UE can include this field only if <i>simultaneousReceptionDiffTypeD-r16</i> is present. Otherwise, the UE does not include this field.</p>	Band	No	N/A	FR2 only
<p>dmrs-BundlingNonBackToBackTX-r17 Indicates whether the UE supports DM-RS bundling for non-back-to-back transmission for consecutive slots for PUSCH and PUCCH only for corresponding supported back-to-back transmission as reported in <i>dmrs-BundlingPUSCH-RepTypeA-r17</i>, <i>dmrs-BundlingPUSCH-RepTypeB-r17</i>, <i>dmrs-BundlingPUSCH-multiSlot-r17</i> or <i>dmrs-BundlingPUCCH-Rep-r17</i>. The UE is considered to support the feature in a band of a band combination if the UE indicates support of the feature for the corresponding band and for the band combination.</p> <p>UE indicating support of this feature shall also indicate support of at least one of <i>dmrs-BundlingPUSCH-RepTypeA-r17</i>, <i>dmrs-BundlingPUSCH-RepTypeB-r17</i>, <i>dmrs-BundlingPUSCH-multiSlot-r17</i> or <i>dmrs-BundlingPUCCH-Rep-r17</i>.</p>	Band	No	N/A	N/A
<p>dmrs-BundlingPUCCH-Rep-r17 Indicates whether the UE supports DM-RS bundling for PUCCH repetitions for PUCCH formats 1/3/4 over consecutive symbols. The UE is considered to support the feature in a band of a band combination if the UE indicates support of the feature for the corresponding band and for the band combination.</p> <p>UE indicating support of this feature shall also indicate support of <i>maxDurationDMRS-Bundling-r17</i> and <i>pucch-Repetition-F1-3-4</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>dmrs-BundlingPUSCH-multiSlot-r17 Indicates whether the UE supports DM-RS bundling for TB processing over multi-slot PUSCH over consecutive symbols. The UE is considered to support the feature in a band of a band combination if the UE indicates support of the feature for the corresponding band and for the band combination.</p> <p>UE indicating support of this feature shall also indicate support of <i>maxDurationDMRS-Bundling-r17</i> and <i>tb-ProcessingMultiSlotPUSCH-r17</i>.</p>	Band	No	N/A	N/A
<p>dmrs-BundlingPUSCH-RepTypeA-r17 Indicates whether the UE supports DM-RS bundling for PUSCH repetition type A over consecutive symbols. The UE is considered to support the feature in a band of a band combination if the UE indicates support of the feature for the corresponding band and for the band combination.</p> <p>UE indicating support of this feature shall also indicate support of <i>maxDurationDMRS-Bundling-r17</i> and at least one of <i>type1-PUSCH-RepetitionMultiSlots</i>, <i>type2-PUSCH-RepetitionMultiSlots</i> or <i>pusch-RepetitionMultiSlots</i>.</p>	Band	No	N/A	N/A
<p>dmrs-BundlingPUSCH-RepTypeB-r17 Indicates whether the UE supports DM-RS bundling for PUSCH repetition type B over consecutive symbols. The UE is considered to support the feature in a band of a band combination if the UE indicates support of the feature for the corresponding band and for the band combination.</p> <p>UE indicating support of this feature shall also indicate support of <i>maxDurationDMRS-Bundling-r17</i> and <i>pusch-RepetitionTypeB-r16</i>.</p>	Band	No	N/A	N/A
<p>dmrs-BundlingRestart-r17 Indicates whether the UE supports restarting DM-RS bundling after the events triggered by DCI or MAC CE that violate power consistency and phase continuity. The UE is considered to support the feature in a band of a band combination if the UE indicates support of the feature for the corresponding band and for the band combination.</p> <p>UE indicating support of this feature shall also indicate support of <i>maxDurationDMRS-Bundling-r17</i>.</p> <p>NOTE: Events which are triggered by DCI or MAC CE, but do not require UE capability to resume maintaining power consistency and/or phase continuity as specified in clause 6.1.7 of TS 38.214 [12] are excluded from this feature.</p>	Band	No	N/A	N/A
<p>dynamicMulticastDCI-Format4-2-r17 Indicates whether the UE supports DCI format 4_2 with CRC scrambled with G-RNTI for multicast. A UE supporting this feature shall also indicate support of <i>dynamicMulticastPCell-r17</i>.</p>	Band	No	N/A	N/A
<p>dynamicSlotRepetitionMulticastNTN-SharedSpectrumChAccess-r17 Indicates the maximum number of supported dynamic slot-level repetitions for group-common PDSCH for multicast for NTN and shared spectrum channel access. Value n8 corresponds to 8, and value n16 corresponds to 16. A UE supporting this feature shall also indicate support of <i>dynamicMulticastPCell-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>dynamicSlotRepetitionMulticastTN-NonSharedSpectrumChAccess-r17 Indicates the maximum number of supported dynamic slot-level repetitions for group-common PDSCH for multicast for TN and non-shared spectrum channel access. Value n8 corresponds to 8, and value n16 corresponds to 16. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2 bands respectively.</p> <p>A UE supporting this feature shall also indicate support of <i>dynamicMulticastPCell-r17</i>.</p>	Band	No	N/A	N/A
<p>enhancedSkipUplinkTxConfigured-v1660 Indicates whether the UE supports skipping UL transmission for a configured uplink grant only if no data is available for transmission and no UCI is multiplexed on the corresponding PUSCH of the uplink grant as specified in TS 38.321 [8]. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>The UE only includes <i>enhancedSkipUplinkTxConfigured-v1660</i> if <i>enhancedSkipUplinkTxConfigured-r16</i> is absent.</p>	Band	No	N/A	N/A
<p>enhancedSkipUplinkTxDynamic-v1660 Indicates whether the UE supports skipping UL transmission for an uplink grant addressed to a C-RNTI only if no data is available for transmission and no UCI is multiplexed on the corresponding PUSCH of the uplink grant as specified in TS 38.321 [8]. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>The UE only includes <i>enhancedSkipUplinkTxDynamic-v1660</i> if <i>enhancedSkipUplinkTxDynamic-r16</i> is absent.</p>	Band	No	N/A	N/A
<p>enhancedType3-HARQ-CodebookFeedback-r17 Indicates whether the UE supports enhanced type 3 HARQ-ACK codebook feedback based on triggering information in DCI 1_1 and DCI 1_2 (for a UE supporting DCI format 1_2 as indicated in <i>dci-Format1-2And0-2-r16</i>) and also supports transmission of enhanced type 3 HARQ-ACK codebook using the first or second PUCCH configuration based on PHY priority indication in the triggering DCI (for a UE supporting two HARQ-ACK codebooks / PUCCH config as indicated in <i>twoHARQ-ACK-Codebook-type1-r16</i>). The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>enhancedType3-HARQ-Codebooks-r17</i> indicates the maximum number of supported enhanced type 3 HARQ-ACK codebooks; - <i>maxNumberPUCCH-Transmissions-r17</i> indicates the maximum number of actual PUCCH transmissions for type 3 or enhanced type 3 HARQ-ACK codebook feedback within a slot. <p>UE only supports feedback of a dynamically selected enhanced type 3 HARQ-ACK codebook based on triggering information in DCI 1_1 and DCI 1_2 (for a UE supporting DCI format 1_2 as indicated in <i>dci-Format1-2And0-2-r16</i>) if the UE supports more than one enhanced type 3 HARQ-ACK codebook to be configured (as indicated in <i>enhancedType3-HARQ-Codebooks-r17</i>). The UE indicates support of this capability shall also indicate support of <i>oneShotHARQ-feedback-r16</i>.</p>	Band	No	N/A	N/A
<p>enhancedUL-TransientPeriod-r16 Indicates whether the UE supports enhanced UL performance for the transient period as specified in clause 6.3.3 of TS 38.101-1 [2] and in clause 6.3.3 of TS 38.101-5 [34]. If not reported, the UE supports transient period of 10us.</p>	Band	No	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>eventA4BasedCondHandover-r17 Indicates whether the UE supports Event A4 based conditional handover in NTN bands, i.e., <i>CondEvent A4</i> as specified in TS 38.331 [9]. A UE supporting this feature shall also indicate the support of <i>condHandover-r16</i> for NTN bands and the support of <i>nonTerrestrialNetwork-r17</i>. UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p>	Band	No	N/A	N/A
<p>extendedCP Indicates whether the UE supports 60 kHz subcarrier spacing with extended CP length for reception of PDCCH, and PDSCH, and transmission of PUCCH, PUSCH, and SRS.</p>	Band	No	N/A	N/A
<p>groupBeamReporting Indicates whether UE supports RSRP reporting for the group of two reference signals.</p>	Band	No	N/A	N/A
<p>groupSINR-reporting-r16 Indicates whether UE supports group based L1-SINR reporting. UE indicates support of this feature shall indicate support of <i>ssb-csirs-SINR-measurement-r16</i>.</p>	Band	No	N/A	N/A
<p>handoverUTRA-FDD-r16 Indicates whether the UE supports NR to UTRA-FDD CELL_DCH CS handover for the PCell on the band. It is mandatory to support both UTRA-FDD measurement and event B triggered reporting, and periodic UTRA-FDD measurement and reporting if the UE supports HO to UTRA-FDD. If this field is included, then UE shall support IMS voice over NR. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p>	Band	No	N/A	N/A
<p>interSlotFreqHopInterSlotBundlingPUSCH-r17 Indicates whether the UE supports enhanced inter-slot frequency hopping with inter-slot bundling for PUSCH.</p> <p>UE indicating support of this feature shall also indicate support of at least one of <i>dmrs-BundlingPUSCH-RepTypeA-r17</i>, <i>dmrs-BundlingPUSCH-RepTypeB-r17</i> or <i>dmrs-BundlingPUSCH-multiSlot-r17</i>.</p>	Band	No	N/A	N/A
<p>interSlotFreqHopPUCCH-r17 Indicates whether the UE supports enhanced inter-slot frequency hopping for PUCCH repetitions with DMRS bundling.</p> <p>UE indicating support of this feature shall also indicate support of <i>dmrs-BundlingPUCCH-Rep-r17</i>.</p>	Band	No	N/A	N/A
<p>maxDurationDMRS-Bundling-r17 Indicates whether the UE supports the maximum duration during which UE is able to maintain power consistency and phase continuity to support DM-RS bundling for PUSCH/PUCCH.</p> <p>NOTE: DM-RS bundling is only applicable for UL transmissions with pi/2 BPSK, BPSK, and QPSK modulation orders for the corresponding physical channels.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>maxMIMO-LayersForMulti-DCI-mTRP-r16</i> Indicates the interpretation of <i>maxNumberMIMO-LayersPDSCH</i> for multi-DCI based mTRP. If this field is included, <i>maxNumberMIMO-LayersPDSCH</i> is interpreted as the maximum number of layers per PDSCH for multi-DCI multi-TRP operation. If this field is not included, <i>maxNumberMIMO-LayersPDSCH</i> is interpreted as the maximum number of layers across two PDSCHs if having at least one RE overlapped, for multi-DCI multi-TRP operation. The UE that indicates support of this feature shall support <i>overlapPDSCHsFullyFreqTime-r16</i>.</p> <p>NOTE 1: For data rate calculation in clause 4.1.2, if this feature is indicated, each multi-DCI based multi-TRP CC is counted two times toward J.</p>	Band	No	N/A	N/A
<p><i>max-HARQ-ProcessNumber-r17</i> Indicates the maximal supported HARQ process numbers for UL and for DL respectively. For each value of <i>max-HARQ-ProcessNumber-r17</i>, value <i>u16d32</i> indicates the maximal supported HARQ process number is 16 for UL and 32 for DL, value <i>u32d16</i> indicates the maximal supported HARQ process number is 32 for UL and 16 for DL, value <i>u32d32</i> indicates the maximal supported HARQ process number is 32 for UL and 32 for DL. This field is only applicable for bands in Table 5.2.2-1 in TS 38.101-5 [34] and HAPS operation bands in clause 5.2 of TS 38.104 [35].</p>	Band	No	N/A	N/A
<p><i>maxNumberPUSCH-TypeA-Repetition-r17</i> Indicates whether the UE supports the increased maximum number of PUSCH Type A repetitions to 32.</p> <p>A UE that indicates support of this feature shall support <i>type1-PUSCH-RepetitionMultiSlots</i>, <i>type2-PUSCH-RepetitionMultiSlots</i>, <i>pusch-RepetitionTypeA-r16</i> or <i>pusch-RepetitionTypeA-v16c0</i>.</p> <p>NOTE: For DG PUSCH, the number of repetitions is indicated in a TDRA list. A row index of the TDRA list is indicated by a DCI. For Type 1 CG PUSCH, the number of repetitions is indicated by <i>repK-v1710</i>. For Type 2 CG PUSCH, the number of repetitions is indicated in a TDRA list or by <i>repK-v1710</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>mux-HARQ-ACK-DiffPriorities-r17 Indicates whether the UE supports HARQ-ACK with different priorities multiplexing on a PUCCH/PUSCH, comprised of the following functional components:</p> <ul style="list-style-type: none"> - Supports multiplexing a high-priority HARQ-ACK and a low-priority HARQ-ACK into a PUCCH. Supports separate coding for the two HARQ-ACKs; - Supports multiplexing a low-priority HARQ-ACK, a high-priority HARQ-ACK and a high-priority SR into a PUCCH; - Supports multiplexing a low-priority HARQ-ACK in a high-priority PUSCH (conveying UL-SCH only). Supports separate beta_offset values for this priority combination; - Supports multiplexing a high-priority HARQ-ACK in a low-priority PUSCH (conveying UL-SCH only). Supports separate beta_offset values for this priority combination; - Supports multiplexing a low-priority HARQ-ACK, a high-priority PUSCH, a high-priority HARQ-ACK and/or CSI; - Supports multiplexing a high-priority HARQ-ACK, a low-priority PUSCH, a low-priority HARQ-ACK and/or CSI. <p>The UE indicating support of this feature shall also indicate the support of <i>twoHARQ-ACK-Codebook-type1-r16</i>.</p>	Band	No	N/A	N/A
<p>jointReleaseConfiguredGrantType2-r16 Indicates whether the UE supports joint release in a DCI for two or more configured grant Type 2 configurations for a given BWP of a serving cell. The UE can include this feature only if the UE indicates support of <i>activeConfiguredGrant-r16</i>.</p>	Band	No	N/A	N/A
<p>jointReleaseSPS-r16 Indicates whether the UE supports joint release in a DCI for two or more SPS configurations for a given BWP of a serving cell. The UE can include this feature only if the UE indicates support of <i>sps-r16</i>.</p>	Band	No	N/A	N/A
<p>k1-RangeExtension-r17 Indicates whether the UE supports extended K1 value range of (0..31) for unpaired spectrum. This field is only applicable for bands in Table 5.2.2-1 in TS 38.101-5 [34] and HAPS operation bands in clause 5.2 of TS 38.104 [35].</p>	Band	No	N/A	N/A
<p>locationBasedCondHandover-r17 Indicates whether the UE supports location based conditional handover, i.e., <i>CondEvent D1</i> as specified in TS 38.331 [9]. A UE supporting this feature shall also indicate the support of <i>condHandover-r16</i> for NTN bands and the support of <i>nonTerrestrialNetwork-r17</i>. UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p>	Band	No	N/A	N/A
<p>lowPAPR-DMRS-PDSCH-r16 Indicates whether the UE supports low PAPR DMRS for PDSCH.</p>	Band	No	N/A	N/A
<p>lowPAPR-DMRS-PUCCH-r16 Indicates whether the UE supports low PAPR DMRS for PUCCH format 3 and format 4 with transform precoding and with pi/2 BPSK modulation. UE indicates support of this feature shall indicate support of <i>pucch-F3-4-HalfPi-BPSK</i> and any combination of support of <i>pucch-F3-WithFH</i>, <i>pucch-F4-WithFH</i> and <i>pucch-F1-3-4WithoutFH</i>. It is mandatory with capability signalling.</p>	Band	Yes	N/A	N/A
<p>lowPAPR-DMRS-PUSCHwithoutPrecoding-r16 Indicates whether the UE supports low PAPR DMRS for PUSCH without transform precoding.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>lowPAPR-DMRS-PUSCHwithPrecoding-r16 Indicates whether the UE supports low PAPR DMRS for PUSCH with transform precoding and with pi/2 BPSK modulation. It is mandatory with capability signalling. UE indicates support of this feature shall indicate support of <i>pusch-HalfPi-BPSK</i>.</p>	Band	Yes	N/A	N/A
<p>maxDynamicSlotRepetitionForSPS-Multicast-r17 Indicates maximum number of dynamic slot-level repetitions for SPS group-common PDSCH for multicast. For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE that indicates support of this feature shall indicate support of <i>sps-Multicast-r17</i>.</p>	Band	No	N/A	N/A
<p>maxModulationOrderForMulticast-r17 Defines the maximal modulation order for multicast PDSCH. If not reported, UE supports the same modulation order as unicast.</p> <ul style="list-style-type: none"> - For FR1, up to 1024QAM is supported. - For FR2, up to 256QAM is supported. <p>A UE supporting this feature shall also indicate support of <i>dynamicMulticastPCell-r17</i>.</p> <p>NOTE: A UE shall support the corresponding mandatory maximum modulation for unicast.</p>	Band	No	N/A	N/A
<p>maxNumberActivatedTCI-States-r16 Indicates maximum number of activated TCI states. This capability signalling includes the following:</p> <ul style="list-style-type: none"> - <i>maxNumberPerCORESET-Pool-r16</i> indicates maximal number of activated TCI states per <i>CORESETPoolIndex</i> per BWP per CC including data and control - <i>maxTotalNumberAcrossCORESET-Pool-r16</i> indicates maximal total number of activated TCI states across <i>CORESETPoolIndex</i> per BWP per CC including data and control <p>The UE that indicates support of this feature shall support <i>multiDCI-MultiTRP-r16</i>.</p>	Band	No	N/A	N/A
<p>maxNumberCSI-RS-BFD Indicates maximal number of CSI-RS resources across all CCs, and across MCG and SCG in case of NR-DC, for UE to monitor PDCCH quality. In this release, the maximum value that can be signalled is 16. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. It is mandatory with capability signalling for FR2 and optional for FR1.</p>	Band	CY	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>maxNumberCSI-RS-SSB-CBD</i> Defines maximal number of different CSI-RS [and/or SSB] resources across all CCs, and across MCG and SCG in case of NR-DC, for new beam identifications. In this release, the maximum value that can be signalled is 128. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. It is mandatory with capability signalling for FR2 and optional for FR1. The UE is mandated to report at least 32 for FR2.</p>	Band	CY	N/A	N/A
<p><i>maxNumberG-CS-RNTI-r17</i> Defines maximum number of G-CS-RNTIs for SPS multicast. For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE supporting this feature shall also indicate support of <i>sps-Multicast-r17</i>.</p>	Band	No	N/A	N/A
<p><i>maxNumberG-RNTI-r17</i> Defines maximum number of G-RNTIs for multicast. For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE supporting this feature shall also indicate support of <i>dynamicMulticastPCell-r17</i>.</p>	Band	No	N/A	N/A
<p><i>maxNumberNonGroupBeamReporting</i> Defines support of non-group based RSRP reporting using N_max RSRP values reported.</p>	Band	Yes	N/A	N/A
<p><i>maxNumberRxBeam, maxNumberRxBeam-v1720</i> Defines whether UE supports receive beamforming switching using NZP CSI-RS resource. UE shall indicate a single value for the preferred number of NZP CSI-RS resource repetitions per CSI-RS resource set. Support of Rx beam switching is mandatory for FR2.</p>	Band	CY	N/A	N/A
<p><i>maxNumberRxTxBeamSwitchDL, maxNumberRxTxBeamSwitchDL-v1710</i> Defines the number of Tx and Rx beam changes UE can perform on this band within a slot. UE shall report one value per each subcarrier spacing supported by the UE. In this release, the number of Tx and Rx beam changes for scs-15kHz and scs-30kHz are not included.</p>	Band	No	N/A	FR2 only
<p><i>maxNumberSCellBFR-r16</i> Defines the maximum number of SCells configured for SCell beam failure recovery simultaneously. The UE indicating support of this also indicates the capabilities of <i>maxNumberCSI-RS-BFD</i>, <i>maxNumberSSB-BFD</i> and <i>maxNumberCSI-RS-SSB-CBD</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>maxNumberSSB-BFD</i> Defines maximal number of different SSBs across all CCs, and across MCG and SCG in case of NR-DC, for UE to monitor PDCCH quality. In this release, the maximum value that can be signalled is 16. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. It is mandatory with capability signalling for FR2 and optional for FR1.</p>	Band	CY	N/A	N/A
<p><i>maxNumber-LEO-SatellitesPerCarrier-r17</i> Indicates the number of target LEO satellites the UE can monitor per carrier. For serving carrier, the number of target LEO satellites also includes the serving satellite. If this field is not included, the number of target satellites UE can monitor per carrier is 2. The value shall be larger than or equal to the reported value on <i>maxNumber-NGSO-SatellitesWithinOneSMTC-r17</i>.</p>	Band	No	FDD only	FR1 only
<p><i>maxNumber-NGSO-SatellitesWithinOneSMTC-r17</i> Indicates the number of different NGSO satellites for target cells that the UE supports of simultaneous measurements within a SMTC with value n1 corresponds to 1, value n2 corresponds to 2 and so on.</p>	Band	No	FDD only	FR1 only
<p><i>maxUplinkDutyCycle-PC2-FR1</i> Indicates the maximum percentage of symbols during a certain evaluation period that can be scheduled for uplink transmission to ensure compliance with applicable electromagnetic energy absorption requirements provided by regulatory bodies. This field is applicable for FR1 power class 2 UE and also applicable for FR1 power class 1.5 UE as specified in clause 6.2.1 of TS 38.101-1 [2]. If the field and <i>maxUplinkDutyCycle-PC1dot5-MPE-FR1-r16</i> are both absent, 50% shall be applied as the upper limit of the UL duty cycle for power class 2. Value n60 corresponds to 60%, value n70 corresponds to 70% and so on. This capability is not applicable to IAB-MT.</p>	Band	No	N/A	FR1 only
<p><i>maxUplinkDutyCycle-FR2</i> Indicates the maximum percentage of symbols during 1s that can be scheduled for uplink transmission at the UE maximum transmission power, so as to ensure compliance with applicable electromagnetic power density exposure requirements provided by regulatory bodies. This field is applicable for all power classes UE in FR2 as specified in TS 38.101-2 [3]. Value n15 corresponds to 15%, value n20 corresponds to 20% and so on. If the field is absent or the percentage of uplink symbols transmitted within any 1s evaluation period is larger than <i>maxUplinkDutyCycle-FR2</i>, the UE behaviour is specified in TS 38.101-2 [3]. This capability is not applicable to IAB-MT.</p>	Band	No	N/A	FR2 only
<p><i>maxUplinkDutyCycle-PC1dot5-MPE-FR1-r16</i> Indicates the maximum percentage of symbols during a certain evaluation period that can be scheduled for uplink transmission to ensure compliance with applicable electromagnetic energy absorption requirements provided by regulatory bodies. This field is only applicable for FR1 power class 1.5 UE as specified in clause 6.2.1 of TS 38.101-1 [2]. If the field and <i>maxUplinkDutyCycle-PC2-FR1</i> are both absent, 25% shall be applied as the upper limit of the UL duty cycle for power class 1.5.</p>	Band	No	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>mn-InitiatedCondPSCellChangeNRDC-r17 Indicates whether the UE supports MN initiated conditional PSCell change in NR-DC, which is configured by NR <i>conditionalReconfiguration</i> using MN configured measurement as triggering condition. The UE supporting this feature shall also support 2 trigger events for same execution condition in MN initiated conditional PSCell change in NR-DC. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands respectively.</p>	Band	No	N/A	N/A
<p>modifiedMPR-Behaviour Indicates whether UE supports modified MPR behaviour defined in TS 38.101-1 [2], TS 38.101-2 [3], and TS 38.101-5 [34].</p>	Band	No	N/A	N/A
<p>mpr-PowerBoost-FR2-r16 Indicates whether UE supports uplink transmission power boost by suspension of in-band emission (IBE) requirements as specified in TS 38.101-2 [3].</p>	Band	No	TDD only	FR2 only
<p>mpe-Mitigation-r17 Indicates the support of enhanced PHR reporting which includes pairs of (P-MPR, SSBRI/CRI). This feature also includes following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumP-MPR-RI-pairs-r17</i> indicates the maximum number of reported P-MPR and SSBRI/CRI pairs; - <i>maxNumConfRS-r17</i> indicates the maximum number of candidate RS(s) configured in a RRC pool for MPE mitigation. <p>NOTE: <i>maxNumConfRS-r17</i> is also counted in <i>maxTotalResourcesForOneFreqRange-r16</i>/ <i>maxTotalResourcesForAcrossFreqRanges-r16</i>.</p>	Band	No	N/A	FR2 only
<p>mTRP-PUCCH-InterSlot-r17 Indicates whether the UE supports the following features:</p> <ul style="list-style-type: none"> - support of PUCCH repetition scheme 1 (inter-slot repetition) with sequential mapping for repetitions larger than 2 and with cyclic mapping for 2 repetitions. - support of up to two PUCCH power control parameter sets/spatial relation information per PUCCH resource. The power control parameter sets only apply to FR1 and spatial relation information only applies to FR2. - supported PUCCH formats for PUCCH repetition scheme 1. 	Band	No	N/A	N/A
<p>mTRP-PUCCH-CyclicMapping-r17 Indicates whether the UE supports cyclic mapping for beam mapping/power control parameter set mapping for PUCCH repetitions scheme 1 and/or 3 when the number of repetitions is larger than 2. The UE that indicates support of this feature shall also indicate support of <i>mTRP-PUCCH-InterSlot-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUCCH-SecondTPC-r17 Indicates whether the UE supports second TPC field for per TRP closed-loop power control for PUCCH with DCI formats 1_1 / 1_2. The UE that indicates support of this feature shall also indicate support of <i>mTRP-PUCCH-InterSlot-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUSCH-twoCSI-RS-r17 Indicates whether the UE supports up to two NZP CSI-RS resources associated with the two SRS resource sets for non-codebook-based mTRP PUSCH. The UE that indicates support of this feature shall also indicate support of <i>srs-AssocCSI-RS</i>, <i>csi-RS-IM-ReceptionForFeedbackPerBandComb</i> and <i>mTRP-PUSCH-RepetitionTypeA-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>mTRP-BFR-twoBFD-RS-Set-r17</i> Indicates whether the UE supports mTRP BFR based on two BFD-RS sets. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxBFD-RS-resourcesPerSetPerBWP-r17</i> indicates the maximum number of supported measured BFD-RS resources per set per BWP. - <i>maxBFR-r17</i> indicates the maximum number of CCs per band configured with BFR (including spCell/SCell/MTRP BFR). - <i>maxBFD-RS-resourcesAcrossSetsPerBWP-r17</i> indicates the supported maximum number of measured BFD-RS resources across two BFD-RS sets per BWP. <p><i>maxBFD-RS-resourcesAcrossSetsPerBWP-r17</i> is also counted in <i>maxTotalResourcesForOneFreqRange-r16</i> and <i>maxTotalResourcesForAcrossFreqRanges-r16</i>.</p>	Band	No	N/A	N/A
<p><i>mTRP-BFR-PUCCH-SR-perCG-r17</i> Indicates the maximum number of supported PUCCH-SR resources for MTRP BFR per cell group. A UE that supports <i>mTRP-BFR-twoBFD-RS-Set-r17</i> shall indicate support of this feature with at least 1 PUCCH-SR resources for MTRP BFR per cell group.</p> <p>UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p>	Band	No	N/A	N/A
<p><i>mTRP-BFR-association-PUCCH-SR-r17</i> Indicates whether the UE supports association between a BFD-RS resource set on SpCell and a PUCCH SR resource. The UE indicating support of this feature shall support <i>mTRP-BFR-PUCCH-SR-perCG-r17</i>. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p>	Band	No	N/A	N/A
<p><i>mTRP-BFD-RS-MAC-CE-r17</i> Indicates the support of MAC-CE based update of explicit BFD-RS for mTRP BFR with maximum number of configured candidate BFD-RS per BWP for MAC-CE based update. The UE indicating support of this feature shall also indicate the support of <i>mTRP-BFR-twoBFD-RS-Set-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-CSI-EnhancementPerBand-r17 Indicates support of CSI enhancements for multi-TRP including support of NZP CSI-RS resource pairs used as CMR (channel measurement resource) pairs for NCJT measurement hypothesis with N=1. This feature also includes following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumNZP-CSI-RS-r17</i> indicates the maximum number of NZP CSI-RS resources in one CSI-RS resource set: Ks,max - <i>cSI-Report-mode-r17</i> indicates the CSI report mode selection. Mode1 indicates mode 1 with X=0, mode2 indicates mode 2, both indicate the support of both mode 1 with X=0 and mode 2. - A list of supported combinations, up to 16, across all CCs simultaneously, where each combination includes: <ul style="list-style-type: none"> - <i>maxNumTx-Ports-r17</i> indicates the maximum number of Tx ports in one NZP CSI-RS resource associated with an NCJT measurement hypothesis - <i>maxTotalNumCMR-r17</i> indicates the maximum total number of CMRs for NCJT measurement - <i>maxTotalNumTx-PortsNZP-CSI-RS-r17</i> indicates the maximum total number of Tx ports of NZP CSI-RS resources associated with NCJT measurement hypotheses - <i>codebookModeNCJT-r17</i> indicates the supported codebook modes for NCJT CSI. 	Band	No	N/A	N/A
<p>mTRP-CSI-numCPU-r17 Indicates the number of CSI processing units (CPUs) occupied by a pair of CMRs for NCJT CSI hypotheses. Maximum number of CPUs is reported in <i>cSI-ReportFramework</i>. The UE indicating support of this feature shall also indicate the support of <i>mTRP-CSI-EnhancementPerBand-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-CSI-additionalCSI-r17 Indicates the maximum value of <i>numberOfSingleTRP-CSI-Mode1</i>.</p> <p>The UE indicating support of this feature shall also indicate 'mode1' or 'both' in <i>cSI-Report-mode-r17</i> of <i>mTRP-CSI-EnhancementPerBand-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-CSI-N-Max2-r17 Indicates the support of maximum number of CMR pairs Nmax=2 configured in <i>NZP-CSI-RS-ResourceSet</i> for a given CSI report setting.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-CSI-EnhancementPerBand-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-CSI-CMR-r17 Indicates the support of a NZP CSI-RS resource referred by both a CMR pair configured for Rel-17 Multi-TRP CSI enhancement and a single CMR configured for Single-TRP measurement in a CSI reporting setting.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-CSI-EnhancementPerBand-r17</i>.</p>	Band	No	N/A	FR2 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>mTRP-PDCCH-individual-r17</i> Indicates the support of monitoring of individual candidates when one of the linked PDCCH candidates uses the same set of CCEs as an individual (unlinked) PDCCH candidate, and they both are associated with the same DCI size, scrambling, and CORESET.</p> <p>The UE indicating support of this feature shall also indicate support of <i>mTRP-PDCCH-Repetition-r17</i>.</p>	Band	No	N/A	N/A
<p><i>mTRP-PDCCH-anySpan-3Symbols-r17</i> Indicates support of PDCCH repetition for PDCCH monitoring on any span of up to 3 consecutive OFDM symbols of a slot. It is applicable to 15kHz SCS only. The UE indicating support of this feature shall also indicate support of <i>pdccchMonitoringSingleOccasion</i> and <i>mTRP-PDCCH-Repetition-r17</i>.</p>	Band	No	N/A	FR1 only
<p><i>mTRP-PDCCH-TwoQCL-TypeD-r17</i> Indicates the support of determining two QCL-TypeD for time-domain overlapping CORESETs in the same CC or for intra-band CA when UE is configured with PDCCH repetition. The UE indicating support of this feature shall also indicate support of <i>mTRP-PDCCH-Repetition-r17</i>.</p>	Band	No	N/A	FR2 only
<p><i>mTRP-PUSCH-CSI-RS-r17</i> Indicates the support of CSI-RS processing framework for SRS with two associated CSI-RS resources.</p> <p>This feature also includes following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumPeriodicSRS-r17</i> indicates the maximum number of periodic SRS resources associated with first and second CSI-RS per BWP. - <i>maxNumAperiodicSRS-r17</i> indicates the maximum number of aperiodic SRS resources associated with first and second CSI-RS per BWP. - <i>maxNumSP-SRS-r17</i> indicates the maximum number of semi-persistent SRS resources associated with first and second CSI-RS per BWP. - <i>numSRS-ResourcePerCC-r17</i>: UE can process Y SRS resources associated with first and second CSI-RS resources simultaneously in a CC. Includes Periodic/Semi-Persistent/Aperiodic SRS. - <i>numSRS-ResourceNonCodebook-r17</i>: UE can process up to X CSI-RS resources associated with SRS for non-codebook based transmission simultaneously. <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-PUSCH-twoCSI-RS-r17</i>.</p>	Band	No	N/A	N/A
<p><i>mTRP-PUSCH-cyclicMapping-r17</i> Indicates the support of cyclic mapping when the number of repetitions is larger than 2 with repetition type.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-PUSCH-TypeA-CB-r17</i> or <i>mTRP-PUSCH-RepetitionTypeA-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUSCH-secondTPC-r17 Indicates the support of second TPC field for per TRP closed-loop power control for PUSCH with DCI formats 0_1 and 0_2.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-PUSCH-TypeA-CB-r17</i> or <i>mTRP-PUSCH-RepetitionTypeA-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUSCH-twoPHR-Reporting-r17 Indicates the support of PHR reporting related to M-TRP PUSCH repetition (calculate two PHRs (at least corresponding to the CC that applies m-TRP PUSCH repetitions), each associated with a first PUSCH occasion corresponding to each SRS resource set, and report two PHRs). The UE indicating support of this feature shall also indicate the support of <i>mTRP-PUSCH-TypeA-CB-r17</i> or <i>mTRP-PUSCH-RepetitionTypeA-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUSCH-A-CSI-r17 Indicates the support of A-CSI report on two PUSCH repetitions.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-PUSCH-TypeA-CB-r17</i> or <i>mTRP-PUSCH-RepetitionTypeA-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUSCH-SP-CSI-r17 Indicates the support of SP-CSI report on two PUSCH repetitions.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-PUSCH-TypeA-CB-r17</i> or <i>mTRP-PUSCH-RepetitionTypeA-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUSCH-CG-r17 Indicates the support of CG PUSCH transmission towards M-TRPs using a single CG configuration. The UE uses same beam mapping principals as dynamic grant PUSCH repetition scheme.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-PUSCH-TypeA-CB-r17</i> or <i>mTRP-PUSCH-RepetitionTypeA-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUCCH-MAC-CE-r17 Indicates the support of updating two Spatial Relation Info's and two sets of power control parameters for a group of PUCCH resources in a CC by MAC-CE.</p> <p>The UE indicates support of this feature shall also indicate support of <i>mTRP-PUCCH-InterSlot-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-PUCCH-maxNum-PC-FR1-r17 Indicates the maximum number of power control parameter sets configured for multi-TRP PUCCH repetition in FR1.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>mTRP-PUCCH-InterSlot-r17</i>.</p>	Band	No	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>mTRP-inter-Cell-r17 Indicates the support of RRC configuration of additional PCI different from serving cell associated with the TCI state and/or QCL-info. This feature also includes following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumAdditionalPCI-Case1-r17</i> indicates the maximum number of configured additional PCIs per CC is X1 (Case 1) when each configuration of SSB time domain positions and periodicity of the additional PCIs is the same as SSB time domain positions and periodicity of the serving cell PCI. - <i>maxNumAdditionalPCI-Case2-r17</i> indicates the maximum number of configured additional PCIs per CC is X2 (Case 2) when the configurations of SSB time domain positions and periodicity of the additional PCIs is not according to Case 1. <p>The UE indicating support of this feature shall also indicate the support of <i>multiDCI-MultiTRP-r16</i>.</p>	Band	No	N/A	N/A
<p>mTRP-GroupBasedL1-RSRP-r17 Indicates the support of group based L1-RSRP reporting enhancements. This feature also includes following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumBeamGroups-r17</i> indicates the maximum number N of beam groups (M=2 beams per beam group) in a single L1-RSRP reporting instance based on measurement on two CMR resource sets. - <i>maxNumRS-WithinSlot-r17</i> indicates the maximum number of SSB and CSI-RS resources for measurement in both CMR sets within a slot across all CCs. - <i>maxNumRS-AcrossSlot-r17</i> indicates the maximum number of configured SSB and CSI-RS resources for measurement in both CMR sets across all CCs. <p><i>maxNumRS-WithinSlot-r17</i> and <i>maxNumRS-AcrossSlot-r17</i> are also counted in <i>maxTotalResourcesForOneFreqRange-r16</i> and <i>maxTotalResourcesForAcrossFreqRanges-r16</i>.</p>	Band	No	N/A	N/A
<p>multiPDSCH-SingleDCI-FR2-1-SCS-120kHz-r17 Indicates whether the UE supports multi-PDSCH scheduling by single DCI for the operation with 120kHz SCS in FR2-1 and HARQ enhancements for both type 1 and type 2 HARQ codebook.</p>	Band	No	N/A	N/A
<p>multiPUCCH-HARQ-ACK-ForMulticastUnicast-r17 Indicates whether the UE supports two non-overlapping slot-based PUCCHs for ACK/NACK based HARQ-ACK feedback for multicast or for unicast and multicast with different priorities in a slot.</p> <p>For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE supporting this feature shall also indicate support of <i>priorityIndicatorInDCI-Multicast-r17</i> and <i>twoHARQ-ACK-CodebookForUnicastAndMulticast-r17</i>.</p>	Band	No	N/A	N/A
<p>multiPUSCH-SingleDCI-FR2-1-SCS-120kHz-r17 Indicates whether the UE supports multi-PUSCH scheduling by single DCI for the operation with 120kHz SCS in FR2-1 with non-contiguous allocation.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>multipleRateMatchingEUTRA-CRS-r16 Indicates whether the UE supports multiple E-UTRA CRS rate matching patterns, which is supported only for FR1. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberPatterns-r16</i> indicates the maximum number of LTE-CRS rate matching patterns in total within a NR carrier using 15 kHz SCS. The UE can report the value larger than 2 only if UE reports the value of <i>maxNumberNon-OverlapPatterns-r16</i> is larger than 1. - <i>maxNumberNon-OverlapPatterns-r16</i> indicates the maximum number of LTE-CRS non-overlapping rate matching patterns within a NR carrier using 15 kHz SCS. <p>The UE can include this feature only if the UE indicates support of <i>rateMatchingLTE-CRS</i>.</p>	Band	No	N/A	FR1 only
<p>multipleTCI Indicates whether UE supports more than one TCI state configurations per CORESET. UE is only required to track one active TCI state per CORESET. UE is required to support minimum between 64 and number of configured TCI states indicated by <i>tcI-StatePDSCH</i>. This field shall be set to <i>supported</i>.</p>	Band	Yes	N/A	N/A
<p>nack-OnlyFeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling NACK-only based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2. A UE supporting this feature shall also indicate support of <i>nack-OnlyFeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>nack-OnlyFeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling NACK-only based HARQ-ACK feedback configured per G-CS-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE that indicates support of this feature shall indicate support of <i>nack-OnlyFeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>nonGroupSINR-reporting-r16 Indicates N_max L1-SINR values reported when UE supports non-group based L1-SINR reporting. UE indicates support of this feature shall indicate support of <i>ssb-csirs-SINR-measurement-r16</i>.</p>	Band	No	N/A	N/A
<p>nr-UE-TxTEG-ID-MaxSupport-r17 Indicates the maximum number of UE TxTEG for SRS resource for positioning, which is supported and reported by UE for UL TDOA. The UE can include this field only if the UE supports <i>srs-AllPosResources-r16</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>olpc-SRS-Pos-r16</i> Indicates whether the UE supports OLPC for SRS for positioning. The capability signalling comprises the following parameters.</p> <ul style="list-style-type: none"> - <i>olpc-SRS-PosBasedOnPRS-Serving-r16</i> indicates whether the UE supports OLPC for SRS for positioning based on PRS from the serving cell in the same band. The UE can include this field only if the UE supports <i>NR-DL-PRS-ProcessingCapability-r16</i> defined in TS 37.355 [22], and <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field; - <i>olpc-SRS-PosBasedOnSSB-Neigh-r16</i> indicates whether the UE supports OLPC for SRS for positioning based on SSB from the neighbouring cell in the same band. The UE can include this field only if the UE supports <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field; - <i>olpc-SRS-PosBasedOnPRS-Neigh-r16</i> indicates whether the UE supports OLPC for SRS for positioning based on PRS from the neighbouring cell in the same band. The UE can include this field only if the UE supports <i>olpc-SRS-PosBasedOnPRS-Serving-r16</i>. Otherwise, the UE does not include this field; <p>NOTE: A PRS from a PRS-only TP is treated as PRS from a non-serving cell.</p> <ul style="list-style-type: none"> - <i>maxNumberPathLossEstimatePerServing-r16</i> indicates the maximum number of pathloss estimates that the UE can simultaneously maintain for all the SRS resource sets for positioning per serving cell in addition to the up to four pathloss estimates that the UE maintains per serving cell for the PUSCH/PUCCH/SRS transmissions. The UE shall include this field if the UE supports any of <i>olpc-SRS-PosBasedOnPRS-Serving-r16</i>, <i>olpc-SRS-PosBasedOnSSB-Neigh-r16</i> and <i>olpc-SRS-PosBasedOnPRS-Neigh-r16</i>. Otherwise, the UE does not include this field. 	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>olpc-SRS-PosRRC-Inactive-r17 Indicates whether the UE supports OLPC for SRS for positioning in RRC_INACTIVE. The capability signalling comprises the following parameters.</p> <ul style="list-style-type: none"> - <i>olpc-SRS-PosBasedOnPRS-Serving-r16</i> indicates whether the UE supports OLPC for SRS for positioning based on PRS from the serving cell in the same band. The UE can include this field only if the UE supports <i>NR-DL-PRS-ProcessingCapability-r16</i> defined in TS 37.355 [22], and <i>srs-PosResourcesRRC-Inactive-r17</i>. Otherwise, the UE does not include this field; - <i>olpc-SRS-PosBasedOnSSB-Neigh-r16</i> indicates whether the UE supports OLPC for SRS for positioning based on SSB from the neighbouring cell in the same band. The UE can include this field only if the UE supports <i>srs-PosResourcesRRC-Inactive-r17</i>. Otherwise, the UE does not include this field; - <i>olpc-SRS-PosBasedOnPRS-Neigh-r16</i> indicates whether the UE supports OLPC for SRS for positioning based on PRS from the neighbouring cell in the same band. The UE can include this field only if the UE supports <i>olpc-SRS-PosBasedOnPRS-Serving-r16</i>. Otherwise, the UE does not include this field; <p>NOTE: A PRS from a PRS-only TP is treated as PRS from a non-serving cell.</p> <ul style="list-style-type: none"> - <i>maxNumberPathLossEstimatePerServing-r16</i> indicates the maximum number of pathloss estimates that the UE can simultaneously maintain for all the SRS resource sets for positioning per serving cell in addition to the up to four pathloss estimates that the UE maintains per serving cell for the PUSCH/PUCCH/SRS transmissions. The UE shall include this field if the UE supports any of <i>olpc-SRS-PosBasedOnPRS-Serving-r16</i>, <i>olpc-SRS-PosBasedOnSSB-Neigh-r16</i> and <i>olpc-SRS-PosBasedOnPRS-Neigh-r16</i>. Otherwise, the UE does not include this field. 	Band	No	N/A	N/A
<p>oneShotHARQ-feedbackPhy-Priority-r17 Indicates whether the UE supports transmission of type 3 HARQ-ACK codebook using the first or second PUCCH configuration based on PHY priority indication in the triggering DCI.</p> <p>A UE supporting this feature shall also indicate support of <i>oneShotHARQ-feedback-r16</i> and <i>twoHARQ-ACK-Codebook-type1-r16</i>.</p>	Band	No	N/A	N/A
<p>oneShotHARQ-feedbackTriggeredByDCI-1-2-r17 Indicates whether the UE supports one-shot HARQ ACK feedback triggered by DCI format 1_2, comprised of the following functional components:</p> <ul style="list-style-type: none"> - Supports feedback of type 3 HARQ-ACK codebook, triggered by a DCI 1_2 scheduling a PDSCH; - Supports feedback of type 3 HARQ-ACK codebook, triggered by a DCI 1_2 without scheduling a PDSCH using a reserved FDRA value. <p>A UE supporting this feature shall also indicate support of <i>oneShotHARQ-feedback-r16</i> and <i>dci-Format1-2And0-2-r16</i>.</p>	Band	No	N/A	N/A
<p>oneSlotPeriodicTRS-r16 Indicates whether the UE supports one-slot periodic TRS configuration only when no two consecutive slots are indicated as downlink slots by <i>tdd-UL-DL-ConfigurationCommon</i> or <i>tdd-UL-DL-ConfigDedicated</i>. If the UE supports this feature, the UE needs to report <i>csi-RS-ForTracking</i>.</p>	Band	No	TDD only	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>outOfOrderOperationDL-r16 Indicates whether the UE supports out of order operation for DL. The UE that indicates support of this feature shall support <i>multiDCI-MultiTRP-r16</i>. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>supportPDCCH-ToPDSCH-r16</i> indicates support out-of-order operation for PDCCH to PDSCH; - <i>supportPDSCH-ToHARQ-ACK-r16</i> indicates support out-of-order operation for PDSCH to HARQ-ACK. 	Band	No	N/A	N/A
<p>outOfOrderOperationUL-r16 Indicates whether the UE supports out of order operation for UL. The UE that indicates support of this feature shall support <i>multiDCI-MultiTRP-r16</i>.</p> <p>Note: Same closed loop index for power control across PUSCHs associated with different <i>CORESETPoolIndex</i> values is not supported by a UE indicating the support of this feature when TPC accumulation is enabled.</p>	Band	No	N/A	N/A
<p>overlapPDSCHsFullyFreqTime-r16 Indicates the maximal number of PDSCH scrambling sequences per serving cell when the UE supports PDSCHs with fully overlapping Resource Elements. The UE that indicates support of this feature shall support <i>multiDCI-MultiTRP-r16</i>.</p> <p>Note: A UE may assume that its maximum receive timing difference between the DL transmissions from two TRPs is within a Cyclic Prefix</p>	Band	No	N/A	N/A
<p>overlapPDSCHsInTimePartiallyFreq-r16 Indicates whether the UE supports PDSCHs with partially overlapping Resource Elements. The UE that indicates support of this feature shall support <i>overlapPDSCHsFullyFreqTime-r16</i>.</p>	Band	No	N/A	N/A
<p>overlapRateMatchingEUTRA-CRS-r16 Indicates whether the UE supports two LTE-CRS overlapping rate matching patterns within a part of NR carrier using 15 kHz SCS overlapping with a LTE carrier. If the UE supports this feature, the UE needs to report <i>multipleRateMatchingEUTRA-CRS-r16</i>.</p>	Band	No	N/A	FR1 only
<p>parallelMeasurementWithoutRestriction-r17 Indicates whether the UE supports measurements on cells belonging to different satellites as the serving cell in parallel with normal operation (i.e. data/control transmission and/or reception, and L1 measurements) of serving cell without scheduling restrictions. The feature is applicable only when the serving satellite is NGSO. If the serving cell belongs to GSO satellite, the scheduling restriction is not applied on the premise that a mixed type of satellites on the same frequency layer is not supported in this release. If not reported, for measurements in parallel with normal operation of serving cell scheduling restrictions shall apply.</p>	Band	No	FDD only	FR1 only
<p>parallelPRS-MeasRRC-Inactive-r17 Indicates whether the UE supports performing RRM measurement and PRS measurement in parallel. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively</p>	Band	No	N/A	N/A
<p>pdccch-SkippingWithoutSSSG-r17 Indicates whether the UE supports up to 2-bit indication of PDCCH skipping by scheduling DCI if SSSG is not configured as specified in TS 38.213 [11], clause 10.4.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>pdccch-SkippingWithSSSG-r17</i> Indicates whether the UE supports 2-bit indication of SSSG switching between 2 SSSGs, PDCCH skipping by scheduling DCI, and timer based SSSG switching as specified in TS 38.213 [11], clause 10.4. UE supports search space set group switching capability-1 according to Table 10.4-1 of TS 38.213 [11].</p> <p>UE indicating support of this feature shall also indicate support of <i>pdccch-SkippingWithoutSSSG-r17</i> and <i>sssg-Switching-1bitInd-r17</i>.</p>	Band	No	N/A	N/A
<p><i>pdsch-1024QAM-2MIMO-FR1-r17</i> Indicates whether the UE supports 1024QAM modulation scheme for PDSCH with maximum 2 MIMO layers for FR1 as defined in TS 38.211 [6], MCS and CQI feedback tables based on 1024QAM modulation order as defined in TS 38.214 [12].</p> <p>UE indicating support of this feature shall also indicate support of <i>pdsch-256QAM-FR1</i> and shall not indicate support of <i>pdsch-1024QAM-FR1-r17</i>.</p>	Band	No	N/A	FR1 only
<p><i>pdsch-1024QAM-FR1-r17</i> Indicates whether the UE supports 1024QAM modulation scheme for PDSCH for FR1 as defined in TS 38.211 [6], MCS and CQI feedback tables based on 1024QAM modulation order as defined in TS 38.214 [12].</p> <p>UE indicating support of this feature shall also indicate support of <i>pdsch-256QAM-FR1</i> and shall not indicate support of <i>pdsch-1024QAM-2MIMO-FR1-r17</i>.</p>	Band	No	N/A	FR1 only
<p><i>pdsch-256QAM-FR2</i> Indicates whether the UE supports 256QAM modulation scheme for PDSCH for FR2 as defined in 7.3.1.2 of TS 38.211 [6].</p>	Band	No	N/A	FR2 only
<p><i>pdsch-MappingTypeB-Alt-r16</i> Indicates whether the UE supports PDSCH Type B scheduling of length 9 and 10 OFDM symbols, and DMRS shift for length-10 symbols. If the UE supports this feature, the UE needs to report <i>pdsch-MappingTypeB</i>.</p>	Band	No	N/A	FR1 only
<p><i>periodicBeamReport</i> Indicates whether UE supports periodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting using PUCCH formats 2, 3 and 4 in one slot.</p>	Band	Yes	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>posSRS-RRC-Inactive-OutsidelInitialUL-BWP-r17</i> Indicates support of Positioning SRS transmission in RRC_INACTIVE state configured outside initial UL BWP. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxSRSposBandwidthForEachSCS-withinCC-FR1-r17</i> Indicates the maximum SRS bandwidth supported for each SCS that UE supports within a single CC for FR1; - <i>maxSRSposBandwidthForEachSCS-withinCC-FR2-r17</i> indicates the maximum SRS bandwidth supported for each SCS that UE supports within a single CC for FR2; - <i>maxNumOfSRSposResourceSets-r17</i> indicates the max number of SRS Resource Sets for positioning supported by UE; - <i>maxNumOfPeriodicSRSposResources-r17</i> indicates the max number of periodic SRS Resources for positioning; - <i>maxNumOfPeriodicSRSposResourcesPerSlot-r17</i> indicates the max number of periodic SRS Resources for positioning per slot; - <i>differentNumerologyBetweenSRSposAndInitialBWP-r17</i> indicates the support of different numerology between the SRS and the initial UL BWP; - <i>srsPosWithoutRestrictionOnBWP-r17</i> indicates the support of SRS operation without restriction on the BW: BW of the SRS may not include BW of the CORESET#0 and SSB; - <i>maxNumOfPeriodicAndSemipersistentSRSposResources-r17</i> indicates the max number of P/SP SRS Resources for positioning; - <i>maxNumOfPeriodicAndSemipersistentSRSposResourcesPerSlot-r17</i> indicates the max number of P/SP SRS Resources for positioning per slot; - <i>differentCenterFreqBetweenSRSposAndInitialBWP-r17</i> indicates the support of a different center frequency between the SRS for positioning and the initial UL BWP; - <i>switchingTimeSRS-TX-OtherTX-r17</i> indicates the switching time between SRS TX and other TX in initial UL BWP or RX in initial DL BWP - <i>maxNumOfSemiPersistentSRSposResources-r17</i> indicates the max number of semi-persistent SRS Resources for positioning; - <i>maxNumOfSemiPersistentSRSposResourcesPerSlot-r17</i> indicates the max number of semi-persistent SRS Resources for positioning per slot. <p>The UE can include this field only if the UE supports <i>srs-PosResourcesRRC-Inactive-r17</i>. Otherwise, the UE does not include this field;</p> <p>NOTE 1: The SRS should have a <i>locationAndBandwidth</i>, SCS, CP, defined the same way as a legacy BWP.</p> <p>NOTE 2: If <i>differentCenterFreqBetweenSRSposAndInitialBWP-r17</i> is not signalled, the UE only supports same center frequency between the SRS for positioning and initial UL BWP.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>powerBoosting-pi2BPSK Indicates whether UE supports power boosting for pi/2 BPSK, when applicable as defined in 6.2 of TS 38.101-1 [2] v16.9.0. It is mandatory with capability signalling. This capability is not applicable to IAB-MT.</p>	Band	CY	TDD only	FR1 only
<p>priorityIndicatorInDCI-Multicast-r17 Indicates whether the UE supports DL priority indication for multicast in DCI, comprised of the following functional components:</p> <ul style="list-style-type: none"> - Support of priority indicator field configured in DCI formats 4_2 with CRC scrambled with G-RNTI for multicast; - Supports two HARQ-ACK codebooks with different priorities to be simultaneously constructed different priorities for multicast and multicast at a UE. <p>For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>priorityIndicatorInDCI-SPS-Multicast-r17 Indicates whether the UE supports priority indicator field configured in DCI format 4_2 for multicast HARQ-ACK feedback of SPS multicast.</p> <p>For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>prs-MeasurementWithoutMG-r17 Indicates whether the UE supports using the threshold to compare the Rx time difference between the serving cell and a neighbor cell/TRP for PRS measurements, as defined in clause 9.9.1.2 of TS 38.133 [5], to determine whether the PRS from the non-serving cell satisfy the condition of PRS measurement outside MG. The UE can include this field only if the UE supports one of <i>prs-ProcessingWindowType1A-r17</i>, <i>prs-ProcessingWindowType1B-r17</i> and <i>prs-ProcessingWindowType2-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>prs-ProcessingCapabilityOutsideMGinPPW-r17</i> Indicates the DL-PRS Processing Capability outside MG of each of the supported PRS Processing Window (PPW) Type in the case the UE supports multiple PPW Types in a band and comprises the following subfields:</p> <ul style="list-style-type: none"> - <i>prsProcessingType-r17</i>: Indicates the PPW Type for which the <i>prs-ProcessingCapabilityOutsideMGinPPW-r17</i> are provided. - <i>ppw-dl-PRS-BufferType-r17</i>: Indicates DL-PRS buffering capability. Value 'type1' indicates sub-slot/symbol level buffering and value 'type2' indicates slot level buffering. - <i>ppw-durationOfPRS-Processing1-r17</i>: Indicates the duration of DL-PRS symbols N in units of ms a UE can process every T ms assuming maximum DL-PRS bandwidth provided in <i>ppw-maxNumOfDL-Bandwidth-r17</i> and comprises the following subfields <ul style="list-style-type: none"> - <i>ppw-durationOfPRS-ProcessingSymbolsN-r17</i>: This field specifies the values for N with values msDot125 indicates 0.125ms, msDot25 indicates 0.25ms, and so on - <i>ppw-durationOfPRS-ProcessingSymbolsT-r17</i>: This field specifies the values for T with values ms1 indicates 1ms, ms2 indicates 2ms, and so on. - <i>ppw-durationOfPRS-Processing2-r17</i>: Indicates the duration of DL-PRS symbols N2 in units of ms a UE can process every T2 ms assuming maximum DL-PRS bandwidth provided in <i>ppw-maxNumOfDL-Bandwidth-r17</i> and comprises the following subfields: <ul style="list-style-type: none"> - <i>ppw-durationOfPRS-ProcessingSymbolsN2-r17</i>: This field specifies the values for N2 with values msDot125 indicates 0.125ms, msDot25 indicates 0.25ms, and so on. - <i>ppw-durationOfPRS-ProcessingSymbolsT2-r17</i>: This field specifies the values for T2 with values ms4 indicates 4ms, ms5 indicates 5ms, and so on. - <i>ppw-maxNumOfDL-PRS-ResProcessedPerSlot-r17</i>: Indicates the maximum number of DL PRS bandwidth in MHz, which is supported and reported by UE for PRS measurement outside MG within the PPW. - <i>ppw-maxNumOfDL-Bandwidth-r17</i>: Indicates the maximum number of DL PRS bandwidth in MHz for FR1 and FR2, which is supported and reported by UE for PRS measurement outside MG within the PPW. <p>The UE can include this field only if the UE supports one of <i>prs-ProcessingWindowType1A-r17</i>, <i>prs-ProcessingWindowType1B-r17</i> and <i>prs-ProcessingWindowType2-r17</i>. Otherwise, the UE does not include this field.</p> <p>NOTE 1: A UE that supports one of <i>prs-ProcessingWindowType1A-r17</i>, <i>prs-ProcessingWindowType1B-r17</i> or <i>prs-ProcessingWindowType2-r17</i> shall always include the <i>prs-ProcessingCapabilityOutsideMGinPPW-r17</i>.</p> <p>NOTE 2: The (N, T) in <i>ppw-durationOfPRS-Processing1-r17</i> is interpreted as in (N,T) in <i>durationOfPRS-Processing-r16</i> in TS 37.355 [22], and the UE is expected to receive the DL-PRS within the PPW but the processing of the received DL-PRS may be outside a PPW</p> <p>NOTE 3: The (N2, T2) in <i>ppw-durationOfPRS-Processing2-r17</i> is interpreted such that the UE is capable of measuring up to N2 ms DL-PRS within a PPW and is capable of completing the DL-PRS processing within the PPW, e.g., if the time duration from the last symbol of the measured DL-PRS resource(s) inside the PPW to the end of PPW is not smaller than T2 ms.</p> <p>NOTE 4: A UE which supports <i>prs-ProcessingCapabilityOutsideMGinPPW-r17</i> shall support either <i>ppw-durationOfPRS-Processing1-r17</i> or <i>ppw-</i></p>	Band	No	N/A	N/A

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>prs-ProcessingRRC-Inactive-r17</i> Indicates whether the UE supports PRS processing in RRC_INACTIVE.</p>	Band	No	N/A	N/A
<p><i>prs-ProcessingWindowType1A-r17</i> Indicates whether the UE supports PRS processing Type 1A, subject to the UE determining that DL PRS to be higher priority for PRS measurement outside MG and in a PRS processing window and the priority handling options of PRS as follows:</p> <ul style="list-style-type: none"> - Option 1: Support of "st1" and "st3" defined in clause 5.1.6.5 of TS 38.214 [12]. - Option 2: Support of "st1", "st2", and "st3" defined in clause 5.1.6.5 of TS 38.214 [12]. <p>NOTE 1: Void.</p> <ul style="list-style-type: none"> - Option 3: Support of "st1" only defined in clause 5.1.6.5 of TS 38.214 [12]. <p>The UE can include this field only if the UE supports <i>prs-ProcessingCapabilityBandList-r16</i> defined in TS 37.355 [22]. A UE supporting this feature shall also indicate support of <i>prs-ProcessingCapabilityOutsideMGinPPW-r17</i>.</p> <p>NOTE 2: Type 1A refers to the determination of prioritization between DL PRS and other DL signals/channels in all OFDM symbols within the PRS processing window. The DL signals/channels from all DL CCs (per UE) are affected across LTE and NR.</p> <p>NOTE 3: Within a PRS processing window, UE measurement is inside the active DL BWP with PRS having the same numerology as the active DL BWP.</p> <p>NOTE 4: Support of configuration of PRS processing window in RRC and support of using DL MAC CE to activate/deactivate the PRS processing window for PRS measurements is part of the feature.</p> <p>NOTE 5: When the UE determines higher priority for other DL signals/channels over the DL-PRS measurement/processing, the UE is not expected to measure/process DL-PRS.</p>	Band	No	N/A	N/A

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>prs-ProcessingWindowType1B-r17</i> Indicates whether the UE supports PRS processing Type 1B, subject to the UE determining that DL PRS to be higher priority for PRS measurement outside MG and in a PRS processing window and the priority handling options of PRS as follows:</p> <ul style="list-style-type: none"> - Option 1: Support of "st1" and "st3" defined in clause 5.1.6.5 of TS 38.214 [12]. - Option 2: Support of "st1", "st2", and "st3" defined in clause 5.1.6.5 of TS 38.214 [12]. NOTE 1: Void. - Option 3: Support of "st1" only defined in clause 5.1.6.5 of TS 38.214 [12]. <p>The UE can include this field only if the UE supports <i>prs-ProcessingCapabilityBandList-r16</i> defined in TS 37.355 [22]. A UE supporting this feature shall also indicate support of <i>prs-ProcessingCapabilityOutsideMGinPPW-r17</i>.</p> <p>NOTE 2: Type 1B refers to the determination of prioritization between DL PRS and other DL signals/channels in all OFDM symbols within the PRS processing window. The DL signals/channels from a certain band are affected.</p> <p>NOTE 3: Within a PRS processing window, UE measurement is inside the active DL BWP with PRS having the same numerology as the active DL BWP.</p> <p>NOTE 4: Support of configuration of PRS processing window in RRC and support of using DL MAC CE to activate/deactivate the PRS processing window for PRS measurements is part of the feature.</p> <p>NOTE 5: When the UE determines higher priority for other DL signals/channels over the DL-PRS measurement/processing, the UE is not expected to measure/process DL-PRS.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>prs-ProcessingWindowType2-r17 Indicates whether the UE supports PRS processing Type 2, subject to the UE determining that DL PRS to be higher priority for PRS measurement outside MG and in a PRS processing window and the priority handling options of PRS as follows:</p> <ul style="list-style-type: none"> - Option 1: Support of "st1" and "st3" defined in clause 5.1.6.5 of TS 38.214 [12]. - Option 2: Support of "st1", "st2", and "st3" defined in clause 5.1.6.5 of TS 38.214 [12]. NOTE 1: Void. - Option 3: Support of "st1" only defined in clause 5.1.6.5 of TS 38.214 [12]. <p>The UE can include this field only if the UE supports <i>prs-ProcessingCapabilityBandList-r16</i> defined in TS 37.355 [22]. A UE supporting this feature shall also indicate support of <i>prs-ProcessingCapabilityOutsideMGinPPW-r17</i>.</p> <p>NOTE 2: Type 2 refers to the determination of prioritization between DL PRS and other DL signals/channels only in DL PRS symbols within the PRS processing window.</p> <p>NOTE 3: Within a PRS processing window, UE measurement is inside the active DL BWP with PRS having the same numerology as the active DL BWP.</p> <p>NOTE 4: Support of configuration of PRS processing window in RRC and support of using DL MAC CE to activate/deactivate the PRS processing window for PRS measurements is part of the feature.</p> <p>NOTE 5: When the UE determines higher priority for other DL signals/channels over the DL-PRS measurement/processing, the UE is not expected to measure/process DL-PRS.</p>	Band	No	N/A	N/A
<p>ptrs-DensityRecommendationSetDL For each supported sub-carrier spacing, indicates preferred threshold sets for determining DL PTRS density. It is mandated for FR2. For each supported sub-carrier spacing, this field comprises:</p> <ul style="list-style-type: none"> - two values of <i>frequencyDensity</i>; - three values of <i>timeDensity</i>. 	Band	CY	N/A	N/A
<p>ptrs-DensityRecommendationSetUL For each supported sub-carrier spacing, indicates preferred threshold sets for determining UL PTRS density. For each supported sub-carrier spacing, this field comprises:</p> <ul style="list-style-type: none"> - two values of <i>frequencyDensity</i>; - three values of <i>timeDensity</i>; - five values of <i>sampleDensity</i>. 	Band	No	N/A	N/A
<p>pucch-Repetition-F0-2-r17 Indicates whether the UE supports transmission of a PUCCH format 0 and 2 over multiple slots with the repetition factor 2, 4 or 8. A UE supporting this feature shall also indicate support of <i>pucch-Repetition-F1-3-4</i>.</p>	Band	No	N/A	N/A
<p>pucch-SpatialRelInfoMAC-CE Indicates whether the UE supports indication of <i>PUCCH-spatialrelationinfo</i> by a MAC CE per PUCCH resource. It is mandatory for FR2 and optional for FR1.</p>	Band	CY	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>pusch-256QAM Indicates whether the UE supports 256QAM modulation scheme for PUSCH as defined in 6.3.1.2 of TS 38.211 [6].</p>	Band	No	N/A	N/A
<p>pusch-RepetitionMsg3-r17 Indicates whether the UE supports repetition of PUSCH transmission scheduled by RAR UL grant and DCI format 0_0 with CRC scrambled by TC-RNTI.</p>	Band	No	N/A	N/A
<p>pusch-RepetitionMultiSlots-v1650 Indicates whether the UE supports transmitting PUSCH scheduled by DCI format 0_1 when configured with <i>pusch-AggregationFactor</i> > 1, as defined in clause 6.1.2.1 of TS 38.214 [12]. This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>pusch-RepetitionMultiSlots-r16</i> applies. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>The UE only includes <i>pusch-RepetitionMultiSlots-v1650</i> if <i>pusch-RepetitionMultiSlots</i> is absent.</p>	Band	Yes	N/A	N/A
<p>pusch-RepetitionTypeA-v16c0 Indicates whether the UE supports the dynamic indication of the number of repetitions for PUSCH transmission as specified in TS 38.214 [12], clause 6.1.2.1. Support of this field is reported for shared spectrum channel access and non-shared spectrum channel access, respectively. UE indicating support of this feature shall support at least one of <i>type2-PUSCH-RepetitionMultiSlots</i> and <i>pusch-RepetitionMultiSlots</i> for shared spectrum and non-shared spectrum respectively.</p> <p>UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands respectively.</p> <p>The UE only includes <i>pusch-RepetitionTypeA-v16c0</i> if <i>pusch-RepetitionTypeA-r16</i> is absent.</p>	Band	No	N/A	N/A
<p>pusch-TransCoherence Defines support of the uplink codebook subset by the UE for UL precoding for PUSCH transmission as described in clause 6.1.1.1 of TS 38.214 [12]. UE indicated support of partial coherent codebook subset shall also support non-coherent codebook subset. UE indicated support of full coherent codebook subset shall also support partial and non-coherent codebook subset.</p>	Band	No	N/A	N/A
<p>puschTypeA-RepetitionsAvailSlot-r17 Indicates whether UE supports dynamic and configured grant PUSCH repetitions based on available slots. Transmission occasions for the repetitions for dynamic and configured grant PUSCH are determined on the basis of available slots.</p> <p>A UE that indicates support of this feature shall support <i>type1-PUSCH-RepetitionMultiSlots</i>, <i>type2-PUSCH-RepetitionMultiSlots</i> or <i>pusch-RepetitionMultiSlots</i>.</p>	Band	No	N/A	N/A
<p>rateMatchingLTE-CRS Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs determined by the higher layer configuration LTE-carrier configuring common RS, as specified in TS 38.214 [12].</p>	Band	Yes	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>releaseSPS-MulticastWithCS-RNTI-r17 Indicates whether UE supports unicast PDCCH scrambled with CS-RNTI to release SPS group-common PDSCH. For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE that indicates the support of this feature shall indicate support of <i>sps-Multicast-r17</i> and <i>sps-r16</i>.</p>	Band	No	N/A	N/A
<p>re-LevelRateMatchingForMulticast-r17 Indicates whether the UE supports group-common PDSCH RE-level rate matching for multicast, comprised of the following functional components:</p> <ul style="list-style-type: none"> - Supports SP ZP-CSI-RS for group-common PDSCH RE-mapping patterns; - Supports P ZP-CSI-RS for group-common PDSCH RE-mapping patterns; - Supports <i>p-ZP-CSI-RS-ResourceSet</i> configured in <i>PDSCH-Config-Multicast</i> same as or different from the <i>p-ZP-CSI-RS-ResourceSet</i> configured in <i>PDSCH-Config</i>; - Supports AP ZP-CSI-RS for group-common PDSCH RE-mapping patterns. <p>For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE supporting this feature shall also indicate support of <i>dynamicMulticastPCell-r17</i>. A UE supporting this feature in FR1 bands shall also indicate support of <i>pdsch-RE-MappingFR1-PerSymbol</i> or <i>pdsch-RE-MappingFR1-PerSlot</i>. A UE supporting this feature in FR2 bands shall also indicate support of <i>pdsch-RE-MappingFR2-PerSymbol</i> or <i>pdsch-RE-MappingFR2-PerSlot</i>.</p> <p>NOTE: The total number of semi-persistent ZP-CSI-RS-ResourceSet that a UE can be configured with is the same as for unicast in Rel-16.</p>	Band	No	N/A	N/A
<p>rlm-Relaxation-r17 Indicates whether the UE supports RLM relaxation criteria and requirement as specified in TS 38.133 [5]. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>UE indicating support of this feature shall also indicate support of <i>ssb-RLM</i> and/or <i>csi-RS-RLM</i>.</p>	Band	No	N/A	N/A
<p>searchSpaceSetGrp-switchCap2-r17 Indicates whether UE supports search space set group switching capability 2 for FR1 according to Table 10.4-1 of TS 38.213 [11] for SSSG switching.</p> <p>UE indicating support of this feature shall also indicate support of <i>sssg-Switching-1BitInd-r17</i>.</p> <p>NOTE: For UE supporting this feature and also <i>sssg-Switching-1BitInd-r17</i>, <i>sssg-Switching-2BitInd-r17</i>, and/or <i>pdccch-SkippingWithSSSG-r17</i>, search space set group switching Capability-2 is applied to <i>sssg-Switching-1BitInd-r17</i>, <i>sssg-Switching-2BitInd-r17</i>, and/or <i>pdccch-SkippingWithSSSG-r17</i>.</p>	Band	No	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>semi-PersistentL1-SINR-Report-PUCCH-r16 Indicates whether the UE supports semi-persistent L1-SINR report on PUCCH. The UE indicating support of this feature shall include at least one of the following capabilities:</p> <ul style="list-style-type: none"> - <i>supportReportFormat1-2OFDM-syms-r16</i> indicates support of report on PUCCH formats over 1 – 2 OFDM symbols once per slot (or piggybacked on a PUSCH) - <i>supportReportFormat4-14OFDM-syms-r16</i> indicates support of report on PUCCH formats over 4 – 14 OFDM symbols once per slot (or piggybacked on a PUSCH). <p>The UE indicating support of this feature shall also indicate support of <i>ssb-csirs-SINR-measurement-r16</i>.</p>	Band	No	N/A	N/A
<p>semi-PersistentL1-SINR-Report-PUSCH-r16 Indicates whether the UE supports semi-persistent L1-SINR report on PUSCH. The UE indicating support of this feature shall also indicate support of <i>ssb-csirs-SINR-measurement-r16</i>.</p>	Band	No	N/A	N/A
<p>separateCRS-RateMatching-r16 Indicates whether the UE supports rate match around configured CRS patterns which is associated with <i>CORESETPoolIndex</i> (if configured) and are applied to the PDSCH scheduled with a DCI detected on a CORESET with the same value of <i>CORESETPoolIndex</i>. The UE that indicates support of this feature shall support <i>multiDCI-MultiTRP-r16</i> and <i>overlapRateMatchingEUTRA-CRS-r16</i>. This is only applicable for 15kHz SCS.</p>	Band	No	N/A	FR1 only
<p>sfn-SimulTwoTCI-AcrossMultiCC-r17 Indicates whether the UE supports simultaneous activation of two TCI states for CORESETs with the same CORESET ID in all BWPs across a set of configured component carriers by single MAC-CE. The UE indicating support of this feature shall also indicate <i>sfn-schemeA-r17</i> or <i>sfn-schemeB-r17</i> or <i>sfn-SchemeA-PDCCH-only-r17</i>.</p> <p>The UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p>	Band	No	N/A	N/A
<p>sfn-DefaultDL-BeamSetup-r17 Indicates whether the UE supports the following features:</p> <ul style="list-style-type: none"> - For FR2 only, PDSCH reception using default beam for enhanced SFN scheme when PDSCH is scheduled with offset less than threshold. - For FR1 and FR2, PDSCH reception using default beam for enhanced SFN scheme when TCI field is not present in DCI format 1_0/1_1/1_2 when PDSCH is scheduled with offset equal or larger than the threshold, if applicable. - For FR2 only, aperiodic CSI-RS reception using default beam for enhanced SFN scheme when scheduling offset is less than threshold. <p>The UE indicating support of this feature shall also indicate <i>sfn-schemeA-r17</i> or <i>sfn-schemeB-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>sfn-DefaultUL-BeamSetup-r17 Indicates whether the UE supports the following features:</p> <ul style="list-style-type: none"> - Support of single-TRP PUCCH transmission using default beam when enhanced SFN PDCCH transmission scheme is configured. - Support of single-TRP PUSCH transmission using default beam when enhanced SFN PDCCH transmission scheme is configured. - Support of single-TRP SRS resource transmission using default beam when enhanced SFN PDCCH transmission scheme is configured. <p>The UE indicating support of this feature shall also indicate <i>sfn-schemeA-r17</i> or <i>sfn-schemeB-r17</i> or <i>sfn-SchemeA-PDCCH-only-r17</i>.</p>	Band	No	N/A	FR2 only
<p>sfn-ImplicitRS-twoTCI-r17 Indicates whether the UE supports RS(s) with two TCI states configured implicitly for beam failure detection enhancement for HST.</p>	Band	No	N/A	N/A
<p>sfn-QCL-TypeD-Collision-twoTCI-r17 Indicates whether the UE supports identification of two QCL-TypeD properties for multiple overlapping CORESETs when a CORESET is activated with two TCI states which overlaps with another CORESET.</p>	Band	No	N/A	N/A
<p>simul-SpatialRelationUpdatePUCCHResGroup-r16 Indicates whether the UE support PUCCH resource groups per BWP for simultaneous spatial relation update. The UE indicating support of this also indicates the capabilities of supported SRS resources and maximum supported spatial relations for the supported bands using <i>supportedSRS-Resources</i>, <i>maxNumberConfiguredSpatialRelations</i> and <i>pucch-SpatialRelInfoMAC-CE</i>.</p>	Band	No	N/A	N/A
<p>simulTX-SRS-AntSwitchingIntraBandUL-CA-r16 Indicates whether the UE support simultaneous transmission of SRS on different CCs for intra-band UL CA. The UE indicating support of this feature shall include at least one of the following capabilities:</p> <ul style="list-style-type: none"> - <i>supportSRS-xTyR-xLessThanY-r16</i> indicates support transmission of SRS for xTyR (x<y) based antenna switching and SRS for CB/NCB/BM on different CCs in overlapped symbol(s) for intra-band UL CA. - <i>supportSRS-xTyR-xEqualToY-r16</i> indicates support transmission of SRS for xTyR (x=y) based antenna switching and SRS for CB/NCB/BM on different CCs in overlapped symbol(s) for intra-band UL CA. - <i>supportSRS-AntennaSwitching-r16</i> Indicates whether the UE support simultaneous transmission of SRS for antenna switching on different CCs in overlapped symbol(s) for intra-band UL CA. <p>NOTE: For simultaneously antenna switching and antenna switching SRS in intra-band CAs with bands whose UL are switched together according to the reported <i>supportSRS-AntennaSwitching-r16</i>, the UE expects the same configuration of xTyR across the different CCs and the SRS resources overlapped in time domain from UE perspective are from the same UE antenna ports.</p>	Band	No	N/A	N/A
<p>simulSRS-MIMO-TransWithinBand-r16 Indicates the number of SRS resources for positioning and SRS resource for MIMO on a symbol within a band across multiple CCs. The UE can include this field only if the UE supports <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field.</p>	Band	No	N/A	N/A
<p>simulSRS-TransWithinBand-r16 Indicates the number of SRS resources for positioning on a symbol within a band across multiple CCs. The UE can include this field only if the UE supports <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>simultaneousReceptionDiffTypeD-r16</i> Indicates whether the UE supports simultaneous reception with different QCL Type D reference signal as specified in TS38.213 [11].</p>	Band	No	N/A	FR2 only
<p><i>sn-InitiatedCondPSCellChangeNRDC-r17</i> Indicates whether the UE supports SN initiated inter-SN conditional PSCell change in NR-DC, which is configured by NR <i>conditionalReconfiguration</i> using SN configured measurement as triggering condition. The UE supporting this feature shall also support 2 trigger events for same execution condition in SN initiated inter-SN conditional PSCell change in NR-DC. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands respectively.</p>	Band	No	N/A	N/A
<p><i>spatialRelations, spatialRelations-v1640</i> Indicates whether the UE supports spatial relations. The capability signalling comprises the following parameters.</p> <ul style="list-style-type: none"> - <i>maxNumberConfiguredSpatialRelations</i> indicates the maximum number of configured spatial relations per CC for PUCCH and SRS. It is not applicable to FR1 and applicable to FR2 only. The UE is mandated to report 16 or higher values. <i>maxNumberConfiguredSpatialRelations-v1640</i> indicates the maximum number of configured spatial relations per CC for PUCCH and SRS with UE supporting the configuration of maximum 64 PUCCH spatial relations per BWP per CC; - <i>maxNumberActiveSpatialRelations</i> indicates the maximum number of active spatial relations with regarding to PUCCH and SRS for PUSCH, per BWP per CC. It is not applicable to FR1 and applicable and mandatory to report one or higher value for FR2 only; - <i>additionalActiveSpatialRelationPUCCH</i> indicates support of one additional active spatial relation for PUCCH. It is mandatory with capability signalling if <i>maxNumberActiveSpatialRelations</i> is set to n1; - <i>maxNumberDL-RS-QCL-TypeD</i> indicates the maximum number of downlink RS resources used for QCL type D in the active TCI states and active spatial relation information, which is optional. <p>The UE is mandated to report <i>spatialRelations</i> for FR2. if <i>maxNumberConfiguredSpatialRelations-v1640</i> is reported, UE shall report value <i>n96</i> in <i>maxNumberConfiguredSpatialRelations</i>.</p>	Band	FD	N/A	FD

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>spatialRelationsSRS-Pos-r16</i> Indicates whether the UE supports spatial relations for SRS for positioning. The capability signalling comprises the following parameters.</p> <ul style="list-style-type: none"> - <i>spatialRelation-SRS-PosBasedOnSSB-Serving-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on SSB from the serving cell in the same band. The UE can include this field only if the UE supports <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field; - <i>spatialRelation-SRS-PosBasedOnCSI-RS-Serving-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on CSI-RS from the serving cell in the same band. The UE can include this field only if the UE supports <i>spatialRelation-SRS-PosBasedOnSSB-Serving-r16</i>. Otherwise, the UE does not include this field; - <i>spatialRelation-SRS-PosBasedOnPRS-Serving-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on PRS from the serving cell in the same band. The UE can include this field only if the UE supports any of DL PRS Resources for DL AoD, DL PRS Resources for DL-TDOA or DL PRS Resources for Multi-RTT defined in TS37.355 [22], or <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field; - <i>spatialRelation-SRS-PosBasedOnSRS-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on SRS in the same band. The UE can include this field only if the UE supports <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field; - <i>spatialRelation-SRS-PosBasedOnSSB-Neigh-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on SSB from the neighbouring cell in the same band. The UE can include this field only if the UE supports <i>spatialRelation-SRS-PosBasedOnSSB-Serving-r16</i>. Otherwise, the UE does not include this field; - <i>spatialRelation-SRS-PosBasedOnPRS-Neigh-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on PRS from the neighbouring cell in the same band. The UE can include this field only if the UE supports <i>spatialRelation-SRS-PosBasedOnPRS-Serving-r16</i>. Otherwise, the UE does not include this field; <p>NOTE: A PRS from a PRS-only TP is treated as PRS from a non-serving cell.</p>	Band	No	N/A	FR2 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>spatialRelationsSRS-PosRRC-Inactive-r17 Indicates whether the UE supports spatial relations for SRS for positioning in RRC_INACTIVE. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>spatialRelation-SRS-PosBasedOnSSB-Serving-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on SSB from the serving cell in the same band. The UE indicating support of this feature shall also indicate support of <i>srs-PosResourcesRRC-Inactive-r17</i>; - <i>spatialRelation-SRS-PosBasedOnCSI-RS-Serving-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on CSI-RS from the serving cell in the same band. The UE indicating support of this feature shall also indicate support of <i>spatialRelation-SRS-PosBasedOnSSB-Serving-r16</i>; - <i>spatialRelation-SRS-PosBasedOnPRS-Serving-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on PRS from the serving cell in the same band. The UE indicating support of this feature shall also indicate support any of DL PRS Resources for DL AoD, DL PRS Resources for DL-TDOA or DL PRS Resources for Multi-RTT defined in TS37.355 [22], or <i>srs-PosResourcesRRC-Inactive-r17</i>; - <i>spatialRelation-SRS-PosBasedOnSRS-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on SRS in the same band. The UE indicating support of this feature shall also indicate support of <i>srs-PosResourcesRRC-Inactive-r17</i>; - <i>spatialRelation-SRS-PosBasedOnSSB-Neigh-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on SSB from the neighbouring cell in the same band. The UE indicating support of this feature shall also indicate support of <i>spatialRelation-SRS-PosBasedOnSSB-Serving-r16</i>; - <i>spatialRelation-SRS-PosBasedOnPRS-Neigh-r16</i> indicates whether the UE supports spatial relation for SRS for positioning based on PRS from the neighbouring cell in the same band. The UE indicating support of this feature shall also indicate support of <i>spatialRelation-SRS-PosBasedOnPRS-Serving-r16</i>. <p>NOTE: A PRS from a PRS-only TP is treated as PRS from a non-serving cell.</p>	Band	No	N/A	FR2 only
<p>sp-BeamReportPUCCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting using PUCCH formats 2, 3 and 4 in one slot.</p>	Band	No	N/A	N/A
<p>sp-BeamReportPUSCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH.</p>	Band	No	N/A	N/A
<p>sps-MulticastDCI-Format4-2-r17 Indicates whether the UE supports transmission and retransmission scheduled by DCI format 4_2 with CRC scrambled with G-CS-RNTI for multicast SPS scheduling.</p> <p>A UE that indicates support of this feature shall indicate support of <i>sps-Multicast-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>sps-MulticastMultiConfig-r17 Indicates whether the UE supports up to 8 SPS group-common PDSCH configurations per CFR for multicast on PCell. The value indicates the maximum number of activated SPS group-common PDSCH configurations per CFR for multicast.</p> <p>The total number of SPS configurations for both multicast and unicast is no larger than 8 in a BWP of a serving cell. The total number of SPS configurations for both multicast and unicast in a cell group is no larger than 32.</p> <p>For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE that indicates support of this feature shall indicate support of <i>sps-Multicast-r17</i>.</p>	Band	No	N/A	N/A
<p>sps-r16 Indicates whether the UE support of up to 8 configured SPS configurations in a BWP of a serving cell and up to 32 configured SPS configurations in a cell group. This field includes the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberConfigsPerBWP-r16</i> indicates the maximum number of active SPS configurations in a BWP of a serving cell. - <i>maxNumberConfigsAllCC-r16</i> indicates the maximum number of active SPS configurations across all serving cells in a MAC entity, and across MCG and SCG in case of NR-DC. <p>The UE can include this feature only if the UE indicates support of <i>downlinkSPS</i>.</p> <p>NOTE:</p> <ul style="list-style-type: none"> - For all the reported bands in FR1, a same X1 value is reported for <i>maxNumberConfigsAllCC-r16</i>. For all the reported bands in FR2, a same X2 value is reported for <i>maxNumberConfigsAllCC-r16</i>. - The total number of active SPS configurations across all serving cells in FR1 is no greater than X1. - The total number of active SPS configurations across all serving cells in FR2 is no greater than X2. - If the CA have some serving cell(s) in FR1 and some serving cell(s) in FR2, the total number of active SPS configurations across all serving cells is no greater than max(X1, X2). 	Band	No	N/A	N/A

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>srs-AssocCSI-RS</i> Parameters for the calculation of the precoder for SRS transmission based on channel measurements using associated NZP CSI-RS resource (<i>srs-AssocCSI-RS</i>) as described in clause 6.1.1.2 of TS 38.214 [12]. UE supporting this feature shall also indicate support of non-codebook based PUSCH transmission. This capability signalling includes list of the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource; - <i>maxNumberResourcesPerBand</i> indicates the maximum number of resources across all CCs within a band simultaneously; - <i>totalNumberTxPortsPerBand</i> indicates the total number of Tx ports across all CCs within a band simultaneously. 	Band	No	N/A	N/A
<p><i>srs-combEight-r17</i> Indicates whether the UE supports comb-8 for SRS other than for positioning.</p>	Band	No	N/A	N/A
<p><i>srs-increasedRepetition-r17</i> Indicates whether the UE supports increased repetition patterns (8, 10, 12, 14 symbols) for SRS resource.</p> <p>The UE supporting this feature shall also indicate the support of <i>srs-StartAnyOFDM-Symbol-r16</i>.</p>	Band	No	N/A	N/A
<p><i>srs-partialFreqSounding-r17</i> Indicates the support of partial frequency sounding for SRS for non-frequency hopping case.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>srs-partialFrequencySounding-r17</i>.</p>	Band	No	N/A	N/A
<p><i>srs-partialFrequencySounding-r17</i> Indicates whether the UE supports partial frequency sounding for SRS with frequency hopping.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>srs-PosResourcesRRC-Inactive-r17 Indicates support of positioning SRS transmission in RRC_INACTIVE for initial UL BWP. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberSRS-PosResourceSetPerBWP-r17</i> Indicates the max number of SRS Resource Sets for positioning supported by UE; - <i>maxNumberSRS-PosResourcesPerBWP-r17</i> indicates the max number of P/SP SRS Resources for positioning; - <i>maxNumberSRS-ResourcesPerBWP-PerSlot-r17</i> indicates the max number of P/SP SRS Resources for positioning per slot; - <i>maxNumberPeriodicSRS-PosResourcesPerBWP-r17</i> indicates the max number of periodic SRS Resources for positioning; - <i>maxNumberPeriodicSRS-PosResourcesPerBWP-PerSlot-r17</i> indicates the max number of periodic SRS Resources for positioning per slot. <p>NOTE: OLPC for SRS for positioning based on SSB from the last serving cell (the cell that releases UE from connection) is part of this feature. No dedicated capability signalling is intended for this component</p>	Band	No	N/A	N/A
<p>srs-SemiPersistent-PosResourcesRRC-Inactive-r17 Indicates support of positioning SRS transmission in RRC_INACTIVE for initial UL BWP with semi-persistent SRS. UE indicating support of this feature shall indicate support of <i>srs-PosResourcesRRC-Inactive-r17</i>.</p> <p>The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumOfSemiPersistentSRSpSResources-r17</i> indicates the max number of semi-persistent SRS Resources for positioning; - <i>maxNumOfSemiPersistentSRSpSResourcesPerSlot-r17</i> indicates the max number of semi-persistent SRS Resources for positioning per slot. 	Band	No	N/A	N/A
<p>srs-PortReport-r17 Indicates the maximum number of SRS ports for each UE reported quantity in <i>reportQuantity-r17</i>.</p>	Band	No	N/A	N/A
<p>srs-PortReportSP-AP-r17 Indicates that the UE supports the maximum number of SRS ports with semi-persistent/aperiodic capability value reporting. The UE supporting this feature shall also indicate support of <i>srs-PortReport-r17</i> and one of <i>aperiodicBeamReport</i>, <i>sp-BeamReportPUCCH</i>, <i>sp-BeamReportPUSCH</i>, <i>ssb-csirs-SINR-measurement-r16</i>, <i>semi-PersistentL1-SINR-Report-PUCCH-r16</i> or <i>semi-PersistentL1-SINR-Report-PUSCH-r16</i>.</p>	Band	No	N/A	N/A
<p>srs-startRB-locationHoppingPartial-r17 Indicates whether the UE supports start RB location hopping in partial frequency SRS transmission across different SRS frequency hopping periods for periodic/semi-persistent/aperiodic SRS.</p> <p>The UE supporting this feature shall also indicate the support of <i>srs-partialFrequencySounding-r17</i>.</p>	Band	No	N/A	N/A

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>srs-TriggeringOffset-r17</i> Indicates the maximum number of configured available slots offsets for determining aperiodic SRS location based on available slot.</p>	Band	No	N/A	N/A
<p><i>srs-TriggeringDCI-r17</i> Indicates whether the UE supports triggering SRS in DCI 0_1/0_2 without data and without CSI.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ssb-csirs-SINR-measurement-r16 Indicates the limitations of the UE support of SSB/CSI-RS for L1-SINR measurement. This capability signalling includes list of the following parameters: Per slot limitations:</p> <ul style="list-style-type: none"> - <i>maxNumberSSB-CSIRS-OneTx-CMR-r16</i> indicates the maximum number of SSB/CSI-RS (1TX) across all CCs within a band for Channel Measurement Report - <i>maxNumberCSI-IM-NZP-IMR-res-r16</i> indicates the maximum number of CSI-IM/NZP-IMR resources across all CCs within a band - <i>maxNumberCSIRS-2Tx-res-r16</i> indicates the maximum number of CSI-RS (2TX) resources across all CCs within a band for Channel Measurement Report <p>Memory limitations:</p> <ul style="list-style-type: none"> - <i>maxNumberSSB-CSIRS-res-r16</i> indicates the max number of SSB/CSI-RS resources across all CCs within a band as Channel Measurement Report - <i>maxNumberCSI-IM-NZP-IMR-res-mem-r16</i> indicates the maximum number of CSI-IM/NZP-IMR resources across all CCs within a band <p>Other limitations:</p> <ul style="list-style-type: none"> - <i>supportedCSI-RS-Density-CMR-r16</i> indicates supported density of CSI-RS for Channel Measurement Report. - <i>maxNumberAperiodicCSI-RS-Res-r16</i> indicates the maximum number of aperiodic CSI-RS resources across all CCs within a band configured to measure L1-SINR (including CMR and IMR) - <i>supportedSINR-meas</i> indicates the supported SINR measurements. <ul style="list-style-type: none"> - <i>supportedSINR-meas-r16</i> contains values {<i>ssbWithCSI-IM</i>, <i>ssbWithNZP-IMR</i>, <i>csirsWithNZP-IMR</i>, <i>csi-RSWithoutIMR</i>} representing {SSB as CMR with dedicated CSI-IM, SSB as CMR with dedicated NZP IMR, CSI-RS as CMR with dedicated NZP IMR configured, CSI-RS as CMR without dedicated IMR configured}. - <i>supportedSINR-meas-v1670</i> indicates a 4-bit bitmap {<i>ssbWithCSI-IM</i>, <i>ssbWithNZP-IMR</i>, <i>csirsWithNZP-IMR</i>, <i>csi-RSWithoutIMR</i>}, where the leftmost bit corresponds to <i>ssbWithCSI-IM</i>, the next bit corresponds to <i>ssbWithNZP-IMR</i> and so on. UE indicating <i>supportedSINR-meas-v1670</i> shall always indicate <i>supportedSINR-meas-r16</i>. <p>UE supporting this feature shall also indicate support of CSI-RS as CMR with dedicated CSI-IM. UE indicating support of this feature shall also indicate support of <i>periodicBeamReport</i> and <i>aperiodicBeamReport</i> or <i>sp-BeamReportPUCCH</i> and <i>sp-BeamReportPUSCH</i>. UE indicating support of <i>ssb-csirs-SINR-measurement-r16</i> shall support periodic and aperiodic L1-SINR report.</p> <p>NOTE 1: The reference slot duration is the shortest slot duration defined for the frequency range where the reported band belongs.</p> <p>NOTE 2: For <i>maxNumberSSB-CSIRS-res-r16</i> and <i>maxNumberCSI-IM-NZP-IMR-res-mem-r16</i> the configured CSI-RS resources for both active and inactive BWPs are counted.</p> <p>NOTE 3: For <i>maxNumberSSB-CSIRS-OneTx-CMR-r16</i>, <i>maxNumberCSI-IM-NZP-IMR-res-r16</i> and <i>maxNumberCSIRS-2Tx-res-r16</i>, CSI-RS resources configured as CMR without dedicated IMR are counted both as CMR and IMR.</p> <p>NOTE 4: For <i>maxNumberSSB-CSIRS-OneTx-CMR-r16</i>, <i>maxNumberCSI-IM-NZP-IMR-res-r16</i>, <i>maxNumberCSIRS-2Tx-res-r16</i>, <i>maxNumberAperiodicCSI-RS-Res-r16</i>, a SSB/CSI-RS resource is counted within the duration of a</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>sssg-Switching-1BitInd-r17 Indicates whether the UE supports 1-bit indication of SSSG switching between 2 SSSGs by scheduling DCI, and timer based SSSG switching, if <i>pdcc-SkippingDurationList</i> is not configured as specified in TS 38.213 [11], clause 10.4. UE supports search space set group switching capability-1 according to Table 10.4-1 of TS 38.213 [11].</p>	Band	No	N/A	N/A
<p>sssg-Switching-2BitInd-r17 Indicates whether the UE supports 2-bit indication of SSSG switching among 3 SSSGs by scheduling DCI and timer based SSSG switching, if <i>pdcc-SkippingDurationList</i> is not configured as specified in TS 38.213 [11], clause 10.4. UE supports search space set group switching capability-1 according to Table 10.4-1 of TS 38.213 [11].</p> <p>UE indicating support of this feature shall also indicate support of <i>sssg-Switching-1bitInd-r17</i>.</p>	Band	No	N/A	N/A
<p>support64CandidateBeamRS-BFR-r16 Indicates UE support of configuring maximum 64 candidate beam RSs per BWP per CC. UE indicating support of this feature shall also indicate support of <i>maxNumberCSI-RS-BFD</i>, <i>maxNumberSSB-BFD</i> and <i>maxNumberCSI-RS-SSB-CBD</i>.</p>	Band	No	N/A	N/A
<p>supportCodeWordSoftCombining-r16 Indicates whether UE supports codeword soft combining for FDMSchemeB. UE indicates support of this feature depends on whether the <i>supportFDM-SchemeB-r16</i> is also supported.</p>	Band	No	N/A	N/A
<p>supportFDM-SchemeA-r16 Indicates whether UE supports single DCI based FDMSchemeA.</p>	Band	No	N/A	N/A
<p>supportInter-slotTDM-r16 Indicates whether UE supports single-DCI based inter-slot TDM. This capability signalling includes the following:</p> <ul style="list-style-type: none"> - <i>supportRepNumPDSCH-TDRA-r16</i> indicates support of RepNumR16 in PDSCH-TimeDomainResourceAllocation and the maximum value of RepNumR16 - <i>maxTBS-Size-r16</i> indicates maximum TBS size. - <i>maxNumberTCI-states-r16</i> indicates the maximum number of TCI states. 	Band	No	N/A	N/A
<p>supportNewDMRS-Port-r16 Indicates whether UE supports new DMRS port entry {0,2,3}. UE supports this feature should indicate support <i>singleDCI-SDM-scheme-r16</i> for the band.</p>	Band	No	N/A	N/A
<p>supportRepNumPDSCH-TDRA-DCI-1-2-r17 Indicates support of <i>repetitionNumber-v1730</i> in <i>PDSCH-TimeDomainResourceAllocation</i> for DCI format 1_2 and the maximum value of <i>repetitionNumber-v1730</i>.</p>	Band	No	N/A	N/A
<p>supportTDM-SchemeA-r16 Indicates whether UE supports single DCI based TDMSchemeA. The capability signalling includes the maximum TBS size.</p>	Band	No	N/A	N/A
<p>supportTwoPortDL-PTRS-r16 Indicates whether UE supports 2-port DL PT-RS. UE supports this feature should indicate support <i>singleDCI-SDM-scheme-r16</i> for the band.</p>	Band	No	N/A	N/A
<p>ta-BasedPDC-NTN-SharedSpectrumChAccess-r17 Indicates whether the UE supports propagation delay compensation based on legacy TA procedure for NTN and shared spectrum channel access.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>tb-ProcessingMultiSlotPUSCH-r17 Indicates whether UE supports TB processing over multi-slot PUSCH for DG and Type 2 CG without repetition in RRC connected mode.</p>	Band	No	N/A	N/A
<p>tb-ProcessingRepMultiSlotPUSCH-r17 Indicates whether UE supports repetition of TB processing over multi-slot PUSCH in RRC connected mode.</p> <p>UE supporting this feature shall also indicate support of <i>tb-ProcessingMultiSlotPUSCH-r17</i>.</p>	Band	No	N/A	N/A
<p>tcI-StatePDSCH Defines support of TCI-States for PDSCH. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberConfiguredTCIstatesPerCC</i> indicates the maximum number of configured TCI-states per CC for PDSCH. For FR2, the UE is mandated to set the value at least to 64 (i.e. value 128 is an optional value). For FR1, the UE is mandated to set these values at least to the maximum number of allowed SSBs in the supported band; - <i>maxNumberActiveTCI-PerBWP</i> indicates the maximum number of activated TCI-states per BWP per CC, including control and data. If a UE reports X active TCI state(s), it is not expected that more than X active QCL type D assumption(s) for any PDSCH and any CORESETs for a given BWP of a serving cell become active for the UE. The UE shall include this field. <p>Note the UE is required to track only the active TCI states.</p> <p>The UE is mandated to report <i>tcI-StatePDSCH</i>.</p>	Band	Yes	N/A	N/A
<p>timeBasedCondHandover-r17 Indicates whether the UE supports time based conditional handover, i.e., <i>CondEvent T1</i> as specified in TS 38.331 [9]. A UE supporting this feature shall also indicate the support of <i>condHandover-r16</i> for NTN bands and the support of <i>nonTerrestrialNetwork-r17</i>. UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p>	Band	No	N/A	N/A
<p>triggeredHARQ-CodebookRetx-r17 Indicates whether the UE supports triggered HARQ-ACK codebook re-transmission from an earlier PUCCH slot based on the triggering information in DCI format 1_1 and DCI format 1_2 (for a UE supporting DCI format 1_2 as indicated in <i>dci-Format1-2And0-2-r16</i>) and support the related PHY priority handling in terms of HARQ-ACK codebook selection and the applicable PUCCH configuration (for a UE supporting two HARQ-ACK codebooks / PUCCH config as indicated in <i>twoHARQ-ACK-Codebook-type1-r16</i>). The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>minHARQ-Retx-Offset-r17</i> indicates minimum value for the HARQ re-tx offset. Value <i>n-7</i> corresponds to -7, value <i>n-5</i> corresponds to -5, and so on. - <i>maxHARQ-Retx-Offset-r17</i> indicates maximum value for the HARQ re-tx offset. <p>NOTE: The minimum requirement for <i>minHARQ-Retx-Offset-r17</i> and <i>maxHARQ-Retx-Offset-r17</i> is valid for HARQ CBs consisted of HARQ Processes with a single HARQ bit per HARQ Process ID.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>trs-AdditionalBandwidth-r16 Indicates the UE supported TRS bandwidths, in addition to 52 RBs, for a 10MHz UE channel bandwidth. This field only applies for the BWPs configured with 52 RBs size and 15kHz SCS, in FDD bands. Value <i>trs-AddBW-Set1</i> indicates 28, 32, 36, 40, 44, 48 RBs. Value <i>trs-AddBW-Set2</i> indicates 32, 36, 40, 44, 48 RBs.</p>	Band	No	FDD only	FR1 only
<p>twoHARQ-ACK-CodebookForUnicastAndMulticast-r17 Indicates whether the UE supports two HARQ-ACK codebooks simultaneously constructed for supporting HARQ-ACK codebooks with different priorities for unicast and multicast at a UE.</p> <p>For TN, the UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands, associated with supported shared and non-shared spectrum respectively. For NTN, UE shall set the capability value consistently for all FDD-FR1 NTN bands.</p> <p>A UE supporting this feature shall also indicate support of <i>priorityIndicatorInDCI-Multicast-r17</i>.</p>	Band	No	N/A	N/A
<p>twoPortsPTRS-UL Defines whether UE supports PT-RS with 2 antenna ports for UL transmission.</p>	Band	No	N/A	N/A
<p>type1-HARQ-Codebook-r17 Indicates whether the UE supports Type-1 HARQ codebook enhancements when there are feedback-disabled HARQ processes. UE indicating support of this feature shall also indicate support of <i>harq-FeedbackDisabled-r17</i>. This field is only applicable for bands in Table 5.2.2-1 in TS 38.101-5 [34] and HAPS operation bands in clause 5.2 of TS 38.104 [35].</p>	Band	No	N/A	N/A
<p>type2-HARQ-Codebook-r17 Indicates whether the UE supports Type-2 HARQ codebook enhancements when there are feedback-disabled HARQ processes. UE indicating support of this feature shall also indicate support of <i>harq-FeedbackDisabled-r17</i>. This field is only applicable for bands in Table 5.2.2-1 in TS 38.101-5 [34] and HAPS operation bands in clause 5.2 of TS 38.104 [35].</p>	Band	No	N/A	N/A
<p>type1-PUSCH-RepetitionMultiSlots-v1650 Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one. This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>type1-PUSCH-RepetitionMultiSlots-r16</i> applies. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>The UE only includes <i>type1-PUSCH-RepetitionMultiSlots-v1650</i> if <i>type1-PUSCH-RepetitionMultiSlots</i> is absent</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>type2-PUSCH-RepetitionMultiSlots-v1650 Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one. This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>type2-PUSCH-RepetitionMultiSlots-r16</i> applies. UE shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands, all TDD-FR2-1 bands and all TDD-FR2-2 bands respectively.</p> <p>The UE only includes <i>type2-PUSCH-RepetitionMultiSlots-v1650</i> if <i>type2-PUSCH-RepetitionMultiSlots</i> is absent</p>	Band	No	N/A	N/A
<p>type3-HARQ-Codebook-r17 Indicates whether the UE supports Type-3 HARQ codebook enhancements when there are feedback-disabled HARQ processes. UE indicating support of this feature shall also indicate support of <i>harq-FeedbackDisabled-r17</i>. This field is only applicable for bands in Table 5.2.2-1 in TS 38.101-5 [34] and HAPS operation bands in clause 5.2 of TS 38.104 [35].</p>	Band	No	N/A	N/A
<p>txDiversity-r16 Indicates whether the UE supports transparent Tx diversity requirements as specified in the suffix G clauses of TS 38.101-1 [2] (see also clauses 4.2 and 4.3 of TS38.101-1 [2]).</p>	Band	No	N/A	FR1 only
<p>ue-OneShotUL-TimingAdj-r17 Indicates whether the UE supports one shot large UL timing adjustment.</p> <p>UE indicating support of this feature shall indicate support of <i>ue-PowerClass-v1700</i> set to 'pc6'.</p>	Band	No	N/A	FR2 only
<p>ue-PowerClass, ue-PowerClass-v1610, ue-PowerClass-v1700 For FR1, if the UE supports the different UE power class than the default UE power class as defined in clause 6.2 of TS 38.101-1 [2], or in clause 6.2 of TS 38.101-5 [34], the UE shall report the supported UE power class in this field. For FR2, UE shall report the supported UE power class as defined in clause 6 and 7 of TS 38.101-2 [3] in this field. UE indicating support for <i>pc6</i> supports the enhanced intra-NR RRM and demodulation processing requirements for FR2 to support high speed up to 350 km/h as specified in TS 38.133 [5]. This capability is not applicable to IAB-MT. The power class <i>pc7</i> is only applicable for RedCap UEs operation in FR2.</p>	Band	Yes	N/A	N/A
<p>ue-specific-K-Offset-r17 Indicates whether the UE supports the reception of UE-specific K_offset comprised of the following functional components:</p> <ul style="list-style-type: none"> - Support of reception of UE-specific K_offset via MAC-CE - Support of determining the timing of PUSCH, PUCCH, CSI reference resource, transmission of aperiodic SRS, activation of TA command, first PUSCH transmission in CG Type 2 with UE-specific Koffset <p>UE indicating support of this feature shall also indicate support of <i>uplinkPreCompensation-r17</i> and <i>uplink-TA-Reporting-r17</i> for this band. This field is only applicable for bands in Table 5.2.2-1 in TS 38.101-5 [34] and HAPS operation bands in clause 5.2 of TS 38.104 [35].</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ul-GapFR2-r17 Indicates whether the UE supports FR2 UL gap to perform BPS sensing for Tx power management by the use of uplink gap patterns as specified in TS 38.133 [5] if UE supports a band in FR2.</p>	Band	No	No	FR2 only
<p>unifiedJointTCI-BeamAlignDLRS-r17 Indicates the support of beam misalignment between the DL source RS in the TCI state to provide spatial relation indication and the PL-RS. The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>.</p>	Band	No	N/A	FR2 only
<p>unifiedJointTCI-commonMultiCC-r17 Indicates the support of common multi-CC TCI state ID update and activation. The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>.</p>	Band	No	N/A	N/A
<p>unifiedJointTCI-InterCell-r17 Indicates the support of Unified TCI with joint DL/UL TCI update for inter-cell beam management including following parameters:</p> <ul style="list-style-type: none"> - <i>additionalMAC-CE-PerCC-r17</i> indicates the number of K additional MAC-CEs to indicate joint TCI states per CC in a band. - <i>additionalMAC-CE-AcrossCC-r17</i> indicates the number of K additional MAC-CE activated joint TCI states across all CC(s) in a band. <p>A UE indicating support of this shall also indicate support of <i>unifiedJointTCI-r17</i> and <i>unifiedJointTCI-mTRP-InterCell-BM-r17</i>.</p> <p>NOTE: A UE that supports <i>unifiedJointTCI-InterCell-r17</i> supports K additional MAC-CE activated joint TCI states across all CC(s) in a band in addition to the maximum number of MAC-CE activated joint TCI states across all CC(s) in a band signalled in <i>unifiedJointTCI-r17</i>. The signalled value in <i>additionalMAC-CE-AcrossCC-r17</i> plus the signalled value in <i>maxActivatedTCIAcrossCC-r17</i> determine the maximum number of MAC-CE activated joint TCI states across all CC(s) in a band that are applied to intra and inter-cell beam management jointly.</p>	Band	No	N/A	N/A
<p>unifiedJointTCI-Legacy-CORESET0-r17 Indicates the support of indication/configuration of R17 TCI states for CORESET #0 and the respective PDSCH reception reusing the Rel-15/16 signalling/configuration design(s). The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>.</p>	Band	No	N/A	N/A
<p>unifiedJointTCI-Legacy-SRS-r17 Indicates the support of indication/configuration of R17 TCI states for SRS (except for periodic/semi-persistent SRS for BM) reusing the Rel-15/16 signalling/configuration design(s). The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>.</p>	Band	No	N/A	N/A
<p>unifiedJointTCI-Legacy-r17 Indicates the support of indication/configuration of R17 TCI states for aperiodic CSI-RS, PDCCH, PDSCH (except for TRS and for CORESET #0 and the respective PDSCH reception) reusing the Rel-15/16 signalling/configuration design(s). The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p>unifiedJointTCI-ListSharingCA-r17 Indicates the support of reference BWP/serving cell index to indicate reference TCI state list shared by multiple BWPs/serving cells. The value indicates the maximum number of configured joint TCI state lists across all BWPs and all Serving cells in a band.</p> <p>The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>. A UE that supports CA and <i>unifiedJointTCI-r17</i> shall indicate support of this feature.</p>	Band	No	N/A	N/A
<p>unifiedJointTCI-mTRP-InterCell-BM-r17 Indicates the support of inter-cell beam measurement and reporting for inter-cell BM and mTRP. This feature includes support of L1-RSRP measurement and reporting on SSB(s) with PCI(s) different from serving cell PCI (additional PCI) and support of up to K SSBRI-RSRP pairs in one report where a pair is associated with a PCI different from serving cell PCI can be reported, where K is equal to <i>maxNumberNonGroupBeamReporting</i>.</p> <p>This feature also includes following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumAdditionalPCI-L1-RSRP-r17</i> indicates the maximum number of RRC-configured] PCI(s) different from serving cell PCI for L1-RSRP measurement. - <i>maxNumSSB-ResourceL1-RSRP-AcrossCC-r17</i> indicates the maximum number of SSB resources configured to measure L1-RSRP within a slot with PCI(s) same as or different from serving cell PCI [across all CC]. <p>NOTE: <i>maxNumSSBResource-L1-RSRP-AcrossCC-r17</i> is also counted in <i>maxTotalResourcesForOneFreqRange-r16/</i> <i>maxTotalResourcesForAcrossFreqRanges-r16</i>.</p>	Band	No	N/A	N/A
<p>unifiedJointTCI-multiMAC-CE-r17 Indicates the support of unified TCI state operation with joint DL/UL TCI update for intra- and inter-cell beam management with more than one MAC-CE activated joint TCI state per CC with MAC CE and DCI based TCI state indication in DCI formats 1_1 and 1_2 with and without DL assignment.</p> <p>This capability signalling includes the following parameters:</p> <ul style="list-style-type: none"> - <i>minBeamApplicationTime-r17</i> indicates the minimum beam application time in Y symbols per SCS indicated only for FR2. - <i>maxNumMAC-CE-PerCC-r17</i> indicates the maximum number of MAC-CE activated joint TCI states per CC in a band. <p>The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>.</p> <p>NOTE 1: The maximum number of MAC-CE activated joint TCI states across all CC(s) in a band for more than one MAC-CE activated joint TCI state is signaled in <i>unifiedJointTCI-r17</i>.</p> <p>NOTE 2: Activated joint TCI state(s) include all PDCCH/PDSCH receptions and PUSCH/PUCCH.</p>	Band	No	N/A	N/A
<p>unifiedJointTCI-PC-association-r17 Indicates the support of association between TCI state and UL PC settings except for PL RS for PUCCH, PUSCH, and SRS.</p> <p>The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>.</p>	Band	No	N/A	N/A

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>unifiedJointTCI-perBWP-CA-r17</i> Indicates the support of TCI state list configuration per BWP when CA is configured. The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>.</p>	Band	No	N/A	N/A
<p><i>unifiedJointTCI-r17</i> Indicates the support of unified TCI state operation with joint DL/UL TCI update for intra-cell beam management including the support of:</p> <ul style="list-style-type: none"> - One MAC-CE activated joint TCI state per CC in a band - TCI state indication for update and activation of MAC CE based TCI state indication for one active TCI state <p>The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxConfiguredJointTCI-r17</i> indicates the maximum number of configured joint TCI states per BWP per CC in a band - <i>maxActivatedTCIAcrossCC-r17</i> indicates the maximum number of MAC-CE activated joint TCI states across all CC(s) in a band <p>If a UE supports <i>unifiedJointTCI-InterCell-r17</i>, the signalled component values (except <i>additionalMAC-CE-AcrossCC-r17</i>) also apply to inter-cell beam management,</p> <p>NOTE: Activated joint TCI state(s) include all PDCCH/PDSCH receptions and PUSCH/PUCCH transmissions</p>	Band	No	N/A	N/A
<p><i>unifiedJointTCI-SCellBFR-r17</i> Indicates the support of SCell BFR with unified TCI operation. The maximum number of CCs configured with SCell BFR with unified TCI framework in a band with SpCell BFR is given by <i>maxNumberSCellBFR-r16</i>. The UE supporting this feature assumes that <i>maxNumberSCellBFR-r16</i> includes SpCell.</p>	Band	No	N/A	N/A
<p><i>unifiedSeparateTCI-commonMultiCC-r17</i> Indicates the Common multi-CC DL/UL-TCI state ID update and activation.</p> <p>The UE indicating support of this feature shall also indicate support of <i>unifiedSeparateTCI-r17</i>.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>unifiedSeparateTCI-InterCell-r17</i> Indicates the support of unified TCI with separate DL/UL TCI update for inter-cell beam management with more than one MAC-CE activated separate TCI state per CC.</p> <p>This feature also includes following parameters:</p> <ul style="list-style-type: none"> - <i>k-DL-PerCC-r17</i> indicates the number of additional MAC-CE activated DL TCI states per CC in a band - <i>k-UL-PerCC-r17</i> indicates the number of additional MAC-CE activated UL TCI states per CC in a band - <i>k-DL-AcrossCC-r17</i> indicates the number of additional MAC-CE activated DL TCI states across all CC(s) in a band - <i>k-UL-AcrossCC-r17</i> indicates the number of additional MAC-CE activated UL TCI states across all CC(s) in a band <p>The UE indicating support of this feature shall also indicate support of <i>unifiedSeparateTCI-r17</i>.</p> <p>NOTE: A UE that supports this feature supports K additional MAC-CE activated DL and K additional MAC-CE activated UL TCI states across all CC(s) in a band in addition to the maximum number of MAC-CE activated DL and UL TCI states across all CC(s) in a band signalled in <i>unifiedSeparateTCI-r17</i>. The signalled value in <i>k-DL-AcrossCC-r17</i> (<i>k-UL-AcrossCC-r17</i>) plus the signalled value in <i>maxActivatedDL-TCIAcrossCC-r17</i> (<i>maxActivatedUL-TCIAcrossCC-r17</i>) determine the maximum number of MAC-CE activated DL (UL) TCI states across all CC(s) in a band that are applied to intra and inter-cell beam management jointly.</p>	Band	No	N/A	N/A
<p><i>unifiedSeparateTCI-ListSharingCA-r17</i> Indicates the support of reference BWP/serving cell configured with reference TCI state pool shared by a set of BWPs/serving cells. The value indicates the maximum number of configured DL/UL TCI state pools across all BWPs and all serving cells in a band.</p>	Band	No	N/A	N/A
<p><i>unifiedSeparateTCI-multiMAC-CE-r17</i> Indicates TCI state indication for update and activation a) MAC-CE+DCI-based TCI state indication (use of DCI formats 1_1/1_2 with DL assignment) And b) MAC-CE+DCI-based TCI state indication (use of DCI formats 1_1/1_2 without DL assignment).</p> <p>This capability signalling includes the following parameters:</p> <ul style="list-style-type: none"> - <i>minBeamApplicationTime-r17</i> indicates the minimum beam application time in Y symbols per SCS. - <i>maxActivatedDL-TCIPerCC-r17</i> indicates the maximum number of MAC-CE activated DL TCI states per CC in a band - <i>maxActivatedUL-TCIPerCC-r17</i> indicates the maximum number of MAC-CE activated UL TCI states per CC in a band <p>The UE indicating support of this feature shall also indicate support of <i>unifiedSeparateTCI-r17</i>.</p>	Band	No	N/A	N/A

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>unifiedSeparateTCI-perBWP-CA-r17</i> Indicates the support of DL/UL TCI state pool configuration per BWP for CA mode.</p> <p>The UE indicating support of this feature shall also indicate support of <i>unifiedSeparateTCI-r17</i>.</p>	Band	No	N/A	N/A
<p><i>unifiedSeparateTCI-r17</i> Indicates the support of unified TCI state operation with joint DL/UL TCI update for intra-cell beam management including the support of:</p> <ul style="list-style-type: none"> - One MAC-CE activated DL TCI state per CC in a band - One MAC-CE activated UL TCI state per CC in a band - TCI state indication for update and activation including MAC CE based TCI state indication for one active DL/UL TCI state <p>The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxConfiguredDL-TCI-r17</i> indicates the maximum number of configured DL TCI states per BWP per CC - <i>maxConfiguredUL-TCI-r17</i> indicates the maximum number of configured UL TCI states per BWP per CC - <i>maxActivatedDL-TCIAcrossCC-r17</i> indicates the maximum number of MAC-CE activated DL TCI states across all CC(s) in a band - <i>maxActivatedUL-TCIAcrossCC-r17</i> indicates the maximum number of MAC-CE activated UL TCI states across all CC(s) in a band <p>The UE indicating support of this feature shall also indicate support of <i>unifiedJointTCI-r17</i>. If a UE supports <i>unifiedSeperateTCI-InterCell-r17</i>, the <i>maxConfiguredDL-TCI-r17</i> and <i>maxConfiguredUL-TCI-r17</i> apply to intra- and inter-cell beam management jointly.</p>	Band	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF																		
<p>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A																		
<p>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17 Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A																		
<p>uplinkBeamManagement Defines support of beam management for UL. This capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberSRS-ResourcePerSet-BM</i> indicates the maximum number of SRS resources per SRS resource set configurable for beam management, supported by the UE. - <i>maxNumberSRS-ResourceSet</i> indicates the maximum number of SRS resource sets configurable for beam management, supported by the UE. <p>If the UE does not set <i>beamCorrespondenceWithoutUL-BeamSweeping</i> to <i>supported</i>, the UE shall report this capability. This feature is optional for the UE that supports beam correspondence without uplink beam sweeping as defined in clause 6.6, TS 38.101-2 [3].</p> <p>NOTE: The network uses <i>maxNumberSRS-ResourceSet</i> to determine the maximum number of SRS resource sets that can be configured to the UE for periodic/semi-persistent/aperiodic configurations as below:</p> <table border="1" data-bbox="167 1064 1061 1469"> <thead> <tr> <th data-bbox="167 1064 574 1232">Maximum number of SRS resource sets across all time domain behaviour (periodic/semi-persistent/aperiodic) reported in <i>maxNumberSRS-ResourceSet</i></th> <th data-bbox="574 1064 1061 1232">Additional constraint on the maximum number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic)</th> </tr> </thead> <tbody> <tr><td data-bbox="167 1232 574 1265">1</td><td data-bbox="574 1232 1061 1265">1</td></tr> <tr><td data-bbox="167 1265 574 1299">2</td><td data-bbox="574 1265 1061 1299">1</td></tr> <tr><td data-bbox="167 1299 574 1332">3</td><td data-bbox="574 1299 1061 1332">1</td></tr> <tr><td data-bbox="167 1332 574 1366">4</td><td data-bbox="574 1332 1061 1366">2</td></tr> <tr><td data-bbox="167 1366 574 1400">5</td><td data-bbox="574 1366 1061 1400">2</td></tr> <tr><td data-bbox="167 1400 574 1433">6</td><td data-bbox="574 1400 1061 1433">2</td></tr> <tr><td data-bbox="167 1433 574 1467">7</td><td data-bbox="574 1433 1061 1467">4</td></tr> <tr><td data-bbox="167 1467 574 1500">8</td><td data-bbox="574 1467 1061 1500">4</td></tr> </tbody> </table>	Maximum number of SRS resource sets across all time domain behaviour (periodic/semi-persistent/aperiodic) reported in <i>maxNumberSRS-ResourceSet</i>	Additional constraint on the maximum number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic)	1	1	2	1	3	1	4	2	5	2	6	2	7	4	8	4	Band	No	N/A	FR2 only
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi-persistent/aperiodic) reported in <i>maxNumberSRS-ResourceSet</i>	Additional constraint on the maximum number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic)																					
1	1																					
2	1																					
3	1																					
4	2																					
5	2																					
6	2																					
7	4																					
8	4																					

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>ack-NACK-FeedbackForMulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-RNTI by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForMulticast-r17</i> and <i>dynamicMulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ack-NACK-FeedbackForSPS-MulticastWithDCI-Enabler-r17</i> Indicates whether the UE supports DCI-based enabling/disabling ACK/NACK based HARQ-ACK feedback configured per G-CS-RNTI for multicast by RRC signalling via DCI format 4_2.</p> <p>A UE supporting this feature shall also indicate support of <i>ack-NACK-FeedbackForSPS-Multicast-r17</i> and <i>sps-MulticastDCI-Format4-2-r17</i>.</p>	Band	No	N/A	N/A
<p><i>uplinkPreCompensation-r17</i> Indicates whether the UE supports the uplink time and frequency pre-compensation and timing relationship enhancements comprised of the following functional components:</p> <ul style="list-style-type: none"> - Support of UE specific TA calculation based on its GNSS-acquired position and the serving satellite ephemeris. - Support of common TA calculation according to the parameters provided by the network (UE considers common TA as 0 if the parameters are not provided) - For TA update in RRC_CONNECTED state, support of combination of both open (i.e. UE autonomous TA estimation, and common TA estimation) and closed (i.e., received TA commands) control loops - Support of pre-compensation of the calculated TA in its uplink transmissions - Support of estimating UE-gNB RTT and delaying the start of RAR window by UE-gNB RTT - Support of frequency pre-compensation to counter shift the Doppler experienced on the service link - Support of determining timing of the scheduling of PUSCH, PUCCH and PDCCH ordered PRACH, CSI reference resource, transmission of aperiodic SRS activation of TA command, first PUSCH transmission in CG Type 2 with cell-specific K_offset if indicated - Support of determining timing of the UE action and assumption on a downlink configuration carried by MAC CE command by K_mac if it is indicated and determining the timing of PDCCH monitoring in recovery search space using K_mac during beam failure recovery procedure - Support of UE receiving cell-specific K_offset/K_mac in system information <p>Support of this feature in NTN bands is mandatory for UE supporting <i>nonTerrestrialNetwork-r17</i>. This field is only applicable for bands in Table 5.2.2-1 in TS 38.101-5 [34] and HAPS operation bands in clause 5.2 of TS 38.104 [35].</p>	Band	CY	N/A	N/A
<p><i>uplink-TA-Reporting-r17</i> Indicates whether the UE supports UE reporting of information related to TA pre-compensation as specified in TS 38.321 [8]. UE indicating support of this feature shall also indicate support of <i>uplinkPreCompensation-r17</i> for this band. This field is only applicable for bands in Table 5.2.2-1 in TS 38.101-5 [34] and HAPS operation bands in clause 5.2 of TS 38.104 [35].</p>	Band	No	N/A	N/A

Release 17

4.2.7.2a *SharedSpectrumChAccessParamsPerBand*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
ul-DynamicChAccess-r16 Indicates whether the UE supports UL channel access for dynamic channel access mode. Support of this feature is mandatory if UE supports any of the deployment scenarios A.2, B, C, D and E in Annex B.3 of TS 38.300 [28] with dynamic channel access mode.	Band	CY	N/A	N/A
ul-Semi-StaticChAccess-r16 Indicates whether the UE supports UL channel access for semi-static channel access mode. Support of this feature is mandatory if UE supports any of the deployment scenarios A.2, B, C, D and E in Annex B.3 of TS 38.300 [28] with semi-static channel access mode.	Band	CY	N/A	N/A
ssb-RRM-DynamicChAccess-r16 Indicates whether the UE supports SSB-based RRM for dynamic channel access mode. Support of this feature is mandatory if UE supports any of the deployment scenarios A.1, A.2, B, C, D and E in Annex B.3 of TS 38.300 [28] with dynamic channel access mode.	Band	CY	N/A	N/A
ssb-RRM-Semi-StaticChAccess-r16 Indicates whether the UE supports SSB-based RRM for semi-static channel access mode, when SMTC window is no longer than the fixed frame period. Support of this feature is mandatory if UE supports any of the deployment scenarios A.1, A.2, B, C, D and E in Annex B.3 of TS 38.300 [28] with semi-static channel access mode.	Band	CY	N/A	N/A
mib-Acquisition-r16 Indicates whether the UE supports acquiring MIB on an unlicensed cell for SpCell. Support of this feature is mandatory if UE supports any of the deployment scenarios B, C, D and E in Annex B.3 of TS 38.300 [28].	Band	CY	N/A	N/A
ssb-RLM-DynamicChAccess-r16 Indicates whether the UE supports SSB-based RLM for dynamic channel access mode. Support of this feature is mandatory if UE supports any of the deployment scenarios B, C, D and E in Annex B.3 of TS 38.300 [28] with dynamic channel access mode.	Band	CY	N/A	N/A
ssb-RLM-Semi-StaticChAccess-r16 Indicates whether the UE supports SSB-based RLM for semi-static channel access mode, when discovery burst transmission window is no longer than the fixed frame period. Support of this feature is mandatory if UE supports any of the deployment scenarios B, C, D and E in Annex B.3 of TS 38.300 [28] with semi-static channel access mode.	Band	CY	N/A	N/A
sib1-Acquisition-r16 Indicates whether the UE supports acquiring SIB1 on an unlicensed cell for PCell. Support of this feature is mandatory if UE supports any of the deployment scenarios C and D in Annex B.3 of TS 38.300 [28].	Band	CY	N/A	N/A
extRA-ResponseWindow-r16 Indicates whether the UE supports the configuration of maximum length of RAR window with a value larger than 10ms and up to 40ms by decoding of the 2 LSBs of SFN in the DCI format 1_0 for 4-step RA type. Support of this feature is mandatory if the UE supports any of the deployment scenarios B, C, D and E in Annex B.3 of TS 38.300 [28].	Band	CY	N/A	N/A
ssb-BFD-CBD-dynamicChannelAccess-r16 Indicates whether the UE supports SSB based Beam Failure Detection and Candidate Beam Detection with N_{SSB}^{QCL} for dynamic channel access mode.	Band	No	N/A	N/A
ssb-BFD-CBD-semi-staticChannelAccess-r16 Indicates whether the UE supports SSB based Beam Failure Detection and Candidate Beam Detection with N_{SSB}^{QCL} for semi-static channel access mode.	Band	No	N/A	N/A
csi-RS-BFD-CBD-r16 Indicates whether the UE supports CSI-RS based Beam Failure Detection and Candidate Beam Detection for shared spectrum operation.	Band	No	N/A	N/A
ul-ChannelBW-SCell-10mhz-r16 Indicates whether the UE supports 10 MHz of LBT bandwidth for an SCell. A UE that supports this feature shall also support <i>ul-DynamicChAccess-r16</i> or <i>ul-Semi-StaticChAccess-r16</i> .	Band	No	N/A	N/A
rssi-ChannelOccupancyReporting-r16 Indicates whether the UE supports RSSI measurements and channel occupancy	Band	No	N/A	N/A

Release 17

reporting.				
srs-StartAnyOFDM-Symbol-r16 Indicates whether the UE supports transmitting SRS starting in all symbols (0 to 13) of a slot. This capability is also applicable to a frequency band that does not require shared spectrum access.	Band	No	N/A	N/A
searchSpaceFreqMonitorLocation-r16 Indicates the maximum number of frequency domain locations supported by the UE, for a search space set configuration with <i>freqMonitorLocations-r16</i> .	Band	No	N/A	N/A
coreset-RB-Offset-r16 Indicates whether the UE supports CORESET configuration with <i>rb-Offset-r16</i> . This capability is also applicable to a frequency band that does not require shared spectrum access.	Band	No	N/A	N/A
cgi-Acquisition-r16 Indicates whether the UE supports acquisition of CGI information from a neighbouring NR unlicensed cell in an unlicensed carrier by reading SIB1 of the neighbouring unlicensed cell and reporting the acquired information to the network.	Band	No	N/A	N/A
configuredUL-Tx-r16 Indicates whether the UE supports configuration of enableConfiguredUL-r16 and enable transmission of higher-layer configured UL (SRS, PUCCH, CG-PUSCH, etc) when SFI field in DCI 2_0 is configured but DCI 2_0 is not detected.	Band	No	N/A	N/A
prach-Wideband-r16 Indicates whether the UE supports enhanced PRACH design for operation with shared spectrum channel access by adopting a single long ZC sequence, with ZC sequence = 1151 for 15 kHz and ZC sequence = 571 for 30 kHz.	Band	No	N/A	N/A
dci-AvailableRB-Set-r16 Indicates whether the UE supports monitoring DCI 2_0 to read available RB set indicator.	Band	No	N/A	N/A
dci-ChOccupancyDuration-r16 Indicates whether the UE supports monitoring DCI 2_0 to read COT duration.	Band	No	N/A	N/A
typeB-PDSCH-length-r16 Indicates whether the UE supports 1. Type B PDSCH length {3, 5, 6, 8, 9, 10, 11, 12, 13} without DMRS shift due to CRS collision. This capability is also applicable to a frequency band that does not require shared spectrum access.	Band	No	N/A	N/A
searchSpaceSwitchWithDCI-r16 Indicates whether the UE supports switching between two groups of search space sets with DCI 2_0 monitoring that comprises of the following functional components: <ul style="list-style-type: none"> - Monitor DCI 2_0 with a search space set switching field; - Support switching the search space set group with PDCCH decoding in group 1; - Support a timer to switch back to original search space set group; - Monitor DCI 2_0 for channel occupancy time and use the end of channel occupancy time to switch back to the original search space set group. <p>The UE can switch search space set groups for different cells independently, unless the UE supports <i>jointSearchSpaceSwitchAcrossCells-r16</i>. The UE supports search space set group switching capability-1: P=25/25/25 symbols for $\mu=0/1/2$, unless the UE supports <i>searchSpaceSwitchCapability2-r16</i>. The UE supports search space switching triggers to be configured for up to 4 cells or 4 cell groups.</p>	Band	No	N/A	N/A
extendedSearchSpaceSwitchWithDCI-r16 Indicates whether the UE supports search space switching triggers to be individually configured for up to 16 cells. UE indicating support of this feature shall indicate support of <i>searchSpaceSwitchWithDCI-r16</i> .	Band	No	N/A	N/A
searchSpaceSwitchWithoutDCI-r16 Indicates whether the UE supports switching between two groups of search space sets without DCI 2_0 monitoring (i.e. implicit PDCCH decoding) that comprises of the following functional components: <ul style="list-style-type: none"> - Support switching the search space set group with PDCCH decoding in group 1; - Support a timer to switch back to original search space set group. <p>The UE can switch search space set groups for different cells independently, unless the UE supports <i>jointSearchSpaceSwitchAcrossCells-r16</i>. The UE supports search space set group switching capability-1: P=25/25/25 symbols for $\mu=0/1/2$, unless the UE supports <i>searchSpaceSwitchCapability2-r16</i>.</p>	Band	No	N/A	N/A
searchSpaceSwitchCapability2-r16	Band	No	N/A	N/A

Release 17

Indicates whether the UE supports search space set group switching Capability-2: P=10/12/22 symbols for $\mu = 0/1/2$ SCS. If the UE supports this feature, the UE needs to report <i>searchSpaceSwitchWithDCI-r16</i> or <i>searchSpaceSwitchWithoutDCI-r16</i> .				
non-numericalPDSCH-HARQ-timing-r16 Indicates whether the UE supports configuration of a value for <i>dl-DataToUL-ACK-r16</i> indicating an inapplicable time to report HARQ ACK.	Band	No	N/A	N/A
enhancedDynamicHARQ-codebook-r16 Indicates whether the UE supports enhanced dynamic HARQ codebook supporting grouping of HARQ ACK and triggering the retransmission of HARQ ACK in each group. The enhanced dynamic HARQ codebook comprises of the following functional components: <ul style="list-style-type: none"> - Support of bit fields signalling PDSCH HARQ group index and NFI in DCI 1_1 (configuration of <i>nfi-TotalDAI-Included</i>); - Support of bit field in DCI 0_1 for other group total DAI if configured. (configuration of <i>ul-TotalDAI-Included</i>); - Support the retransmission of HARQ ACK (<i>pdsch-HARQ-ACK-Codebook = enhancedDynamic-r16</i>). <p>This capability is also applicable to a frequency band that does not require shared spectrum access.</p>	Band	No	N/A	N/A
oneShotHARQ-feedback-r16 Indicates whether the UE supports one shot HARQ ACK feedback comprised of the following functional components: <ul style="list-style-type: none"> - Support feedback of type 3 HARQ-ACK codebook, triggered by a DCI 1_1 scheduling a PDSCH; - Support feedback of type 3 HARQ-ACK codebook, triggered by a DCI 1_1 without scheduling a PDSCH using a reserved FDRA value. <p>This capability is also applicable to a frequency band that does not require shared spectrum access.</p>	Band	No	N/A	N/A
multiPUSCH-UL-grant-r16 Indicates whether the UE supports scheduling up to 8 PUSCH with a single DCI 0_1. This capability is also applicable to a frequency band that does not require shared spectrum access.	Band	No	N/A	N/A
csi-RS-RLM-r16 Indicates whether the UE supports CSI-RS based RLM for NR-Unlicensed.	Band	No	N/A	N/A
csi-RSRP-AndRSRQ-MeasWithSSB-r16 Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured with an associated SS/PBCH in shared spectrum channel access.	Band	No	N/A	N/A
csi-RSRP-AndRSRQ-MeasWithoutSSB-r16 Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that transmits SS/PBCH block and without an associated SS/PBCH block in shared spectrum channel access.	Band	No	N/A	N/A
csi-SINR-Meas-r16 Indicates whether the UE can perform CSI-SINR measurements based on configured CSI-RS resources as specified in TS 38.215 [13] in shared spectrum channel access. If the UE supports this feature, the UE needs to report <i>maxNumberCSI-RS-RRM-RS-SINR</i> . UE indicating support of this feature shall indicate support of <i>csi-RSRP-AndRSRQ-MeasWithSSB-r16</i> .	Band	No	N/A	N/A
ssb-AndCSI-RS-RLM-r16 Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block and CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5] in shared spectrum channel access. If the UE supports this feature, the UE needs to report <i>maxNumberResource-CSI-RS-RLM</i> . UE indicating support of this feature shall indicate support of <i>csi-RS-RLM-r16</i> and either <i>ssb-RLM-DynamicChAccess-r16</i> or <i>ssb-RLM-Semi-StaticChAccess-r16</i> .	Band	No	N/A	N/A
csi-RS-CFRA-ForHO-r16 Indicates whether the UE can perform reconfiguration with sync using a contention free random access with 4-step RA type on PRACH resources that are associated with CSI-RS resources of the target cell in shared spectrum channel access. UE indicating support of this feature shall indicate support of either <i>csi-RSRP-</i>	Band	No	N/A	N/A

Release 17

<i>AndRSRQ-MeasWithSSB-r16</i> or <i>csi-RSRP-AndRSRQ-MeasWithoutSSB-r16</i> .				
periodicAndSemi-PersistentCSI-RS-r16 Indicates whether the UE supports validating P/SP-CSI-RS reception when receiving a DCI granting a PDSCH over the same set of symbols, and when receiving a DCI triggering an A-CSI-RS over the same set of symbols.	Band	No	N/A	N/A
pusch-PRB-interlace-r16 Indicates whether the UE supports PRB interlace frequency domain resource allocation for PUSCH.	Band	No	N/A	N/A
pucch-F0-F1-PRB-Interlace-r16 Indicates whether the UE supports PRB interlace frequency domain resource allocation for PUCCH format 0, 1, 2 and 3.	Band	No	N/A	N/A
occ-PRB-PF2-PF3-r16 Indicates whether the UE supports OCC for PRB interface mapping for PUCCH format 2 and 3. If the UE supports this feature, the UE needs to report <i>pucch-F0-F1-PRB-Interlace-r16</i> .	Band	No	N/A	N/A
extCP-rangeCG-PUSCH-r16 Indicates whether the UE supports generating a CP extension of length longer than 1 symbol for Configured Grant PUSCH transmission. If the UE supports this feature, the UE needs to report <i>configuredUL-GrantType1</i> or <i>configuredUL-GrantType1-v1650</i> and/or <i>configuredUL-GrantType2</i> or <i>configuredUL-GrantType2-v1650</i> .	Band	No	N/A	N/A
configuredGrantWithReTx-r16 Indicates whether the UE supports configured grant with retransmission in configured grant resource, comprised of retransmission timer, DFI monitoring and CG-UCI in CG-PUSCH. If the UE supports this feature, the UE needs to report <i>configuredUL-GrantType1</i> or <i>configuredUL-GrantType1-v1650</i> and/or <i>configuredUL-GrantType2</i> or <i>configuredUL-GrantType2-v1650</i> .	Band	No	N/A	N/A
ed-Threshold-r16 Indicates whether the UE supports using ED threshold given by gNB for UL to DL COT sharing. A UE that supports this feature shall also support <i>ul-DynamicChAccess-r16</i> .	Band	No	N/A	N/A
ul-DL-COT-Sharing-r16 Indicates whether the UE supports UL to DL COT sharing. A UE that supports this feature shall also support <i>ul-DynamicChAccess-r16</i> .	Band	No	N/A	N/A
mux-CG-UCI-HARQ-ACK-r16 Indicates whether the UE supports multiplexing CG-UCI with HARQ ACK. If the UE supports this feature, the UE needs to report <i>configuredGrantWithReTx-r16</i> .	Band	No	N/A	N/A
cg-resourceConfig-r16 Indicates whether the UE supports configuration of resources with <i>cg-nrofSlots-r16</i> and <i>cg-nrofPUSCH-InSlot-r16</i> . If the UE supports this feature, the UE needs to report <i>configuredUL-GrantType1</i> or <i>configuredUL-GrantType1-v1650</i> and/or <i>configuredUL-GrantType2</i> or <i>configuredUL-GrantType2-v1650</i> .	Band	No	N/A	N/A
dl-ReceptionLBT-subsetRB-r16 Indicates whether the UE supports reception in a wideband carrier when LBT is successful in a subset of the configured RB sets, which are either contiguous or non-contiguous, of the carrier.	Band	No	N/A	N/A
dl-ReceptionIntraCellGuardband-r16 Indicates whether the UE supports reception in the non-zero intra-cell guardband between contiguous RB sets in DL wideband carrier operation wider than 20MHz when LBT is successful only in a subset of RB sets. The UE indicates support of this capability shall also indicate support of <i>dl-ReceptionLBT-subsetRB-r16</i> .	Band	No	N/A	N/A
ul-Semi-StaticChAccessDependentConfig-r17 Indicates whether the UE supports initiating a semi-static channel occupancy with configurations dependent on gNB semi-static channel access configurations, comprised of the following functional components: <ul style="list-style-type: none"> - Support initiating a semi-static channel access occupancy by the UE where the corresponding period is the same as, integer multiple of, or inter-factor of the period configured for a semi-static channel occupancy that can be initiated by gNB; - Sensing to initiate a semi-static CO or transmit after a gap greater than 16us from any transmission burst within a UE-initiated CO; - Determination of COT initiator assumption based on rules for configured UL; - Validating COT initiator assumption indicated in UL scheduling DCI. A UE supporting this feature shall also indicate support of <i>ul-Semi-StaticChAccess-r16</i> .	Band	No	N/A	N/A
ul-Semi-StaticChAccessIndependentConfig-r17 Indicates whether the UE supports initiating a semi-static channel access occupancy by the UE where the corresponding period is independently configured from the period configured for a semi-static channel occupancy that can be initiated	Band	No	N/A	N/A

Release 17

by gNB. A UE supporting this feature shall also indicate support of <i>ul-Semi-StaticChAccess-r16</i> and <i>ul-Semi-StaticChAccessDependentConfig-r17</i> .				
--	--	--	--	--

Release 17

4.2.7.2b *FR2-2-AccessParamsPerBand*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>dl-FR2-2-SCS-120kHz-r17 Indicates whether the UE supports reception of 120kHz subcarrier spacing for DL data and control channels, SSB, and reference signals in FR2-2 for non-initial access.</p> <p>It is mandatory for UE supporting at least one FR2-2 frequency band.</p>	Band	CY	N/A	N/A
<p>dl-FR2-2-SCS-480kHz-r17 Indicates whether the UE supports the following:</p> <ul style="list-style-type: none"> - Reception of 480kHz subcarrier spacing for DL data and control channels, SSB, and reference signals in FR2-2 for non-initial access. - Multiple-slot PDCCH monitoring for 480kHz with $(X_s, Y_s) = (4, 1)$ - Multi-PDSCH scheduling by single DCI for the operation with 480 kHz SCS and corresponding HARQ enhancements. - Within the $Y_s = 1$ slot (with $X_s=4$), monitoring of type 1 CSS with dedicated RRC configuration, type 3 CSS, and UE-SS with a maximum of two monitoring spans per slot with a span duration of Y symbols and a minimum gap of X symbols between the start of two spans, where $(X, Y) = (4, 3)$ and $(7, 3)$ are supported. - Processing one unicast DCI scheduling DL and one unicast DCI scheduling UL per slot group of X_s slots per scheduled CC for FDD. - Processing one unicast DCI scheduling DL and 2 unicast DCI scheduling UL per slot group of X_s slots per scheduled CC for TDD. - For type 1 CSS without dedicated RRC configuration and for type 0, 0A, and 2 CSS, the configured monitoring occasion(s) can be any OFDM symbol(s) of any slot(s) of the slot group, and the actual monitoring occasions for any one of Type 1- CSS without dedicated RRC configuration, or Types 0, 0A, or 2 CSS is within a single span of three consecutive OFDM symbols within a single slot of the slot group. <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p>dl-FR2-2-SCS-960kHz-r17 Indicates whether the UE supports the following:</p> <ul style="list-style-type: none"> - Reception of 960kHz subcarrier spacing for DL data and control channels, SSB, and reference signals in FR2-2 for non-initial access. - Multiple-slot PDCCH monitoring for 960kHz with $(X_s, Y_s) = (8, 1)$. - Multi-PDSCH scheduling by single DCI for the operation with 960 kHz SCS and corresponding HARQ enhancements. - Within the $Y_s = 1$ slot (with $X_s=8$), monitoring of type 1 CSS with dedicated RRC configuration, type 3 CSS, and UE-SS with a maximum of two monitoring spans per slot with a span duration of Y symbols and a minimum gap of X symbols between the start of two spans, where $(X, Y) = (7, 3)$ is supported. - Processing one unicast DCI scheduling DL and one unicast DCI scheduling UL per slot group of X_s slots per scheduled CC for FDD. - Processing one unicast DCI scheduling DL and 2 unicast DCI scheduling UL per slot group of X_s slots per scheduled CC for TDD. - For type 1 CSS without dedicated RRC configuration and for type 0, 0A, and 2 CSS, the configured monitoring occasion(s) can be any OFDM symbol(s) of any slot(s) of the slot group, and the actual monitoring occasions for any one of Type 1- CSS without dedicated RRC configuration, or Types 0, 0A, or 2 CSS is within a single span of three consecutive OFDM symbols within a single slot of the slot group. <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p>enhancedPDCCH-monitoringSCS-480kHz-r17 Indicates whether the UE supports multiple-slot PDCCH monitoring of type 1 CSS with dedicated RRC configuration, type 3 CSS, and UE-SS in the first 3 OFDM symbols of each slot within each of the $Y_s=2$ slots (with $X_s=4$) for 480kHz with $(X_s, Y_s)=(4, 2)$.</p> <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-480kHz-r17</i>.</p>	Band	No	N/A	N/A
<p>enhancedPDCCH-monitoringSCS-960kHz-r17</p>	Band	No	N/A	N/A

Release 17

<p>Indicates whether the UE supports multiple-slot PDCCH monitoring for one or more of (Xs, Ys) = {(4,1), (4,2), (8,4)} for 960kHz:</p> <ul style="list-style-type: none"> - Type 1 CSS with dedicated RRC configuration, type 3 CSS, and UE-SS in the first 3 OFDM symbols of each slot within each of the Ys=2 slots (with Xs=4) or Ys=4 slots (with Xs=8). - Type 1 CSS with dedicated RRC configuration, type 3 CSS, and UE-SS with a span duration of Y symbols and a minimum gap of X symbols between the start of two spans where (X,Y) = (7, 3) within the Ys=1 slot (with Xs=4). <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-960kHz-r17</i> and shall include at least one of <i>pdccch-monitoring4-1</i>, <i>pdccch-monitoring4-2</i>, or <i>pdccch-monitoring8-4</i>.</p>				
<p><i>modulation64-QAM-PUSCH-FR2-2-r17</i> Indicates whether the UE supports 64-QAM modulation for FR2-2 PUSCH.</p>	Band	No	N/A	N/A
<p><i>ul-FR2-2-SCS-120kHz-r17</i> Indicates whether the UE supports PRACH with 120kHz SCS and length 139 and transmission of 120kHz subcarrier spacing for UL data and control channels and reference signals in FR2-2.</p> <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ul-FR2-2-SCS-480kHz-r17</i> Indicates whether the UE supports the following:</p> <ul style="list-style-type: none"> - PRACH with 480kHz SCS and length 139. - Transmission of 480kHz subcarrier spacing for UL data and control channels and reference signals in FR2-2. - Multi-PUSCH scheduling by single DCI for the operation with 480 kHz SCS. <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-480kHz-r17</i> and <i>ul-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p><i>ul-FR2-2-SCS-960kHz-r17</i> Indicates whether the UE supports the following:</p> <ul style="list-style-type: none"> - PRACH with 960kHz SCS and length 139. - Transmission of 960kHz subcarrier spacing for UL data and control channels and reference signals in FR2-2. - Multi-PUSCH scheduling by single DCI for the operation with 960 kHz SCS. <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-960kHz-r17</i> and <i>ul-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p><i>initialAccessSSB-120kHz-r17</i> Indicates whether the UE supports 120kHz SSB for initial access in FR2-2.</p> <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-120kHz-r17</i> and <i>ul-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p><i>initialAccessSSB-480kHz-r17</i> Indicates whether the UE supports 480kHz SSB for initial access in FR2-2.</p> <p>UE indicating support of this feature shall also indicate support of <i>initialAccessSSB-120kHz-r17</i>, <i>dl-FR2-2-SCS-480kHz-r17</i> and <i>ul-FR2-2-SCS-480kHz-r17</i>.</p>	Band	No	N/A	N/A
<p><i>multiPDSCH-SingleDCI-FR2-2-SCS-120kHz-r17</i> Indicates whether the UE supports multi-PDSCH scheduling by single DCI for the operation with 120 kHz SCS in FR2-2 and HARQ enhancements for both type 1 and type 2 HARQ codebook.</p> <p>UE indicating support of this feature shall also indicate support of <i>dl-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p><i>multiPUSCH-SingleDCI-FR2-2-SCS-120kHz-r17</i> Indicates whether the UE supports multi-PUSCH scheduling by single DCI for the operation with 120 kHz SCS in FR2-2.</p> <p>UE indicating support of this feature shall also indicate support of <i>ul-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p><i>multiRB-PUCCH-SCS-120kHz-r17</i> Indicates whether the UE supports multi-RB PUCCH format 0/1/4 for 120kHz SCS. This feature is only applicable when PSD limitation applies within FR2-2 based on the regional regulations.</p> <p>UE indicating support of this feature shall also indicate support of <i>ul-FR2-2-SCS-</i></p>	Band	No	N/A	N/A

Release 17

<i>120kHz-r17.</i>				
<p>multiRB-PUCCH-SCS-480kHz-r17 Indicates whether the UE supports multi-RB PUCCH format 0/1/4 for 480kHz SCS. This feature is only applicable when PSD limitation applies within FR2-2 based on the regional regulations.</p> <p>UE indicating support of this feature shall also indicate support of <i>ul-FR2-2-SCS-480kHz-r17</i>.</p>	Band	No	N/A	N/A
<p>multiRB-PUCCH-SCS-960kHz-r17 Indicates whether the UE supports multi-RB PUCCH format 0/1/4 for 960kHz SCS. This feature is only applicable when PSD limitation applies within FR2-2 based on the regional regulations.</p> <p>UE indicating support of this feature shall also indicate support of <i>ul-FR2-2-SCS-960kHz-r17</i>.</p>	Band	No	N/A	N/A
<p>reduced-BeamSwitchTiming-FR2-2-r17 Indicates whether the UE supports reduced beam switching time delay $d = 56$ symbols for 480 kHz SCS as specified in TS 38.214 [12], clause 5.2.1.5.1a.</p> <p>If this capability is not reported and the UE supports both <i>dl-FR2-2-SCS-480kHz-r17</i> and <i>dl-FR2-2-SCS-960kHz-r17</i>, the default value of 112 symbols is assumed.</p>	Band	No	N/A	N/A
<p>support32-DL-HARQ-ProcessPerSCS-r17 Indicates whether the UE supports 32 HARQ processes in DL for each SCS in FR2-2 (i.e. SCS 120kHz/480kHz/960kHz).</p> <p>A UE supporting 32 HARQ processes for 480/960 kHz SCS for DL shall support 32 as the maximum number of HARQ processes for 120 kHz SCS for DL in FR2-2. UE indicating support of this feature shall indicate support of <i>dl-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p>support32-UL-HARQ-ProcessPerSCS-r17 Indicates whether the UE supports 32 HARQ processes in UL for each SCS in FR2-2 (i.e. SCS 120kHz/480kHz/960kHz).</p> <p>A UE supporting 32 HARQ processes for 480/960 kHz SCS for UL shall support 32 as the maximum number of HARQ processes for 120 kHz SCS for UL in FR2-2. UE indicating support of this feature shall indicate support of <i>dl-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p>type1-ChannelAccess-FR2-2-r17 Indicates whether the UE supports Type 1 channel access procedure in uplink for FR2-2 with shared spectrum channel access and supports LBT performed per channel, as defined in TS 37.213 [32], clause 4.4.</p> <p>UE indicating support of this feature shall also indicate support of <i>ul-FR2-2-SCS-120kHz-r17</i>. It is mandatory for UE supporting FR2-2 frequency band to indicate this when required by regulation.</p>	Band	CY	N/A	N/A
<p>type2-ChannelAccess-FR2-2-r17 Indicates whether the UE supports Type 2 channel access procedure in uplink for FR2-2 with shared spectrum channel access and supports LBT performed per channel, as defined in TS 37.213 [32], clause 4.4.</p> <p>UE indicating support of this feature shall also indicate support of <i>ul-FR2-2-SCS-120kHz-r17</i> and <i>type1-ChannelAccess-FR2-2-r17</i>. It is mandatory for UE supporting FR2-2 frequency band to indicate this when required by regulation.</p>	Band	CY	N/A	N/A
<p>widebandPRACH-SCS-120kHz-r17 Indicates whether the UE supports enhanced PRACH design for operation by adopting a single long ZC sequence, with ZC sequence equal to 1151 and 571 for 120kHz SCS.</p> <p>This feature is only applicable when PSD limitation applies within FR2-2 based on the regional regulations.</p> <p>UE indicating support of this feature shall also indicate support of <i>ul-FR2-2-SCS-120kHz-r17</i>.</p>	Band	No	N/A	N/A
<p>widebandPRACH-SCS-480kHz-r17 Indicates whether the UE supports enhanced PRACH design for operation with ZC sequence equal to 571 for 480kHz SCS.</p> <p>This feature is only applicable when PSD limitation applies within FR2-2 based on the regional regulations.</p>	Band	No	N/A	N/A

Release 17

UE indicating support of this feature shall also indicate support of <i>ul-FR2-2-SCS-480kHz-r17</i> .				
---	--	--	--	--

4.2.7.3 CA-ParametersEUTRA

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
additionalRx-Tx-PerformanceReq <i>additionalRx-Tx-PerformanceReq</i> defined in 4.3.5.22, TS 36.306 [15].	BC	No	N/A	N/A
dl-1024QAM-TotalWeightedLayers Indicates total number of weighted layers for the LTE part of the concerned (NG)EN-DC/NE-DC band combination the UE can process for 1024QAM, as described in TS 36.306 [15] equation 4.3.5.31-1. Actual value = (10 + indicated value x 2), i.e. value 0 indicates 10 layers, value 1 indicates 12 layers and so on. For an (NG)EN-DC/NE-DC band combination for which this field is not included, <i>dl-1024QAM-TotalWeightedLayers-r15</i> as described in TS 36.331 [17] applies, if included.	BC	No	N/A	N/A
multipleTimingAdvance <i>multipleTimingAdvance</i> defined in 4.3.5.3, TS 36.306 [15].	BC	No	N/A	N/A
simultaneousRx-Tx <i>simultaneousRx-Tx</i> defined in 4.3.5.4, TS 36.306 [15].	BC	No	N/A	N/A
supportedBandwidthCombinationSetEUTRA Indicates the set of supported bandwidth combinations for the LTE part for inter-band (NG)EN-DC without intra-band (NG)EN-DC component, inter-band NE-DC without intra-band NE-DC component and intra-band (NG)EN-DC/NE-DC with additional inter-band LTE CA component. The field is encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. The UE shall neither include the field for a (NG)EN-DC/NE-DC combination which has only one LTE carrier, nor for a (NG)EN-DC/NE-DC combination which has more than one LTE carrier for which the UE only supports Bandwidth Combination Set 0 for the LTE part. If the inter-band (NG)EN-DC/NE-DC has more than one LTE carrier, the UE shall support at least one bandwidth combination for the supported LTE part.	BC	CY	N/A	N/A
supportedNAICS-2CRS-AP <i>supportedNAICS-2CRS-AP</i> defined in 4.3.5.8, TS 36.306 [15].	BC	No	N/A	N/A
fd-MIMO-TotalWeightedLayers Indicates total number of weighted layers for the LTE part of the concerned (NG)EN-DC/NE-DC band combination the UE can process for FD-MIMO, as described in TS 36.306 [15] equation 4.3.28.13-1 and TS 36.331 [17] clause 6.3.6, NOTE 8 in <i>UE-EUTRA-Capability</i> field descriptions. For an (NG)EN-DC/NE-DC band combination for which this field is not included, <i>totalWeightedLayers-r13</i> as described in TS 36.331 [17] applies, if included.	BC	No	N/A	N/A
ue-CA-PowerClass-N <i>ue-CA-PowerClass-N</i> defined in 4.3.5.1.3, TS 36.306 [15].	BC	No	N/A	N/A

Release 17

4.2.7.4

CA-ParametersNR

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>ack-NACK-FeedbackForMulticast-r17 Indicates whether the UE supports ACK/NACK based HARQ-ACK feedback and RRC-based enabling/disabling ACK/NACK-based feedback for dynamic scheduling for multicast, comprised of the following functional components:</p> <ul style="list-style-type: none"> - Supports ACK/NACK based HARQ-ACK feedback, and support of enabling/disabling ACK/NACK based HARQ-ACK feedback configured by RRC signalling; - Supports PTM retransmission for multicast; - Supports Type-1 and Type-2 HARQ-ACK CB for multicast feedback only; - Supports shared PUCCH resource configurations with unicast; - Supports Type-2 HARQ-ACK codebook for multicast on PUSCH/PUCCH with max number of G-RNTIs indicated in <i>maxNumberG-RNTI-HARQ-ACK-Codebook-r17</i>, which is not larger than max number of G-RNTIs indicated in <i>maxNumberG-RNTI-r17</i>. <p>A UE supporting this feature shall also indicate support of <i>dynamicMulticastPCell-r17</i>.</p>	BC	No	N/A	N/A
<p>ack-NACK-FeedbackForSPS-Multicast-r17 Indicates whether the UE supports ACK/NACK based HARQ-ACK feedback and RRC-based enabling/disabling ACK/NACK-based feedback for SPS group-common PDSCH for multicast, comprised of the following functional components:</p> <ul style="list-style-type: none"> - Support of ACK/NACK based HARQ-ACK feedback, enabling/disabling ACK/NACK based HARQ-ACK feedback configured by RRC signalling for SPS group-common PDSCH without PDCCH scheduling and first PDSCH after SPS activation; - Support of PTM retransmission for SPS multicast associated with G-CS-RNTI; - Support of Type-1 and Type-2 HARQ-ACK CB for SPS multicast feedback only; - Support of shared <i>SPS-PUCCH-AN-List</i> configuration from unicast SPS. <p>A UE supporting this feature shall also indicate support of <i>sps-Multicast-r17</i>.</p>	BC	No	N/A	N/A
<p>beamManagementType-r16, beamManagementType-CBM-r17 Indicates the supported beam management type for inter-band CA within FR2. Beam management type can be independent beam management (IBM) or common beam management (CBM). The UE can support independent beam management (IBM) only or common beam management (CBM) only or both.</p> <p>NOTE: <i>beamManagementType-CBM-r17</i> is only applicable to the band combinations with 2 bands.</p>	BC	Yes	TDD only	FR2 only
<p>blindDetectFactor-r16 Defines the value of factor R for blind detection as specified in Clause 10.1 [11]. The UE that indicates support of this feature shall support <i>multiDCI-MultiTRP-r16</i>.</p>	BC	No	N/A	N/A
<p>codebookComboParametersAdditionPerBC-r16 Indicates the list of supported CSI-RS resources across all bands in a band combination by referring to <i>codebookVariantsList</i> for the mixed codebook types. For mixed codebook types, UE reports support active CSI-RS resources and ports for up to 4 mixed codebook combinations in any slot. The following parameters are included in <i>codebookVariantsList</i> for each code book type:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource across all bands within a band combination; - <i>maxNumberResourcesPerBand</i> indicates the maximum number of resources across all CCs within a band combination, simultaneously; - <i>totalNumberTxPortsPerBand</i> indicates the total number of Tx ports across all CCs within a band combination, simultaneously. <p>For each band in a band combination, supported values for these three parameters are determined in conjunction with <i>codebookComboParametersAddition-r16</i> reported in <i>MIMO-ParametersPerBand</i>.</p>	BC	No	N/A	N/A
<p>codebookParametersAdditionPerBC-r16 Indicates the list of supported CSI-RS resources across all bands in a band combination by referring to <i>codebookVariantsList</i> for the additional codebook types. The following parameters are included in <i>codebookVariantsList</i> for each code book type:</p> <ul style="list-style-type: none"> - <i>maxNumberTxPortsPerResource</i> indicates the maximum number of Tx ports in a resource across all bands within a band combination; - <i>maxNumberResourcesPerBand</i> indicates the maximum number of 	BC	No	N/A	N/A

Release 17

Release 17

4.2.7.5 *FeatureSetDownlink* parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
additionalDMRS-DL-Alt Indicates whether the UE supports the alternative additional DMRS position for co-existence with LTE CRS. It is applied to 15kHz SCS and one additional DMRS case only.	FS	No	N/A	FR1 only
cbgPDSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based reception with one or with up to two or with up to four or with up to seven unicast PDSCHs per slot per CC.	FS	No	N/A	N/A
cbgPDSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based reception with one or with up to two or with up to four or with up to seven unicast PDSCHs per slot per CC.	FS	No	N/A	N/A
crossCarrierSchedulingProcessing-DiffSCS-r16 Indicates the UE cross carrier scheduling processing capability for DL carrier aggregation processing up to X unicast DCI scheduling for DL per scheduled CC. X is based on pair of (scheduling CC SCS, scheduled CC SCS) where a pair of (15,120), (15,60), (30,120) kHz SCS can have X = {1,2,4} while a pair of (15,30), (30,60), (60,120) kHz SCS can have X = {2}, and X applies per slot of scheduling CC.	FS	No	N/A	N/A
csi-RS-MeasSCellWithoutSSB Defines whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that does not transmit SS/PBCH block. A UE that supports this feature shall also support scellWithoutSSB.	FS	No	N/A	N/A
dl-MCS-TableAlt-DynamicIndication Indicates whether the UE supports dynamic indication of MCS table for PDSCH.	FS	No	N/A	N/A
dynamicMulticastPCell-r17 Indicates whether the UE supports dynamic scheduling for multicast for PCell comprised of the following functional components: <ul style="list-style-type: none"> - Supports group-common PDCCH/PDSCH for multicast with CRC scrambled by G-RNTI for PCell; - Supports CFR configuration for multicast; - Supports CORESET and common search space configuration for multicast; - Supports DCI format 4_1 with CRC scrambled with G-RNTI for multicast; - Supports inter-slot TDM between group-common PDSCH for multicast and other PDSCHs in different slots; - Supports {2, 4, 8} times semi-static slot-level repetition for group-common PDSCH for multicast; - Supports long DRX cycle for MBS multicast reception as specified in TS 38.321 [8]. <p>NOTE: One G-RNTI per UE is supported for multicast reception.</p>	FS	No	N/A	N/A
featureSetListPerDownlinkCC Indicates which features the UE supports on the individual DL carriers of the feature set (and hence of a band entry that refer to the feature set) by <i>FeatureSetDownlinkPerCC-Id</i> . The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the <i>FeatureSetDownlinkPerCC-Id</i> in this list. A fallback per CC feature set resulting from the reported feature set per DL CC is not signalled but the UE shall support it.	FS	N/A	N/A	N/A
intraBandFreqSeparationDL, intraBandFreqSeparationDL-v1620 Indicates DL frequency separation class the UE supports, which indicates a maximum frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. The UE sets the same value in the <i>FeatureSetDownlink</i> of each band entry within a band. The values mhzX correspond to the values XMHz defined in TS 38.101-2 [3]. It is mandatory to report for UE which supports DL intra-band non-contiguous CA in FR2. If the UE sets the field <i>intraBandFreqSeparationDL-v1620</i> it shall set <i>intraBandFreqSeparationDL</i> (without suffix) to the nearest smaller value.	FS	CY	N/A	FR2 only
intraBandFreqSeparationDL-Only-r16 Indicates whether the UE supports frequency separation class of DL only extension. If present, the field extends the maximum frequency separation between the lower edge of lowest CC and the upper edge of highest CC in a frequency band that the UE supports according to <i>intraBandFreqSeparationDL</i> . The frequency range extension is either above or below the frequency range indicated by <i>intraBandFreqSeparationDL</i> and extends it in contiguous manner with no frequency	FS	No	N/A	FR2 only

Release 17

Release 17

4.2.7.6 *FeatureSetDownlinkPerCC* parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>broadcastSCell-r17</i> Indicates whether the UE supports MBS reception via broadcast in RRC_CONNECTED, on one frequency indicated in an <i>MBSInterestIndication</i> message, when an SCell is configured and activated on that frequency, as specified in TS 38.331 [9].</p> <p>NOTE: The UE is not required to receive MBS via broadcast on PCell and SCell simultaneously</p>	FSPC	No	No	No
<p><i>channelBW-90mhz</i> Indicates whether the UE supports the channel bandwidth of 90 MHz. For FR1, the UE shall indicate support according to TS 38.101-1 [2], Table 5.3.5-1.</p>	FSPC	CY	N/A	FR1 only
<p><i>dci-BroadcastWith16Repetitions-r17</i> Indicates whether the UE supports up to 16 times dynamic slot-level repetition for broadcast MTCH.</p>	FSPC	No	No	No
<p><i>fdm-BroadcastUcast-r17</i> Indicates whether the UE supports overlapping PDSCH reception that one unicast PDSCH and one group-common PDSCH for broadcast in RRC_CONNECTED in a slot are partially or fully overlapping in time domain and non-overlapping in frequency domain.</p> <p>A UE supporting this feature shall also support broadcast reception as specified in clause 5.10.</p>	FSPC	No	N/A	N/A
<p><i>fdm-MulticastUcast-r17</i> Indicates whether the UE supports overlapping PDSCH reception that one dynamically scheduled unicast PDSCH and one dynamically scheduled group-common PDSCH for multicast in RRC_CONNECTED in a slot are partially or fully overlapping in time domain and non-overlapping in frequency domain.</p> <p>A UE supporting this feature shall also indicate support of <i>dynamicMulticastPCell-r17</i>, or at least one of {<i>ack-NACK-FeedbackForSPS-Multicast-r17</i>, <i>nack-OnlyFeedbackForSPS-Multicast-r17</i>}.</p> <p>NOTE: The UE supporting this feature is not required to support FDMed SPS.</p>	FSPC	No	N/A	N/A
<p><i>intraSlotTDM-UcastGroupCommonPDSCH-r17</i> Indicates whether the UE supports Intra-slot TDM-ed unicast PDSCH and group-common PDSCH. The value indicates that for any two consecutive slots n and $n+1$, if there are more than 1 broadcast/multicast/unicast PDSCH in either slot, whether to require the minimum time separation (4 OFDM symbols for 30kHz and 7 OFDM symbols for 60kHz) between starting time of any two broadcast/multicast/unicast PDSCHs within the duration of these slots.</p> <p>This feature includes the following functional components:</p> <ul style="list-style-type: none"> - Supports TDM between one unicast PDSCH and one group-common PDSCH in a slot; - Support TDM between M ($M>1$) TDMed unicast PDSCHs and one group-common PDSCH in a slot per CC; - Support TDM among N ($N>1$) group-common PDSCHs in a slot per CC; - Support TDM between K ($K>1$) TDMed unicast PDSCHs and L ($L>1$) TDMed group-common PDSCHs in a slot per CC; - The UE maximum number of TDMed PDSCH receptions capability in a slot per CC is kept based on <i>pdsch-ProcessingType1-DifferentTB-PerSlot</i>; - Up to one broadcast PDSCH is supported in a slot. <p>A UE supporting this feature shall support broadcast reception as specified in clause 5.10 and/or indicate support of <i>dynamicMulticastPCell-r17</i>, and shall indicate support of <i>pdsch-ProcessingType1-DifferentTB-PerSlot</i>.</p> <p>NOTE1: Group-common PDSCH(s) are counted as unicast PDSCH(s). NOTE2: The max number of $(M+1)$, N, $(K+L)$ are determined based on the numbers reported by <i>pdsch-ProcessingType1-DifferentTB-PerSlot</i>.</p>	FSPC	No	N/A	N/A
<p><i>supportedCRS-InterfMitigation-r17</i> Indicates whether the UE supports CRS interference mitigation (CRS-IM) in both DSS and non-DSS scenarios with overlapping spectrum for LTE and NR, which is defined in TS 38.101-4 [18]. The capability signalling contains the following:</p>	FSPC	No	No	FR1 only

Release 17

Release 17

4.2.7.7 *FeatureSetUplink* parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	No	N/A	N/A
cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.	FS	No	N/A	N/A
cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.	FS	No	N/A	N/A
crossCarrierSchedulingProcessing-DiffSCS-r16 Indicates the UE cross carrier scheduling processing capability for UL carrier aggregation processing up to X unicast DCI scheduling for UL per scheduled CC. X is based on pair of (scheduling CC SCS, scheduled CC SCS) where a pair of (15,120), (15,60), (30,120) kHz SCS can have X = {1,2,4} while a pair of (15,30), (30,60), (60,120) kHz SCS can have X = {2}, and X applies per slot of scheduling CC.	FS	No	N/A	N/A
dynamicSwitchSUL Indicates whether the UE supports supplemental uplink with dynamic switch (DCI based selection of PUSCH carrier). The UE supports this among a carrier on a band X and a band Y if it sets this capability parameter for both band X and band Y.	FS	No	N/A	N/A
extendedDC-LocationReport-r17 Indicates whether the UE supports extended DC location reporting (based on indicated default DC location) for at least 2 UL CCs in one band. A UE that supports this feature also supports extended DC location reporting for 1 UL CC in one band.	FS	No	N/A	N/A
featureSetListPerUplinkCC Indicates which features the UE supports on the individual UL carriers of the feature set (and hence of a band entry that refer to the feature set) by <i>FeatureSetUplinkPerCC-Id</i> . The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the <i>FeatureSetUplinkPerCC-Id</i> in this list. A fallback per CC feature set resulting from the reported feature set per UL CC is not signalled but the UE shall support it.	FS	N/A	N/A	N/A
interSubslotFreqHopping-PUCCH-r17 Indicates whether the UE supports inter-subslot frequency hopping for PUCCH repetitions comprised of the following functional components: <ul style="list-style-type: none"> - Inter-subslot frequency hopping for PUCCH repetition operation of PUCCH Formats 0, 1, 2, 3 and 4 for 7OS slot-based PUCCH configurations; - Inter-subslot frequency hopping for PUCCH repetition operation of PUCCH Format 0 and Format 2 for 2OS slot-based PUCCH configurations. <p>The UE indicating support of this feature shall also indicate the support of <i>pucch-Repetition-F0-1-2-3-4-RRC-Config-r17</i>.</p>	FS	No	N/A	N/A
intraBandFreqSeparationUL, intraBandFreqSeparationUL-v1620 Indicates UL frequency separation class the UE supports, which indicates a maximum frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. The UE sets the same value in the <i>FeatureSetUplink</i> of each band entry within a band. The values mhzX corresponds to the values XMHz defined in TS 38.101-2 [3]. It is mandatory to report for UE which supports UL non-contiguous CA in FR2. If the UE sets the field <i>intraBandFreqSeparationUL-v1620</i> it shall set <i>intraBandFreqSeparationUL</i> (without suffix) to the nearest smaller value.	FS	CY	N/A	FR2 only
intraFreqDAPS-UL-r16 Indicates whether UE supports enhanced uplink capabilities for intra-frequency DAPS handover. The UE only includes this capability signalling if <i>intraFreqDAPS-r16</i> is included in the <i>FeatureSetDownlink</i> for the same <i>FeatureSet</i> . The capability signalling comprises of the following parameter: <ul style="list-style-type: none"> - <i>intraFreqTwoTAGs-DAPS-r16</i> indicates whether the UE supports different timing advance groups in source PCell and intra-frequency target PCell. It is mandatory with capability signalling. 	FS	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>mTRP-PUCCH-IntraSlot-r17 Indicates whether the UE supports PUCCH repetition scheme 3 (intra-slot repetition) with sequential mapping for repetitions larger than 2 and cyclic mapping for 2 repetitions by indicating the supported PUCCH formats for this scheme. The UE indicating this feature shall also support up to two PUCCH power control parameter sets/spatial relation info per PUCCH resource. Power control parameter sets feature is applicable to FR1 only (without spatial relation info) and spatial relation info is applicable to FR2 only.</p>	FS	No	N/A	N/A
<p>mTRP-PUSCH-TypeA-CB-r17 Indicates the support of multi-TRP PUSCH repetition based on codebook with PUSCH repetition type A. The value indicates the supported number of SRS resources in one SRS resource set.</p> <p>This feature includes the following features:</p> <ul style="list-style-type: none"> - sequential mapping for repetitions larger than 2. - cyclic mapping for 2 repetitions. - two SRS resource sets with usage set to 'codebook'. <p>The UE indicating support of this feature shall also indicate the support of <i>mimo-CB-PUSCH</i>. If the value of supported number of SRS resources is 4 then the UE shall also indicate support of <i>ul-FullPwrMode2-MaxSRS-ResInSet</i> set to n4.</p>	FS	No	N/A	N/A
<p>mTRP-PUSCH-RepetitionTypeA-r17 Indicates whether the UE supports multi-TRP PUSCH repetition for non-codebook based PUSCH repetition type A with sequential mapping for repetitions larger than 2 and cyclic mapping for 2 repetitions by indicating the supported number of SRS resources in one SRS resource set. The UE indicating this feature shall also support two SRS resource sets with usage set to 'nonCodebook'. The UE indicating this feature shall indicate support of <i>maxNumberMIMO-LayersNonCB-PUSCH</i> and <i>mimo-NonCB-PUSCH</i>.</p>	FS	No	N/A	N/A
<p>multiPUCCH-r16 Indicates whether the UE supports more than one PUCCH for HARQ-ACK transmission within a slot. This field includes the following parameters:</p> <ul style="list-style-type: none"> - <i>sub-SlotConfig-NCP-r16</i> indicates the sub-slot configuration for NCP; - <i>sub-SlotConfig-ECP-r16</i> indicates the sub-slot configuration for ECP. <p>For NCP, the value <i>set1</i> denotes 7-symbol*2, and <i>set2</i> denotes 2-symbol*7 and 7-symbol*2. For ECP, the value <i>set1</i> denotes 6-symbol*2, and <i>set2</i> denotes 2-symbol*6 and 6-symbol*2.</p>	FS	No	N/A	N/A
<p>mux-SR-HARQ-ACK-r16 Indicates whether the UE supports SR/HARQ-ACK multiplexing once per subslot using a PUCCH (or HARQ-ACK piggybacked on a PUSCH) when SR/HARQ-ACK are supposed to be sent with different starting symbols in a subslot.</p>	FS	No	N/A	N/A
<p>offsetSRS-CB-PUSCH-Ant-Switch-fr1-r16 Indicates whether UE requires minimum of 19 symbols offset between aperiodic SRS triggering and transmission for SRS for codebook based PUSCH and antenna switching.</p> <p>UE indicating support of this shall indicate support of <i>supportedSRS-Resources</i>.</p>	FS	No	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>offsetSRS-CB-PUSCH-PDCCH-MonitorSingleOcc-fr1-r16 Indicates whether UE requires minimum of 19 symbols offset between aperiodic SRS triggering and transmission for SRS for codebook based PUSCH and antenna switching for the case of PDCCH monitoring on any span of up to 3 consecutive OFDM symbols of a slot.</p> <p>UE indicating support of this shall indicate support of <i>supportedSRS-Resources</i>.</p>	FS	No	N/A	FR1 only
<p>offsetSRS-CB-PUSCH-PDCCH-MonitorAnyOccWithoutGap-fr1-r16 Indicates whether UE requires minimum of 19 symbols offset between aperiodic SRS triggering and transmission for the case of PDCCH search space monitoring occasions in any symbol of the slot for Type 1-PDCCH common search space configured by dedicated RRC signalling, for a Type 3-PDCCH common search space, or for a UE-specific search space with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively.</p> <p>UE indicating support of this shall indicate support of <i>supportedSRS-Resources</i>.</p>	FS	No	N/A	FR1 only
<p>offsetSRS-CB-PUSCH-PDCCH-MonitorAnyOccWithGap-fr1-r16 Indicates whether UE requires minimum of 19 symbols offset between aperiodic SRS triggering and transmission for SRS for codebook based PUSCH and antenna switching for the case of PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation of two OFDM symbols for 15 kHz, four OFDM symbols for 30 kHz, seven OFDM symbols for 60 kHz with NCP, and 14OFDM symbols for 120kHz between two consecutive transmissions of PDCCH scrambled with C-RNTI, MCS-C-RNTI, or CS-RNTI for Type 1-PDCCH common search space configured by dedicated RRC signalling, for a Type 3-PDCCH common search space, or for a UE-specific search space, with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively.</p> <p>UE indicating support of this shall indicate support of <i>pdcc-MonitoringAnyOccasions</i> with value <i>withDCI-Gap</i> and <i>supportedSRS-Resources</i>.</p>	FS	No	N/A	FR1 only
<p>offsetSRS-CB-PUSCH-PDCCH-MonitorAnyOccWithSpanGap-fr1-r16 Indicates whether UE requires minimum of 19 symbols offset between aperiodic SRS triggering and transmission for the case of PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation between two consecutive transmissions of PDCCH with span up to two OFDM symbols for two OFDM symbols or span up to three OFDM symbols for four and seven OFDM symbols. Value set1 indicates the supported value set (X,Y) is (7,3), value set2 indicates the supported value set (X,Y) is (4,3) and (7,3) and value set 3 indicates the supported value set (X,Y) is (2,2), (4,3) and (7,3).</p> <p>UE indicating support of this shall indicate support of <i>supportedSRS-Resources</i>.</p>	FS	No	N/A	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>pa-PhaseDiscontinuityImpacts Indicates incapability motivated by impacts of PA phase discontinuity with overlapping transmissions with non-aligned starting or ending times or hop boundaries across carriers for intra-band (NG)EN-DC/NE-DC, intra-band CA and FDM based ULSUP.</p> <p>This capability applies to:</p> <ul style="list-style-type: none"> - Intra-band (NG)EN-DC/NE-DC combination without additional inter-band NR and LTE CA component; - Intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component; - Inter-band (NG)EN-DC/NE-DC combination, where the frequency range of the E-UTRA band is a subset of the frequency range of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]). <p>If this capability is included in an "Intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component", this capability applies to the intra-band (NG)EN-DC/NE-DC BC part.</p>	FS	No	N/A	N/A
<p>partialCancellationPUCCH-PUSCH-PRACH-TX-r16 Indicates whether UE supports the partial cancellation of the configured PUCCH or PUSCH or PRACH transmission in set of symbols of a slot due to:</p> <ul style="list-style-type: none"> - Detection of a DCI format 2_0 with a slot format value other than 255 that indicates a slot format with a subset of symbols from the set of symbols as downlink or flexible; - DCI format 2_0 being configured but not detected, when either a subset of symbols from the set of symbols are indicated as flexible by <i>tdd-UL-DL-ConfigurationCommon</i>, and <i>tdd-UL-DL-ConfigurationDedicated</i> if provided, or <i>tdd-UL-DL-ConfigurationCommon</i> and <i>tdd-UL-DL-ConfigurationDedicated</i> are not provided to the UE; - Detection of a DCI format 1_0, DCI format 1_1, DCI format 1_2 or DCI format 0_1 and DCI format 0_2 indicating to the UE to receive CSI-RS or PDSCH in a subset of symbols from the set of symbols. 	FS	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>phy-PrioritizationHighPriorityDG-LowPriorityCG-r17 Indicates whether the UE supports PHY prioritization of overlapping high-priority DG-PUSCH and low-priority CG-PUSCH comprised of the following functional components:</p> <ul style="list-style-type: none"> - PHY prioritization of overlapping high-priority dynamic grant PUSCH and low-priority configured grant PUSCH on a BWP of a serving cell; - Configuration of PHY priority level for CG PUSCH, and dynamic indication of priority level for dynamic PUSCH with a single DCI format. <p>The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>pusch-PreparationLowPriority-r17</i> indicates additional number of symbols (d1) needed beyond the PUSCH preparation time for cancelling a low priority UL transmission; - <i>additionalCancellationTime-r17</i> indicates additional number of symbols (d3) needed on top of Rel-16 cancellation time (which results $N2+d1+d3$ in total cancellation time); - <i>maxNumberCarriers-r17</i> indicates maximum number of supported carriers on the band across a set of contiguous carriers for the reported FS of that band. <p>The value sym0 denotes 0 symbol, sym1 denotes one symbol, and so on.</p>	FS	No	N/A	N/A
<p>phy-PrioritizationLowPriorityDG-HighPriorityCG-r17 Indicates whether the UE supports PHY prioritization of overlapping low-priority DG-PUSCH and high-priority CG-PUSCH comprised of the following functional components:</p> <ul style="list-style-type: none"> - PHY prioritization for the case where low-priority DG-PUSCH collides with high-priority CG-PUSCH; - Configuration of PHY priority level for CG PUSCH, and dynamic indication of priority level for dynamic PUSCH with a single DCI format. <p>The value indicates maximum number of supported carriers on the band across a set of contiguous carriers for the reported FS of that band.</p>	FS	No	N/A	N/A
<p>pucch-Repetition-F0-1-2-3-4-DynamicIndication-r17 Indicates whether the UE supports repetitions for PUCCH format 0, 1, 2, 3 and 4 over multiple PUCCH subslots based on dynamic repetition indication.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>pucch-Repetition-F0-1-2-3-4-RRC-Config-r17</i>.</p> <p>NOTE: Dynamic PUCCH repetition factor indication is only supported for HARQ-ACK.</p>	FS	No	N/A	N/A
<p>pucch-Repetition-F0-1-2-3-4-RRC-Config-r17 Indicates whether the UE supports repetitions for PUCCH format 0, 1, 2, 3 and 4 over multiple PUCCH subslots with RRC configured repetition factor $K = 2, 4, 8$. A UE supporting this feature shall also indicate support of <i>pucch-Repetition-F1-3-4</i> and <i>multiPUCCH-r16</i>.</p> <p>NOTE: The support of this feature doesn't imply an increase of the maximum number of PUCCHs per slot that supported by the UE.</p>	FS	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	No	N/A	N/A
cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.	FS	No	N/A	N/A
cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.	FS	No	N/A	N/A
pusch-ProcessingType1-DifferentTB-PerSlot Indicates whether the UE capable of processing time capability 1 supports transmission of up to two, four or seven unicast PUSCHs for several transport blocks in one serving cell within the same slot per CC that are multiplexed in time domain only.	FS	No	N/A	N/A
pusch-ProcessingType2 Indicates whether the UE supports PUSCH processing capability 2. The UE supports it only if all serving cells are self-scheduled and if all serving cells in one band on which the network configured processingType2 use the same subcarrier spacing. This capability signalling comprises the following parameters for each sub-carrier spacing supported by the UE. <ul style="list-style-type: none"> - <i>fallback</i> indicates whether the UE supports PUSCH processing capability 2 when the number of configured carriers is larger than <i>numberOfCarriers</i> for a reported value of <i>differentTB-PerSlot</i>. If <i>fallback</i> = 'sc', UE supports capability 2 processing time on lowest cell index among the configured carriers in the band where the value is reported, if <i>fallback</i> = 'cap1-only', UE supports only capability 1, in the band where the value is reported; - <i>differentTB-PerSlot</i> indicates whether the UE supports processing type 2 for 1, 2, 4 and/or 7 unicast PUSCHs for different transport blocks per slot per CC; and if so, it indicates up to which number of CA serving cells the UE supports that number of unicast PUSCHs for different TBs. The UE shall include at least one of <i>numberOfCarriers</i> for 1, 2, 4 or 7 transport blocks per slot in this field if <i>pusch-ProcessingType2</i> is indicated. 	FS	No	N/A	FR1 only
pusch-RepetitionTypeB-r16, pusch-RepetitionTypeB-v16d0 Indicates whether the UE supports PUSCH repetition type B, as specified in 6.1.2 of TS 38.214 [12]. The <i>maxNumberPUSCH-Tx-r16</i> in <i>pusch-RepetitionTypeB-r16</i> indicates the supported maximum number of PUSCH transmissions within a slot for all TB(s) for processing capability 1 if <i>pusch-ProcessingType2</i> is not included, or for both processing capability 1 and processing capability 2 if <i>pusch-ProcessingType2</i> is included. The <i>maxNumberPUSCH-Tx-Cap1-r16</i> and <i>maxNumberPUSCH-Tx-Cap2-r16</i> in <i>pusch-RepetitionTypeB-v16d0</i> are for processing capability 1 and processing capability 2 separately, which are only included when different values are supported for the processing capabilities. The <i>maxNumberPUSCH-Tx-r16</i> will be ignored by the network if the <i>pusch-RepetitionTypeB-v16d0</i> is included.	FS	No	N/A	N/A
pusch-SeparationWithGap Indicates whether the UE supports separation of two unicast PUSCHs with a gap, applicable to Sub-carrier spacings of 15 kHz, 30 kHz and 60 kHz only. For any two consecutive slots n and n+1, if there are more than 1 unicast PUSCH in either slot, the minimum time separation between starting time of any two unicast PUSCHs within the duration of these slots is 2 OFDM symbols for 15kHz, 4 OFDM symbols for 30kHz and 7 OFDM symbols for 60kHz.	FS	No	N/A	N/A
searchSpaceSharingCA-UL Defines whether the UE supports UL PDCCH search space sharing for carrier aggregation operation.	FS	No	N/A	N/A
semiStaticHARQ-ACK-CodebookSub-SlotPUCCH-r17 Indicates whether the UE supports Semi-static (Type 1) HARQ-ACK codebook for sub-slot based PUCCH configuration. A UE supporting this feature shall also indicate support of <i>semiStaticHARQ-ACK-Codebook</i> and <i>multiPUCCH-r16</i> .	FS	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>simultaneousTxSUL-NonSUL Indicates whether the UE supports simultaneous transmission of SRS on an SUL/non-SUL carrier and PUSCH/PUCCH/SRS on the other UL carrier in the same cell. The UE supports simultaneous transmission on an SUL band X and a Non-SUL band Y if it sets this capability parameter for both band X and band Y.</p>	FS	No	N/A	N/A
<p>srs-AntennaSwitching2SP-1Periodic-r17 Indicates whether the UE supports maximum 2 SP SRS resource sets and maximum 1 periodic SRS resource set for antenna switching. The UE indicating support of this shall indicate support of <i>supportedSRS-Resources</i>.</p> <p>NOTE:</p> <ul style="list-style-type: none"> - Applies for all supported xTyR where $y \leq 8$ - For xTyR where $y > 4$, if UE does not support this feature, UE supports maximum one SRS resource set for periodic SRS and maximum one SRS resource set for semi-persistent SRS - For xTyR where $y \leq 4$, if UE does not support this feature, UE follows Rel-15 on the number of resource sets for periodic and semi-persistent SRS <p>The two SP-SRS resource sets are not activated at the same time.</p>	FS	No	N/A	N/A
<p>srs-ExtensionAperiodicSRS-r17 Indicates whether the UE supports 4 aperiodic SRS resource sets for 1T4R and 2 aperiodic resource sets for 1T2R/2T4R. The UE indicating support of this shall indicate support of <i>srs-TxSwitch</i> and <i>supportedSRS-Resources</i>.</p>	FS	No	N/A	N/A
<p>srs-OneAP-SRS-r17 Indicates the support of 1 aperiodic SRS resource sets for 1T4R.</p> <p>The UE indicating support of this feature shall also indicate the support of <i>srs-StartAnyOFDM-Symbol-r16</i> and <i>srs-TxSwitch</i>.</p>	FS	No	N/A	N/A
<p>srs-PosResources-r16 Indicates support of SRS for positioning. UE supporting this feature should also support open loop power control for positioning SRS based on SSB from the serving cell. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberSRS-PosResourceSetPerBWP-r16</i> Indicates the max number of SRS Resource Sets for positioning supported by UE per BWP; - <i>maxNumberSRS-PosResourcesPerBWP-r16</i> indicates the max number of SRS resources for positioning supported by UE per BWP, including periodic, semi-persistent, and aperiodic SRS; - <i>maxNumberSRS-ResourcesPerBWP-PerSlot-r16</i> indicates the max number of SRS resources configured by <i>SRS-Resource</i> and <i>SRS-PosResource-r16</i> supported by UE per BWP, including periodic, semi-persistent, and aperiodic SRS; - <i>maxNumberPeriodicSRS-PosResourcesPerBWP-r16</i> indicates the max number of periodic SRS resources for positioning supported by UE per BWP; - <i>maxNumberPeriodicSRS-PosResourcesPerBWP-PerSlot-r16</i> indicates the max number of periodic SRS resources for positioning supported by UE per BWP per slot. 	FS	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>srs-PosResourceAP-r16 Indicates support of aperiodic SRS for positioning. The UE can include this field only if the UE supports <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberAP-SRS-PosResourcesPerBWP-r16</i> indicates the max number of aperiodic SRS resources for positioning supported by UE per BWP; - <i>maxNumberAP-SRS-PosResourcesPerBWP-PerSlot-r16</i> indicates the max number of aperiodic SRS resources for positioning supported by UE per BWP per slot. 	FS	No	N/A	N/A
<p>srs-PosResourceSP-r16 Indicates support of semi-persistent SRS for positioning. The UE can include this field only if the UE supports <i>srs-PosResources-r16</i>. Otherwise, the UE does not include this field. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>maxNumberSP-SRS-PosResourcesPerBWP-r16</i> indicates the max number of semi-persistent SRS resources for positioning supported by UE per BWP; - <i>maxNumberSP-SRS-PosResourcesPerBWP-PerSlot-r16</i> indicates the max number of semi-persistent SRS resources for positioning supported by UE per BWP per slot 	FS	No	N/A	N/A
<p>supportedSRS-Resources Defines support of SRS resources. The capability signalling comprising indication of:</p> <ul style="list-style-type: none"> - <i>maxNumberAperiodicSRS-PerBWP</i> indicates supported maximum number of aperiodic SRS resources that can be configured for the UE per each BWP - <i>maxNumberAperiodicSRS-PerBWP-PerSlot</i> indicates supported maximum number of aperiodic SRS resources per slot in the BWP - <i>maxNumberPeriodicSRS-PerBWP</i> indicates supported maximum number of periodic SRS resources per BWP - <i>maxNumberPeriodicSRS-PerBWP-PerSlot</i> indicates supported maximum number of periodic SRS resources per slot in the BWP - <i>maxNumberSemiPersistentSRS-PerBWP</i> indicate supported maximum number of semi-persistent SRS resources that can be configured for the UE per each BWP - <i>maxNumberSemiPersistentSRS-PerBWP-PerSlot</i> indicates supported maximum number of semi-persistent SRS resources per slot in the BWP - <i>maxNumberSRS-Ports-PerResource</i> indicates supported maximum number of SRS antenna port per each SRS resource. <p>If this field is not included, the UE supports one periodic, one aperiodic, no semi-persistent SRS resources per BWP and one periodic, one aperiodic, no semi-persistent SRS resources per BWP per slot and one SRS antenna port per SRS resource.</p>	FS	FD	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>twoHARQ-ACK-Codebook-type1-r16 Indicates whether the UE supports two HARQ-ACK codebooks with up to one subslot based HARQ-ACK codebook (i.e. slot-based + slot-based + subslot based) simultaneously constructed for supporting HARQ-ACK codebooks with different priorities at a UE. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>sub-SlotConfig-NCP-r16</i> indicates the maximum number of actual PUCCH transmissions for HARQ-ACK within a slot for NCP with 2-symbol*7 sub-slot configuration; - <i>sub-SlotConfig-ECP-r16</i> indicates the maximum number of actual PUCCH transmissions for HARQ-ACK within a slot for ECP with 2-symbol*6 sub-slot configuration; <p>For the 7-symbol*2 sub-slot configuration of NCP or the 6-symbol*2 sub-slot configuration of ECP, the value of the maximum number of actual PUCCH transmissions for HARQ-ACK within a slot is {2}.</p> <p>NOTE 1: If the UE indicates support of this feature and is simultaneously configured with two slot-based HARQ-ACK codebooks:</p> <ul style="list-style-type: none"> - whether the UE supports two PUCCH of format 0 or 2 in consecutive symbols in the same slot for each HARQ-ACK codebook is subject to the capability reported by <i>twoPUCCH-F0-2-ConsecSymbols</i>. - whether the UE supports one PUCCH format 0 or 2 and one PUCCH format 1, 3 or 4 in the same slot for each HARQ-ACK codebook is subject to the capability reported by <i>onePUCCH-LongAndShortFormat</i>. - whether the UE supports two PUCCH transmissions in the same slot for each HARQ-ACK codebook not covered by <i>twoPUCCH-F0-2-ConsecSymbols</i> and <i>onePUCCH-LongAndShortFormat</i> is subject to the capability reported by <i>twoPUCCH-AnyOthersInSlot</i>. <p>NOTE 2: If a UE reports both <i>multiPUCCH-r16</i> and <i>twoHARQ-ACK-Codebook-type1-r16</i>, it can support two slot-based HARQ-ACK codebooks, and one slot-based and one-sub-slot-based HARQ-ACK codebooks. If a UE reports <i>twoHARQ-ACK-Codebook-type1-r16</i> but does not report <i>multiPUCCH-r16</i>, it can only support two slot-based HARQ-ACK codebooks.</p>	FS	No	N/A	N/A
<p>twoHARQ-ACK-Codebook-type2-r16 Indicates whether the UE supports two subslot based HARQ-ACK codebooks simultaneously constructed for supporting HARQ-ACK codebooks with different priorities at a UE. The capability signalling comprises the following parameters:</p> <ul style="list-style-type: none"> - <i>sub-SlotConfig-NCP-r16</i> indicates the maximum number of actual PUCCH transmissions for HARQ-ACK within a slot for NCP with 2-symbol*7 sub-slot configuration; - <i>sub-SlotConfig-ECP-r16</i> indicates the maximum number of actual PUCCH transmissions for HARQ-ACK within a slot for ECP with 2-symbol*6 sub-slot configuration; <p>For the 7-symbol*2 sub-slot configuration of NCP or the 6-symbol*2 sub-slot configuration of ECP, the value of the maximum number of actual PUCCH transmissions for HARQ-ACK within a slot is {2}.</p>	FS	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	No	N/A	N/A
cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.	FS	No	N/A	N/A
cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.	FS	No	N/A	N/A
twoPUCCH-Group Indicates whether two PUCCH group in CA with a same numerology across CCs for data and control channel [at a given time] is supported by the UE. For NR CA, two PUCCH group is supported with the same numerology across NR carriers for data and control channel at a given time. For (NG)EN-DC/NE-DC, two PUCCH group is supported with the same numerology across NR carriers for data and control channel at a given time, wherein an NR PUCCH group is configured in FR1 and another NR PUCCH group is configured in FR2. The UE supports two PUCCH groups with PUCCH on a band X and a band Y if it sets this capability parameter for both band X and band Y.	FS	No	N/A	N/A
twoPUCCH-Type1-r16 Indicates whether the UE supports two PUCCH of format 0 or 2 in the same subslot for a single 7*2-symbol subslot based HARQ-ACK codebook.	FS	No	N/A	N/A
twoPUCCH-Type2-r16 Indicates whether the UE supports two PUCCH of format 0 or 2 in consecutive symbols in the same subslot for a single 2*7-symbol subslot based HARQ-ACK codebook.	FS	No	N/A	N/A
twoPUCCH-Type3-r16 Indicates whether the UE supports one PUCCH format 0 or 2 and one PUCCH format 1, 3 or 4 in the same subslot for a single 2*7-symbol HARQ-ACK codebook.	FS	No	N/A	N/A
twoPUCCH-Type4-r16 Indicates whether the UE supports two PUCCH transmissions in the same subslot for a single 2*7-symbol HARQ-ACK codebook which are not covered by <i>twoPUCCH-Type2-r16</i> and <i>twoPUCCH-Type3-r16</i> .	FS	No	N/A	N/A
twoPUCCH-Type5-r16 Indicates whether the UE supports two PUCCH of format 0 or 2 for two HARQ-ACK codebooks with one 7*2-symbol subslot based HARQ-ACK codebook and one slot based HARQ-ACK codebook.	FS	No	N/A	N/A
twoPUCCH-Type6-r16 Indicates whether the UE supports two PUCCH of format 0 or 2 in consecutive symbols in the same subslot for two HARQ-ACK codebooks with one 2*7-symbol subslot based HARQ-ACK codebook and one slot based HARQ-ACK codebook.	FS	No	N/A	N/A
twoPUCCH-Type7-r16 Indicates whether the UE supports two PUCCH of format 0 or 2 in consecutive symbols in the same subslot for two subslot based HARQ-ACK codebooks.	FS	No	N/A	N/A
twoPUCCH-Type8-r16 Indicates whether the UE supports one PUCCH format 0 or 2 and one PUCCH format 1, 3 or 4 in the same subslot for two HARQ-ACK codebooks with one 2*7-symbol subslot based HARQ-ACK codebook and one slot based HARQ-ACK codebook.	FS	No	N/A	N/A
twoPUCCH-Type9-r16 Indicates whether the UE supports one PUCCH format 0 or 2 and one PUCCH format 1, 3 or 4 in the same subslot for two subslot based HARQ-ACK codebooks.	FS	No	N/A	N/A
twoPUCCH-Type10-r16 Indicates whether the UE supports two PUCCH transmissions in the same subslot for two HARQ-ACK codebooks with one 2*7-symbol subslot and one slot based HARQ-ACK codebook which are not covered by <i>twoPUCCH-Type6-r16</i> and <i>twoPUCCH-Type8-r16</i> .	FS	No	N/A	N/A
twoPUCCH-Type11-r16 Indicates whether the UE supports two PUCCH transmissions in the same subslot for two subslot based HARQ-ACK codebooks which are not covered by <i>twoPUCCH-Type7-r16</i> and <i>twoPUCCH-Type9-r16</i> .	FS	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	No	N/A	N/A
cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.	FS	No	N/A	N/A
cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.	FS	No	N/A	N/A
tx-Support-UL-GapFR2-r17 Indicates whether the UE supports UL transmission in FR2 bands within an FR2 UL gap when the FR2 UL gap is activated in inter-band UL CA. The UE which indicates support for <i>tx-Support-UL-GapFR2-r17</i> shall also indicate support for <i>ul-GapFR2-r17</i> in an FR2 band.	FS	No	No	FR2 only
ue-PowerClassPerBandPerBC-r17 Indicates the UE power class per band per band combination. NOTE: Void.	FS	No	N/A	FR1 only
ul-CancellationCrossCarrier-r16 Indicates whether the UE supports UL cancellation scheme for cross-carrier comprised of the following functional components: <ul style="list-style-type: none"> - Supports group common DCI (i.e. DCI format 2_4) for cancellation indication on a different DL CC than that scheduling PUSCH or SRS; - UL cancellation for PUSCH. Cancellation is applied to each PUSCH repetition individually in case of PUSCH repetitions; - UL cancellation for SRS symbols that overlap with the cancelled symbols. 	FS	No	N/A	N/A
ul-CancellationSelfCarrier-r16 Indicates whether the UE supports UL cancellation scheme for self-carrier comprised of the following functional components: <ul style="list-style-type: none"> - Supports group common DCI (i.e. DCI format 2_4) for cancellation indication on the same DL CC as that scheduling PUSCH or SRS; - UL cancellation for PUSCH. Cancellation is applied to each PUSCH repetition individually in case of PUSCH repetitions; - UL cancellation for SRS symbols that overlap with the cancelled symbols. 	FS	No	N/A	N/A
ul-FullPwrMode-r16 Indicates the UE support of UL full power transmission mode of <i>fullpower</i> as specified in clause 7.1 of TS 38.213 [11]. If the UE indicates this capability the UE also indicates the support of codebook based PUSCH MIMO transmission using <i>mimo-CB-PUSCH</i> and the support of PUSCH codebook coherency subset using <i>pusch-TransCoherence</i> .	FS	No	N/A	N/A
ul-FullPwrMode1-r16 Indicates the UE support of UL full power transmission mode of <i>fullpowerMode1</i> . If the UE indicates this capability the UE also indicates the support of codebook based PUSCH MIMO transmission using <i>mimo-CB-PUSCH</i> and the support of PUSCH codebook coherency subset using <i>pusch-TransCoherence</i> .	FS	No	N/A	N/A
ul-FullPwrMode2-MaxSRS-ResInSet-r16 Indicates the UE support of the maximum number of SRS resources in one SRS resource set with usage set to 'codebook' for uplink full power Mode 2 operation. If the UE indicates this capability the UE also indicates the support of codebook based PUSCH MIMO transmission using <i>mimo-CB-PUSCH</i> and the support of PUSCH codebook coherency subset using <i>pusch-TransCoherence</i> . A UE supports this feature shall support at least full power operation with single port.	FS	No	N/A	N/A

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>ul-FullPwrMode2-SRSConfig-diffNumSRSPorts-r16 Indicates the UE supported SRS configuration with different number of antenna ports per SRS resource for uplink full power Mode 2 operation. The possible different number of antenna ports that can be configured for a SRS resource are as follow:</p> <ul style="list-style-type: none"> - value <i>p1-2</i> means that each SRS resource can be configured with 1 port or 2 ports - value <i>p1-4</i> means that each SRS resource can be configured with 1 port or 4 ports - value <i>p1-2-4</i> means that each SRS resource can be configured with 1 port or 2 ports or 4 ports <p>UE indicates support of this feature shall also indicate support of <i>ul-FullPwrMode2-MaxSRS-ResInSet</i>.</p> <p>NOTE: The values <i>p1-2</i>, <i>p1-4</i> or <i>p1-2-4</i> can be used if <i>ul-FullPwrMode2-MaxSRS-ResInSet</i> is reported as <i>n2</i> or <i>n4</i>.</p>	FS	No	N/A	N/A

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF												
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A												
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A												
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A												
<p>ul-FullPwrMode2-TPMIGroup-r16 Indicates the UE supported TPMI group(s) which delivers full power. The capability signalling comprises the following values:</p> <ul style="list-style-type: none"> - <i>twoPorts-r16</i> indicates a 2-bit bitmap, where the leading / leftmost bit (bit 0) corresponds to {TPMI index = 0}. The next bit (bit 1) corresponds to {TPMI index = 1} and the TPMI index is as specified in Table 6.3.1.5-1 of TS 38.211 [6] - <i>fourPortsNonCoherent-r16</i> indicates the TPMI groups {G0-3} - <i>fourPortsPartialCoherent-r16</i> indicates the TPMI groups {G0-6} <p>UE indicates support of this feature shall also indicate support of <i>ul-FullPwrMode2-MaxSRS-ResInSet</i>. Definition of G0~G6 can be found in the table below:</p>	FS	No	N/A	N/A												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">ID</th> <th style="width: 90%;">TPMI groups</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">G0</td> <td style="text-align: center;"> $\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix},$ </td> </tr> <tr> <td style="text-align: center;">G1</td> <td style="text-align: center;"> $\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 0 \\ 1 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix},$ </td> </tr> <tr> <td style="text-align: center;">G2</td> <td style="text-align: center;"> $\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 1 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 0 \\ 1 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 0 \\ 0 & 1 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 & 0 \\ 1 & 1 \\ 0 & 0 \end{bmatrix},$ $\frac{1}{2} \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$ </td> </tr> <tr> <td style="text-align: center;">G3</td> <td style="text-align: center;"> $\frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 0 \\ 0 & 1 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 & 0 \\ 1 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$ </td> </tr> <tr> <td></td> <td style="text-align: center;"> $\begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 & 0 \end{bmatrix}$ </td> </tr> </tbody> </table>	ID	TPMI groups	G0	$\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix},$	G1	$\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 0 \\ 1 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix},$	G2	$\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 1 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 0 \\ 1 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 0 \\ 0 & 1 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 & 0 \\ 1 & 1 \\ 0 & 0 \end{bmatrix},$ $\frac{1}{2} \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$	G3	$\frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 0 \\ 0 & 1 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 & 0 \\ 1 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$		$\begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 & 0 \end{bmatrix}$				
ID	TPMI groups															
G0	$\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix},$															
G1	$\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 0 \\ 1 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix},$															
G2	$\frac{1}{2} \begin{bmatrix} 1 \\ 0 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 1 \\ 0 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 \\ 0 \\ 1 \\ 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 0 \\ 0 & 1 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 & 0 \\ 1 & 1 \\ 0 & 0 \end{bmatrix},$ $\frac{1}{2} \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$															
G3	$\frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 \\ 0 & 0 \\ 0 & 1 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 0 & 0 \\ 1 & 1 \\ 0 & 0 \end{bmatrix}, \frac{1}{2} \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$															
	$\begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 \end{bmatrix} \quad \begin{bmatrix} 1 & 0 \end{bmatrix}$															

Release 17

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType1-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 1 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>cbgPUSCH-ProcessingType2-DifferentTB-PerSlot-r16 Defines whether the UE capable of processing time capability 2 supports CBG based transmission with one or with up to two or with up to four or with up to seven unicast PUSCHs per slot per CC.</p>	FS	No	N/A	N/A
<p>ul-IntraUE-Mux-r16 Indicates whether the UE supports intra-UE multiplexing/prioritization of overlapping PUCCH/PUCCH and PUCCH/PUSCH with two priority levels in the physical layer. This field includes the following parameters:</p> <ul style="list-style-type: none"> - <i>pusch-PreparationLowPriority-r16</i> indicates the additional number of symbols needed beyond the PUSCH preparation time for cancelling a low priority UL transmission; - <i>pusch-PreparationHighPriority-r16</i> indicates the additional number of the preparation time needed for the high priority UL transmission that cancels a low priority UL transmission. <p>The value <i>sym0</i> denotes 0 symbol, <i>sym1</i> denotes one symbol, and so on.</p>	FS	No	N/A	N/A
<p>ul-MCS-TableAlt-DynamicIndication Indicates whether the UE supports dynamic indication of MCS table using MCS-C-RNTI for PUSCH.</p>	FS	No	N/A	N/A
<p>zeroSlotOffsetAperiodicSRS Indicates whether the UE supports 0 slot offset between aperiodic SRS triggering and transmission, for SRS for CB PUSCH and antenna switching on FR1.</p>	FS	No	N/A	N/A

Release 17

4.2.7.8 *FeatureSetUplinkPerCC* parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>channelBW-90mhz Indicates whether the UE supports the channel bandwidth of 90 MHz.</p> <p>For FR1, the UE shall indicate support according to TS 38.101-1 [2], Table 5.3.5-1.</p>	FSPC	CY	N/A	FR1 only
<p>maxNumberMIMO-LayersNonCB-PUSCH Defines supported maximum number of MIMO layers at the UE for PUSCH transmission using non-codebook precoding. A UE supporting non-codebook based PUSCH transmission shall indicate support of <i>maxNumberMIMO-LayersNonCB-PUSCH</i> and <i>mimo-NonCB-PUSCH</i> together.</p>	FSPC	No	N/A	N/A
<p>mimo-CB-PUSCH Indicates whether the UE supports codebook based PUSCH MIMO Transmission. If supported, it includes 2 parameters as follows:</p> <ul style="list-style-type: none"> - <i>maxNumberMIMO-LayersCB-PUSCH</i> defines supported maximum number of MIMO layers at the UE for PUSCH transmission with codebook precoding. - <i>maxNumberSRS-ResourcePerSet</i> defines the maximum number of SRS resources per SRS resource set configured for codebook based transmission to the UE. <p>A UE indicating support of this feature shall also indicate support of <i>pusch-TransCoherence</i>.</p>	FSPC	No	N/A	N/A
<p>mimo-NonCB-PUSCH Indicates whether the UE supports non-codebook based PUSCH MIMO Transmission. If supported, it includes 2 parameters as follows:</p> <ul style="list-style-type: none"> - <i>maxNumberSimultaneousSRS-ResourceTx</i> defines the maximum number of simultaneous transmitted SRS resources at one symbol for non-codebook based transmission to the UE. - <i>maxNumberSRS-ResourcePerSet</i> defines the maximum number of SRS resources per SRS resource set configured for non-codebook based transmission to the UE. 	FSPC	No	N/A	N/A
<p>mTRP-PUSCH-RepetitionTypeB-r17 Indicates whether the UE supports multi-TRP PUSCH repetition for non-codebook based PUSCH repetition type B with sequential mapping for repetitions larger than 2 and cyclic mapping for 2 repetitions by indicating the supported number of SRS resources in one SRS resource set. The UE shall also support two SRS resource sets with usage set to 'nonCodebook'. The UE indicating support of this feature shall also indicate support of <i>maxNumberMIMO-LayersNonCB-PUSCH</i>, <i>mimo-NonCB-PUSCH</i> and <i>pusch-RepetitionTypeB-r16</i>.</p>	FSPC	No	N/A	N/A
<p>mTRP-PUSCH-TypeB-CB-r17 Indicates the support of multi-TRP PUSCH repetition based on codebook with PUSCH repetition type B. The value indicates the number of SRS resources in one SRS resource set. This feature includes the following features:</p> <ul style="list-style-type: none"> - sequential mapping for repetitions larger than 2. - cyclic mapping for 2 repetitions. - two SRS resource sets with usage set to 'codebook'. <p>The UE indicating support of this feature shall also indicate the support of <i>mimo-CB-PUSCH</i> and <i>pusch-RepetitionTypeB-r16</i>.</p>	FSPC	No	N/A	N/A
<p>supportedBandwidthUL, supportedBandwidthUL-v1710 Indicates maximum UL channel bandwidth supported for a given SCS that UE supports within a single CC (and in case of DAPS handover for the source or target cell), which is defined in Table 5.3.5-1 in TS38.101-1 [2] for FR1 and Table 5.3.5-1 in TS 38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 Table 5.3.5-1 for each band shall be mandatory with a single CC unless indicated optional. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3]. For FR2, <i>supportedBandwidthUL-v1710</i> is included if the maximum UL channel bandwidth supported by the UE within a single CC is greater than 400MHz.</p> <p>The UE may report a <i>supportedBandwidthUL</i> wider than the <i>channelBWs-UL</i>; this <i>supportedBandwidthUL</i> may not be included in the Table 5.3.5-1 of TS 38.101-1[2]/TS 38.101-2[3] for the case that the UE is unable to report the actual supported bandwidth according to the Table 5.3.5-1 of TS 38.101-1[2]/TS 38.101-2[3]. For each band, RedCap UEs shall indicate its maximum channel bandwidth, which is</p>	FSPC	CY	N/A	N/A

Release 17

Release 17

4.2.7.9 *MRDC-Parameters*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>asyncIntraBandENDC Indicates whether the UE supports asynchronous FDD-FDD intra-band (NG)EN-DC with MRTD and MTTD as specified in clause 7.5 and 7.6 of TS 38.133 [5]. If asynchronous FDD-FDD intra-band (NG)EN-DC is not supported, the UE supports only synchronous FDD-FDD intra-band (NG)EN-DC.</p> <p>This capability applies to:</p> <ul style="list-style-type: none"> - Intra-band (NG)EN-DC combination without additional inter-band NR and LTE CA component; - Intra-band (NG)EN-DC combination supporting both UL and DL intra-band (NG)EN-DC parts with additional inter-band NR/LTE CA component; - Intra-band (NG)EN-DC combination without supporting UL in both the bands of the intra-band (NG)EN-DC UL part; - Inter-band (NG)EN-DC combination, where the frequency range of the E-UTRA band is a subset of the frequency range of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]). <p>If this capability is included in an "Intra-band (NG)EN-DC combination supporting both UL and DL intra-band (NG)EN-DC parts with additional inter-band NR/LTE CA component" or in an "Intra-band (NG)EN-DC combination without supporting UL in both the bands of the intra-band (NG)EN-DC UL part", this capability applies to the intra-band (NG)EN-DC BC part.</p>	BC	No	FDD only	FR1 only
<p>condPSCellAdditionENDC-r17 Indicates whether the UE supports conditional PSCell addition in EN-DC. The UE supporting this feature shall also support 2 trigger events for same execution condition in conditional PSCell addition in EN-DC.</p>	BC	No	N/A	N/A
<p>dualPA-Architecture For an intra-band band combination, this field indicates the support of dual PAs. If absent in an intra-band band combination, the UE supports single PA for all the ULs in the intra-band band combination. For other band combinations, this field is not applicable.</p> <p>This capability applies to:</p> <ul style="list-style-type: none"> - Intra-band (NG)EN-DC/NE-DC combination without additional inter-band NR and LTE CA component; - Intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component; - Inter-band (NG)EN-DC/NE-DC combination, where the frequency range of the E-UTRA band is a subset of the frequency range of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]). <p>If this capability is included in an "Intra-band (NG)EN-DC/NE-DC combination supporting both UL and DL intra-band (NG)EN-DC/NE-DC parts with additional inter-band NR/LTE CA component", this capability applies to the intra-band (NG)EN-DC/NE-DC BC part.</p>	BC	No	N/A	N/A
<p>dynamicPowerSharingENDC Indicates whether the UE supports dynamic (NG)EN-DC power sharing between NR FR1 carriers and the LTE carriers. If the UE supports this capability the UE supports the dynamic power sharing behaviour as specified in clause 7 of TS 38.213 [11]. In this release of the specification, the UE supporting (NG)EN-DC shall set this field to <i>supported</i>.</p>	BC	Yes	N/A	FR1 only
<p>dynamicPowerSharingNEDC Indicates whether the UE supports dynamic NE-DC power sharing between NR FR1 carriers and the LTE carriers. If the UE supports this capability, the UE supports the dynamic power sharing behavior as specified in clause 7 of TS 38.213 [11].</p>	BC	Yes	N/A	FR1 only
<p>intraBandENDC-Support Indicates whether the UE supports intra-band (NG)EN-DC with only non-contiguous spectrum, or with both contiguous and non-contiguous spectrum for the (NG)EN-DC combination as specified in TS 38.101-3 [4]. If the UE does not include this field for an intra-band (NG)EN-DC combination the UE only supports the contiguous spectrum for the intra-band (NG)EN-DC combination.</p>	BC	No	N/A	N/A
<p>interBandContiguousMRDC Indicates for an inter-band (NG)EN-DC/NE-DC combination, where the frequency</p>	BC	CY	N/A	N/A

Release 17

4.2.7.10 *Phy-Parameters*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
absoluteTPC-Command Indicates whether the UE supports absolute TPC command mode.	UE	No	No	Yes
aggregationFactorSPS-DL-r16 Indicates whether the UE supports configurable PDSCH aggregation factor ({1, 2, 4, 8}) per DL SPS configuration. The UE can include this feature only if the UE indicates support of <i>downlinkSPS</i> .	UE	No	No	Yes
almostContiguousCP-OFDM-UL Indicates whether the UE supports almost contiguous UL CP-OFDM transmissions as defined in clause 6.2 of TS 38.101-1 [2].	UE	No	No	Yes
bwp-SwitchingDelay Defines whether the UE supports DCI and timer based active BWP switching delay type1 or type2 specified in clause 8.6.2 of TS 38.133 [5]. It is mandatory to report type 1 or type 2 when <i>bwp-SameNumerology</i> or <i>bwp-DiffNumerology</i> is supported on at least one band. This capability is not applicable to IAB-MT.	UE	CY	No	No
bwp-SwitchingMultiCCs-r16 Indicates whether the UE supports incremental delay for DCI and timer based active BWP switching on multiple CCs simultaneously as specified in TS 38.133 [5]. The capability signalling comprises of the following: <ul style="list-style-type: none"> - <i>type1-r16</i> indicates the delay value for type 1 BWP switching delay and has values of {100us, 200us} - <i>type2-r16</i> indicates the delay value for type 2 BWP switching delay and has values of {200us, 400us, 800us, 1000us} <p>The UE indicating support of this feature shall also support <i>bwp-SwitchingDelay</i>, <i>bwp-SameNumerology</i> and/or <i>bwp-DiffNumerology</i>. It is mandatory to report either <i>type1-r16</i> or <i>type2-r16</i> for a UE which supports CA.</p>	UE	CY	No	No
bwp-SwitchingMultiDormancyCCs-r16 Indicates whether the UE supports incremental delay for BWP switch processing on additional SCells in DCI based simultaneous dormant BWP switching on multiple SCells as specified in TS 38.133 [5]. The capability signalling comprises of the following: <ul style="list-style-type: none"> - <i>type1-r16</i> indicates the delay value for type 1 BWP switching delay and has values of {100us, 200us} - <i>type2-r16</i> indicates the delay value for type 2 BWP switching delay and has values of {200us, 400us, 800us, 1000us} <p>The UE indicating support of this feature shall also support <i>scellDormancyWithinActiveTime-r16</i> or <i>scellDormancyOutsideActiveTime-r16</i>.</p>	UE	No	No	No
cbg-FlushIndication-DL Indicates whether the UE supports CBG-based (re)transmission for DL using CBG flushing out information (CBGFI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransIndication-DL Indicates whether the UE supports CBG-based (re)transmission for DL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransIndication-UL Indicates whether the UE supports both in-order and out-of-order CBG-based (re)transmission for UL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransInOrderPUSCH-UL-r16 Indicates whether the UE supports CBG-based re-transmission(s) of a TB using CBG transmission information (CBGTI) as specified in TS 38.214 [12] in the following two cases (both are considered as in-order CBG-based retransmission(s)): <ol style="list-style-type: none"> 1. if the initial PUSCH transmission was not cancelled due to gNB scheduling/indication/configuration; and 2. if the initial PUSCH transmission was cancelled due to gNB scheduling/indication/configuration and the following condition is satisfied: the UE is scheduled for a re-transmission of a CBG #N in a given TB when CBG #N-1 has been transmitted before or is scheduled in the same UL grant that includes CBG#N. 	UE	No	No	No
cg-TimeDomainAllocationExtension-r17 Indicates whether UE supports the <i>timeDomainAllocation-v1710</i> configured in <i>rrc-ConfiguredUplinkGrant</i> to indicate 16 or more entries in PUSCH TDRA table. This field is only applicable if the UE supports both <i>pusch-RepetitionTypeB-r16</i> and either <i>configuredUL-GrantType1</i> or <i>configuredUL-GrantType1-v1650</i> .	UE	No	No	No
cli-RSSI-FDM-DL-r16 Indicates whether serving cell DL signal/channel (e.g. PDSCH/PDCCH) and CLI-	UE	No	TDD only	Yes

Release 17

Release 17

4.2.7.11 Other PHY parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
appliedFreqBandListFilter Mirrors the <i>FreqBandList</i> that the NW provided in the capability enquiry, if any. The UE filtered the band combinations in the <i>supportedBandCombinationList</i> in accordance with this <i>appliedFreqBandListFilter</i> .	UE	No	No	No
downlinkSetEUTRA Indicates the features that the UE supports on the DL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-DownlinkId. The FeatureSetEUTRA-DownlinkId = 0 means that the UE does not support a EUTRA DL carrier in this band of a band combination.	Band	N/A	N/A	N/A
downlinkSetNR Indicates the features that the UE supports on the DL carriers corresponding to one NR band entry in a band combination by FeatureSetDownlinkId. The FeatureSetDownlinkId = 0 means that the UE does not support a DL carrier in this band of a band combination. A fallback per band feature set resulting from the reported DL feature set that has fallback per CC feature set is not signalled but the UE shall support it.	Band	N/A	N/A	N/A
extendedBand-n77-r16 This field is only applicable for UEs that indicate support for band n77. If present, the UE supports the restriction to 3450 - 3550 MHz and 3700 - 3980 MHz ranges of band n77 in the USA as specified in Note 12 of Table 5.2-1 in TS 38.101-1 [2]. If absent, the UE supports only restriction to the 3700 - 3980 MHz range of band n77 in the USA. A UE that indicates this field shall also support NS value 55 as specified in TS 38.101-1 [2]. A UE supporting NS value 55 shall indicate this field.	UE	No	No	No
extendedBand-n77-r17 This field is only applicable for UEs that indicate support for band n77. If present, the UE supports the restriction to 3450 - 3650 MHz and 3650 - 3980 ranges of band n77 in Canada as specified in Note 12 of Table 5.2-1 in TS 38.101-1 [2]. If absent, the UE supports only restriction to the 3450 - 3650 MHz range of band n77 in Canada. A UE that indicates this field shall also support NS value 57 as specified in TS 38.101-1 [2]. A UE supporting NS value 57 shall indicate this field.	UE	No	No	No
featureSetCombinations Pools of feature sets that the UE supports on the NR or MR-DC band combinations.	UE	N/A	No	No
featureSets Pools of downlink and uplink features sets as well as a pool of FeatureSetCombination elements. A FeatureSetCombination refers to the IDs of the feature set(s) that the UE supports in that FeatureSetCombination. The BandCombination entries in the BandCombinationList then indicate the ID of the FeatureSetCombination that the UE supports for that band combination.	UE	N/A	No	No
naics-Capability-List Indicates that UE in MR-DC supports NAICS as defined in TS 36.331 [17].	UE	No	No	No
receivedFilters Contains all filters requested with UE-CapabilityRequestFilterNR from version 15.6.0 onwards.	UE	No	No	No
supportedBandCombinationList Defines the supported NR and/or MR-DC band combinations by the UE. For each band combination the UE identifies the associated feature set combination by featureSetCombinations index referring to featureSetCombination. A fallback band combination resulting from the reported CA and MR-DC band combination is not signalled but the UE shall support it. For intra-band non-contiguous CA band combinations, the UE only includes one band combination, and exclude the others for which the presence of uplink CA bandwidth class in the band combination entry is different. One band combination entry can also indicate support of any other possible permutations in the presence of uplink CA bandwidth class where a paired downlink CA bandwidth class is the same or where the number of UL CCs is smaller than the one of paired DL CCs expressed by the CA bandwidth class, as specified in TS 36.306 [15]. For these band combinations not included in the capability, the supported feature set is the same as the ones for the band combination included in the UE capability.	UE	Yes	No	No
supportedBandCombinationListNEDC-Only Defines the supported NE-DC only type of band combinations by the UE.	UE	No	No	No
supportedBandCombinationList-UplinkTxSwitch-r16 Defines the NR inter-band UL CA, SUL and/or EN-DC band combinations where UE supports dynamic UL Tx switching. UE only includes this field if requested by the network. All fallback band combinations resulting from the reported band combination, which include at least one band pair supporting dynamic UL Tx switching as indicated in <i>ULTxSwitchingBandPair</i> , shall be supported by the UE.	UE	No	No	No

Release 17

Release 17

4.2.7.12 *NRDC-Parameters*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>asyncNRDC-r16 Indicates whether the UE supports asynchronous NR-DC with MRTD and MTTD as specified in clause 7.5 and 7.6 of TS 38.133 [5]. If the band combination is comprised of a single band entry for more than two carriers, the UE shall support any permutations of carriers to CGs. If the band combination is comprised of at least two band entries, the carriers corresponding to a band entry shall belong to only one cell group. If the band combination includes both FR1 and FR2 bands, a UE indicating this capability shall support asynchronous NR-DC configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.</p>	BC	No	No	No
<p>condPSCellAdditionNRDC-r17 Indicates whether the UE supports conditional PSCell addition in NR-DC. The UE supporting this feature shall also support 2 trigger events for same execution condition in conditional PSCell addition in NR-DC.</p>	BC	No	No	No
<p>intraFR-NR-DC-PwrSharingMode1-r16 Indicates whether the UE supports intra-FR NR-DC with semi-static power sharing mode1 between MCG and SCG cells of same frequency range as defined in TS 38.213 [11]. If this field is absent, the UE does not support intra-FR NR-DC. In case MCG and SCG have cells in different frequency ranges, this field indicates the support of power sharing only between MCG and SCG cells with UL in FR1.</p>	BC	No	No	FR1 only
<p>intraFR-NR-DC-PwrSharingMode2-r16 Indicates whether the UE supports semi-static power sharing mode2 between MCG and SCG cells of same frequency range for synchronous intra-FR NR-DC as defined in TS 38.213 [11]. The UE indicating the support of this also indicates the support of <i>intraFR-NR-DC-PwrSharingMode1-r16</i>. In case MCG and SCG have cells in different frequency ranges, this field indicates the support of power sharing only between MCG and SCG cells with UL in FR1.</p>	BC	No	No	FR1 only
<p>intraFR-NR-DC-DynamicPwrSharing-r16 Indicates the UE support of dynamic power sharing for intra-FR NR-DC between MCG and SCG cells of same frequency range with long or short offset as specified in TS 38.213 [11]. The UE indicating the support of this also indicates the support of <i>intraFR-NR-DC-PwrSharingMode1-r16</i>. In case MCG and SCG have cells in different frequency ranges, this field indicates the support of power sharing only between MCG and SCG cells with UL in FR1.</p>	BC	No	No	FR1 only
<p>scg-ActivationDeactivationNRDC-r17 Indicates whether the UE supports activation (with or without RACH) and deactivation on SCG in NR-DC, upon SCG addition and upon reconfiguration of the SCG, as specified in TS 38.331 [9]. A UE supporting this feature shall indicate support of NR-DC as specified in TS 38.331 [9]. For the UE supporting this feature, it is mandatory to report <i>maxNumberCSI-RS-BFD</i> and <i>maxNumberSSB-BFD</i> for all NR bands of this band combination where the UE supports SpCell.</p>	BC	No	No	No
<p>scg-ActivationDeactivationResumeNRDC-r17 Indicates whether the UE supports activation (with or without RACH) and deactivation on SCG in NR-DC, upon reception of an <i>RRCReconfiguration</i> included in an <i>RRCResume</i> message, as specified in TS 38.331 [9]. A UE supporting this feature shall indicate support of NR-DC and of <i>resumeWithSCG-Config-r16</i> as specified in TS 38.331 [9]. For the UE supporting this feature, it is mandatory to report <i>maxNumberCSI-RS-BFD</i> and <i>maxNumberSSB-BFD</i> for all NR bands of this band combination where the UE supports SpCell.</p>	BC	No	No	No
<p>sfn-SyncNRDC Indicates the UE supports NR-DC only with SFN and frame synchronization between PCell and PSCell. If not included by the UE supporting NR-DC, the UE supports NR-DC with slot-level synchronization without condition on SFN and frame synchronization. In this release of the specification, the UE shall not report this UE capability.</p>	UE	No	No	No
<p>supportedCellGrouping-r16 Indicates which NR-DC cell groupings the UE supports for the given NR-DC band combination, i.e., mapping of serving cells to MCG and SCG, and the operation mode (synchronous or asynchronous), as requested by the network via <i>requestedCellGrouping-r16</i>. The bitmap reported in this field refers to the cell grouping IDs that the network requested in <i>requestedCellGrouping-r16</i>. The first (leftmost) bit corresponds to ID#0 (i.e. the first element in <i>requestedCellGrouping-r16</i>), the second bit corresponds to ID#1 (i.e. the second element in <i>requestedCellGrouping-r16</i>) and so on. NOTE: Irrespective of the indicated <i>supportedCellGrouping-r16</i>, the UE shall also support NR-DC where all FR1 serving cells are in the MCG and all</p>	BC	No	No	No

4.2.7.13 *CarrierAggregationVariant*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>fr1fdd-FR1TDD-CA-SpCellOnFR1FDD</i> Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when configured with an FR1 TDD SCell.	UE	No	No	No
<i>fr1fdd-FR1TDD-CA-SpCellOnFR1TDD</i> Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when configured with an FR1 FDD SCell.	UE	No	No	No
<i>fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR1FDD</i> Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when configured with an FR1 TDD SCell and an FR2 TDD SCell.	UE	No	No	No
<i>fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR1TDD</i> Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when configured with an FR1 FDD SCell and an FR2 TDD SCell.	UE	No	No	No
<i>fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR2TDD</i> Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when configured with an FR1 FDD SCell and an FR1 TDD SCell.	UE	No	No	No
<i>fr1fdd-FR2TDD-CA-SpCellOnFR1FDD</i> Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when configured with an FR2 TDD SCell.	UE	No	No	No
<i>fr1fdd-FR2TDD-CA-SpCellOnFR2TDD</i> Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when configured with an FR1 FDD SCell.	UE	No	No	No
<i>fr1tdd-FR2TDD-CA-SpCellOnFR1TDD</i> Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when configured with an FR2 TDD SCell.	UE	No	No	No
<i>fr1tdd-FR2TDD-CA-SpCellOnFR2TDD</i> Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when configured with an FR1 TDD SCell.	UE	No	No	No

Release 17

4.2.7.14 *Phy-ParametersSharedSpectrumChAccess*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
configuredUL-GrantType1-r16 Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one in shared spectrum channel access.	UE	No	No	No
configuredUL-GrantType2-r16 Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one in shared spectrum channel access.	UE	No	No	No
downlinkSPS-r16 Indicates whether the UE supports PDSCH reception based on semi-persistent scheduling. One SPS configuration is supported per cell group in shared spectrum channel access.	UE	No	No	No
dynamicSFI-r16 Indicates whether the UE supports monitoring for DCI format 2_0 and determination of slot formats via DCI format 2_0 in shared spectrum channel access.	UE	No	No	No
mux-HARQ-ACK-PUSCH-DiffSymbol-r16 Indicates whether the UE supports HARQ-ACK piggyback on a PUSCH with/without aperiodic CSI once per slot when the starting OFDM symbol of the PUSCH is different from the starting OFDM symbols of the PUCCH resource that HARQ-ACK would have been transmitted on in shared spectrum channel access. This feature is mandatory if UE supports any of the deployment scenarios A.2, B, C, D and E in Annex B.3 of TS 38.300 [28].	UE	CY	No	No
mux-SR-HARQ-ACK-CSI-PUCCH-MultiPerSlot-r16 Indicates whether the UE supports multiplexing SR, HARQ-ACK and CSI on a PUCCH or piggybacking on a PUSCH more than once per slot when SR, HARQ-ACK and CSI are supposed to be sent with the same or different starting symbol in a slot in shared spectrum channel access.	UE	No	No	No
mux-SR-HARQ-ACK-CSI-PUCCH-OncePerSlot-r16 <i>sameSymbol</i> indicates the UE supports multiplexing SR, HARQ-ACK and CSI on a PUCCH or piggybacking on a PUSCH once per slot, when SR, HARQ-ACK and CSI are supposed to be sent with the same starting symbols on the PUCCH resources in a slot. <i>diffSymbol</i> indicates the UE supports multiplexing SR, HARQ-ACK and CSI on a PUCCH or piggybacking on a PUSCH once per slot, when SR, HARQ-ACK and CSI are supposed to be sent with the different starting symbols in a slot in shared spectrum channel access. If the UE indicates <i>sameSymbol</i> in this field and does not support <i>mux-HARQ-ACK-PUSCH-DiffSymbol-r16</i> , the UE supports HARQ-ACK/CSI piggyback on PUSCH once per slot, when the starting OFDM symbol of the PUSCH is the same as the starting OFDM symbols of the PUCCH resource(s) that would have been transmitted on. If the UE indicates <i>sameSymbol</i> in this field and supports <i>mux-HARQ-ACK-PUSCH-DiffSymbol-r16</i> , the UE supports HARQ-ACK/CSI piggyback on PUSCH once per slot for which case the starting OFDM symbol of the PUSCH is the different from the starting OFDM symbols of the PUCCH resource(s) that would have been transmitted on. The UE is mandated to support the multiplexing and piggybacking features indicated by <i>sameSymbol</i> for <i>mux-SR-HARQ-ACK-CSI-PUCCH-OncePerSlot-r16</i> if UE supports any of the deployment scenarios A.2, B, C, D and E in Annex B.3 of TS 38.300 [28].	UE	CY	No	No
mux-SR-HARQ-ACK-PUCCH-r16 Indicates whether the UE supports multiplexing SR and HARQ-ACK on a PUCCH or piggybacking on a PUSCH once per slot, when SR and HARQ-ACK are supposed to be sent with the different starting symbols in a slot in shared spectrum channel access.	UE	No	No	No
pdsch-RepetitionMultiSlots-r16 Indicates whether the UE supports receiving PDSCH scheduled by DCI format 1_1 when configured with <i>pdsch-AggregationFactor</i> > 1, as defined in 5.1.2.1 of TS 38.214 [12] in shared spectrum channel access.	UE	No	No	No
pre-EmptyIndication-DL-r16 Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11] in shared spectrum channel access.	UE	No	No	No
pusch-RepetitionMultiSlots-r16	UE	CY	No	No

Release 17

4.2.8 Void

Release 17

4.2.9 *MeasAndMobParameters*

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
cli-RSSI-Meas-r16 Indicates whether the UE can perform CLI RSSI measurements as specified in TS 38.215 [13] and supports periodical reporting and measurement event triggering as specified in TS 38.331 [9]. If the UE supports this feature, the UE needs to report <i>maxNumberCLI-RSSI-r16</i> . If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measurement resources to be measured.	UE	No	TDD only	Yes
cli-SRS-RSRP-Meas-r16 Indicates whether the UE can perform SRS RSRP measurements as specified in TS 38.215 [13] and supports periodical reporting and measurement event triggering based on SRS-RSRP as specified in TS 38.331 [9]. If the UE supports this feature, the UE needs to report <i>maxNumberCLI-SRS-RSRP-r16</i> and <i>maxNumberPerSlotCLI-SRS-RSRP-r16</i> . If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measurement resources to be measured.	UE	No	TDD only	Yes
concurrentMeasGap-r17 Indicates whether the UE supports the concurrent measurements gaps as specified in TS 38.133 [5]. The capability signalling comprises the following parameters: <ul style="list-style-type: none"> - <i>concurrentPerUE-OnlyMeasGap-r17</i> indicates whether the UE supports more than 1 per-UE measurement gap configurations (i.e. gap combination configuration id = 2 as specified in TS38.133 [5]), or - <i>concurrentPerUE-PerFRCombMeasGap-r17</i> indicates whether the UE supports all concurrent gap combination configurations as specified in TS 38.133 [5] including support of more than 1 per-UE measurement gap configurations. For UE capable of Rel-15 per-FR gap (<i>independentGapConfig</i>), this field indicates whether the UE supports more than 1 per-FR gap measurement gap configurations in an FR, or simultaneous 1 per UE measurement gap plus 1 per-FR measurement gap configurations in an FR, or more than 1 per-UE measurement gap configurations (i.e. gap combination configuration id = 2 as specified in TS38.133 [5]). 	UE	No	No	No
concurrentMeasGapEUTRA-r17 Indicates whether the UE support the configurations of E-UTRAN measurement objectives associated with more than 1 concurrent measurement gaps as specified in TS 38.133 [5]. The UE indicating support of this feature shall also indicate support of <i>concurrentMeasGap-r17</i> .	UE	No	No	No
condHandoverFDD-TDD-r16 Indicates whether the UE supports conditional handover between FDD and TDD cells. The parameter can only be set if <i>condHandover-r16</i> is set for both FDD and TDD. The UE that indicates support of this feature shall also indicate support of <i>handoverFDD-TDD</i> .	UE	No	No	No
condHandoverFR1-FR2-r16 Indicates whether the UE supports conditional handover HO between FR1 and FR2. The parameter can only be set if <i>condHandover-r16</i> is set for both FR1 and FR2. The UE that indicates support of this feature shall also indicate support of <i>handoverFR1-FR2</i> .	UE	No	No	No
condHandoverWithSCG-NRDC-r17 Indicates whether the UE supports conditional handover with NR SCG configuration for NR-DC. The UE indicating support of this feature shall also indicate the support of <i>condHandover-r16</i> and support of at least one NR-DC band combination.	UE	No	No	No
csi-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5]. This parameter needs FR1 and FR2 differentiation. If the UE supports this feature, the UE needs to report <i>maxNumberResource-CSI-RS-RLM</i> . This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>csi-RS-RLM-r16</i> applies.	UE	Yes	No	Yes

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
csi-RSRP-AndRSRQ-MeasWithSSB Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured with an associated SS/PBCH. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report <i>maxNumberCSI-RS-RRM-RS-SINR</i> . This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>csi-RS-RLM-r16</i> applies.	UE	No	No	Yes
csi-RSRP-AndRSRQ-MeasWithoutSSB Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that transmits SS/PBCH block and without an associated SS/PBCH block. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report <i>maxNumberCSI-RS-RRM-RS-SINR</i> . This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>csi-RSRP-AndRSRQ-MeasWithoutSSB-r16</i> applies.	UE	No	No	Yes
csi-SINR-Meas Indicates whether the UE can perform CSI-SINR measurements based on configured CSI-RS resources as specified in TS 38.215 [13]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponding to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report <i>maxNumberCSI-RS-RRM-RS-SINR</i> . This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>csi-SINR-Meas-r16</i> applies.	UE	No	No	Yes
deriveSSB-IndexFromCellInterNon-NCSG-r17 Indicates whether the UE supports configuration of <i>deriveSSB-IndexFromCellInter-r17</i> in <i>MeasObjectNR</i> . This field applies to NR SA, MN configured measurements when NR-DC or NE-DC is configured, and SN configured measurements when NR-DC or (NG)EN-DC is configured. UE supporting this feature is required to meet the measurement requirements in TS 38.133 [5]. This field applies only to non-NCSG capable UEs (i.e. UEs not supporting <i>ncsg-MeasGapNR-Patterns-r17</i>).	UE	No	No	No
eutra-AutonomousGaps-r16 Defines whether the UE supports, upon configuration of <i>useAutonomousGaps</i> by the network, acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell using autonomous gap and reporting the acquired information to the network as specified in TS 38.331 [9] when MR-DC is not configured.	UE	No	No	No
eutra-AutonomousGaps-NEDC-r16 Defines whether the UE supports, upon configuration of <i>useAutonomousGaps</i> by the network, acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell using autonomous gap and reporting the acquired information to the network as specified in TS 38.331 [9] when NE-DC is configured.	UE	No	No	No
eutra-AutonomousGaps-NRDC-r16 Defines whether the UE supports, upon configuration of <i>useAutonomousGaps</i> by the network, acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell using autonomous gap and reporting the acquired information to the network as specified in TS 38.331 [9] when NR-DC is configured.	UE	No	No	No
eutra-CGI-Reporting Defines whether the UE supports acquisition of relevant CGI-information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the (NG)EN-DC and NE-DC are not configured or, when consistent DRX is configured in NR-DC. The consistent DRX configuration implies that MN and SN have the same DRX cycle and on-duration configured by MN completely contains on-duration configured by SN. It is mandated if the UE supports EUTRA. It is optional for RedCap UEs.	UE	CY	No	No
eutra-CGI-Reporting-NEDC Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NE-DC is configured.	UE	No	No	No

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
eutra-CGI-Reporting-NRDC Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NR-DC is configured wherein MN and SN have different DRX cycles, or on-duration configured by MN does not contain on-duration configured by SN if the DRX cycles are the same.	UE	No	No	No
eutra-NeedForGapNCSG-Reporting-r17 Indicates whether the UE supports reporting of the NCSG and measurement gap requirement information for E-UTRA target bands in the UE response to a network configuration RRC message as specified in TS 38.331 [9].	UE	No	No	No
eventA-MeasAndReport Indicates whether the UE supports NR measurements and events A triggered reporting as specified in TS 38.331 [9]. This field only applies to SN configured measurement when (NG)EN-DC is configured. For NR SA, MN and SN configured measurement when NR-DC is configured, and MN configured measurement when NE-DC is configured, this feature is mandatory supported.	UE	Yes	Yes	No
eventB-MeasAndReport Indicates whether the UE supports EUTRA measurement and event B triggered reporting as specified in TS 38.331 [9]. It is mandated if the UE supports EUTRA.	UE	CY	No	No
eventD1-MeasReportTrigger-r17 Indicates whether the UE supports location-based triggered measurement reporting (i.e., event D1) as specified in TS 38.331 [9]. It is mandated if the UE supports <i>locationBasedCondHandover-r17</i> in any NTN band.	UE	CY	No	No
gNB-ID-LengthReporting-r17 Indicates whether the UE supports acquisition and reporting of gNB ID length from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired gNB ID length to the network as specified in TS 38.331 [9] when (NG)EN-DC and NE-DC are not configured or, when consistent DRX is configured in NR-DC. The consistent DRX configuration implies that MN and SN have the same DRX cycle and on-duration configured by MN completely contains on-duration configured by SN. It is mandated if UE supports NR CGI reporting (NG)EN-DC and NE-DC are not configured or, when consistent DRX is configured in NR-DC.	UE	CY	No	No
gNB-ID-LengthReporting-ENDC-r17 Indicates whether the UE supports acquisition and reporting of gNB ID length from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired gNB ID length to the network as specified in TS 38.331 [9] when the (NG)EN-DC is configured. It is mandated if UE supports NR CGI reporting when (NG)EN-DC is configured.	UE	CY	No	No
gNB-ID-LengthReporting-NEDC-r17 Indicates whether the UE supports acquisition and reporting of gNB ID length from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired gNB ID length to the network as specified in TS 38.331 [9] when the NE-DC is configured. It is mandated if UE supports NR CGI reporting when NE-DC is configured.	UE	CY	No	No
gNB-ID-LengthReporting-NRDC-r17 Indicates whether the UE supports acquisition and reporting of gNB ID length from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired gNB ID length to the network as specified in TS 38.331 [9] when the NR-DC is configured wherein MN and SN have different DRX cycles, or on-duration configured by MN does not contain on-duration configured by SN if the DRX cycles are the same. It is mandated if UE supports NR CGI reporting when NR-DC is configured.	UE	CY	No	No
gNB-ID-LengthReporting-NPN-r17 Indicates whether the UE supports acquisition of NPN-relevant gNB ID length from a neighbouring intra-frequency or inter-frequency NR NPN cell by reading the SI of the neighbouring cell and reporting the acquired gNB ID length to the network as specified in TS 38.331 [9]. It is mandated if UE supports NPN CGI reporting.	UE	CY	No	No
handoverLTE-5GC, handoverLTE-5GC-r17 Indicates whether the UE supports HO to EUTRA connected to 5GC. It is mandated if the UE supports EUTRA connected to 5GC.	UE	CY	Yes	Yes (Incl FR2-2 DIFF)

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
handoverFDD-TDD Indicates whether the UE supports HO between FDD and TDD. It is mandated if the UE supports both FDD and TDD. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover). For PSCell change when (NG)EN-DC/NR-DC is configured, this feature is mandatory supported. UEs supporting this shall indicate support of <i>handoverInterF</i> for both FDD and TDD.	UE	Yes	No	No
handoverFR1-FR2 Indicates whether the UE supports HO between FR1 and FR2. Support is mandatory for the UE supporting both FR1 and FR2. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover). For PSCell change when (NG)EN-DC/NR-DC is configured, this feature is mandatory supported. UEs supporting this shall indicate support of <i>handoverInterF</i> for both FR1 and FR2.	UE	Yes	No	No
handoverFR1-FR2-2-r17 Indicates whether the UE supports HO between FR1 and FR2-2. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover) and PSCell change when (NG)EN-DC/NR-DC is configured. UEs supporting this shall indicate support of <i>handoverInterF</i> for both FR1 and FR2-2.	UE	No	No	No
handoverFR2-1-FR2-2-r17 Indicates whether the UE supports HO between FR2-1 and FR2-2. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover) and PSCell change when (NG)EN-DC/NR-DC is configured. UEs supporting this shall indicate support of <i>handoverInterF</i> for both FR2-1 and FR2-2.	UE	No	No	No
handoverInterF, handoverInterF-r17 Indicates whether the UE supports inter-frequency HO. It indicates the support for inter-frequency HO from the corresponding duplex mode and from frequency range indicated to be supported as described in Annex B. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover). For PSCell change when (NG)EN-DC/NR-DC is configured, this feature is mandatory supported.	UE	Yes	Yes	Yes (Incl FR2-2 DIFF)
handoverLTE-EPC, handoverLTE-EPC-r17 Indicates whether the UE supports HO to EUTRA connected to EPC. It is mandated if the UE supports EUTRA connected to EPC.	UE	CY	Yes	Yes (Incl FR2-2 DIFF)
idleInactiveNR-MeasReport-r16, idleInactiveNR-MeasReport-r17 Indicates whether the UE supports configuration of NR SSB measurements in RRC_IDLE/RRC_INACTIVE and reporting of the corresponding results upon network request as specified in TS 38.331 [9]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.	UE	No	No	Yes (Incl FR2-2 DIFF)
idleInactiveNR-MeasBeamReport-r16 Indicates whether the UE supports beam level measurements in RRC_IDLE/RRC_INACTIVE and reporting of the corresponding beam measurement results upon network request as specified in TS 38.331 [9]. A UE supports this feature shall also support <i>idleInactiveNR-MeasReport-r16</i> . If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.	UE	No	No	Yes
idleInactiveEUTRA-MeasReport-r16 Indicates whether the UE supports configuration of E-UTRA measurements in RRC_IDLE/RRC_INACTIVE and reporting of the corresponding results upon network request as specified in TS 38.331 [9].	UE	No	No	No
idleInactive-ValidityArea-r16 Indicates whether the UE supports configuration of a validity area for NR measurements in RRC_IDLE/RRC_INACTIVE as specified in TS 38.331 [9].	UE	No	No	No
independentGapConfig This field indicates whether the UE supports two independent measurement gap configurations for FR1 and FR2 specified in clause 9.1.2 of TS 38.133 [5]. The field also indicates whether the UE supports the FR2 inter-RAT measurement without gaps when (NG)EN-DC is not configured.	UE	No	No	No

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p><i>independentGapConfig-maxCC-r17</i> This field indicates whether the UE supports two independent measurement gap configurations for FR1 and FR2 as specified in clause 9.1.2 of TS 38.133 [5] while the number of configured serving cells is less than or equal to the indicated number.</p> <p>The capability signaling includes the following parameters:</p> <ul style="list-style-type: none"> - <i>fr1-Only-r17</i> indicates the maximum number of configured serving cells when only FR1 serving cells are configured - <i>fr2-Only-r17</i> indicates the maximum number of configured serving cells when only FR2 serving cells are configured - <i>fr1-AndFR2-r17</i> indicates the maximum number of configured serving cells when both FR1 and FR2 serving cells are configured <p>The absence of the <i>fr1-Only-r17</i> or <i>fr2-Only-r17</i> field indicates that per-FR gap is not supported when only FR1 or FR2 serving cells are configured. Absence of the <i>fr1-AndFR2</i> field, indicates that per-FR-gap is not supported when both FR1 and FR2 serving cells are configured. Value "1" for <i>fr1-Only-r17</i> or <i>fr2-Only-r17</i> indicates support of the per-FR gap when only PCell is configured (no additional CC). Value "2" for <i>fr1-Only-r17</i> or <i>fr2-Only-r17</i> indicates support of the per-FR gap when PCell and 1 additional CC are configured, and so on. Value "1" or "2" for <i>fr1-AndFR2-r17</i> indicates the support of per-FR gap when PCell and "1" additional CC are configured.</p> <p>UE indicating support of this feature shall not indicate support of <i>independentGapConfig</i>.</p>	UE	No	No	No
<p><i>independentGapConfigPRS-r17</i> Indicates whether the UE supports two independent measurement gap configurations for FR1 and FR2 for PRS measurement, as specified in clause 9.1.2 of TS 38.133 [5].</p>	UE	No	No	No
<p><i>intraAndInterF-MeasAndReport</i> Indicates whether the UE supports NR intra-frequency and inter-frequency measurements and at least periodical reporting. This field only applies to SN configured measurement when (NG)EN-DC is configured. For NR SA, MN and SN configured measurement when NR-DC is configured, and MN configured measurement when NE-DC is configured, this feature is mandatory supported.</p>	UE	Yes	Yes	No
<p><i>interFrequencyMeas-NoGap-r16</i> Indicates whether the UE can perform inter-frequency SSB based measurements without measurement gaps if the SSB is completely contained in the active BWP of the UE as specified in TS 38.133 [5]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of cells to be measured.</p>	UE	No	No	Yes
<p><i>interSatMeas-r17</i> Indicates whether the UE supports inter-satellite measurement as specified in TS 38.331 [9]. It is mandatory if the UE supports <i>nonTerrestrialNetwork-r17</i>.</p>	UE	CY	No	No
<p><i>periodicEUTRA-MeasAndReport</i> Indicates whether the UE supports periodic EUTRA measurement and reporting. It is mandated if the UE supports EUTRA.</p>	UE	CY	No	No
<p><i>maxNumberCLI-RSSI-r16</i> Defines the maximum number of CLI-RSSI measurement resources for CLI RSSI measurement. If the UE supports <i>cli-RSSI-Meas-r16</i>, the UE shall report this capability.</p>	UE	CY	TDD only	No
<p><i>maxNumberCLI-SRS-RSRP-r16</i> Defines the maximum number of SRS-RSRP measurement resources for SRS-RSRP measurement. If the UE supports <i>cli-SRS-RSRP-Meas-r16</i>, the UE shall report this capability.</p> <p>NOTE 1: A slot is based on minimum SCS among active BWPs across all CCs configured for SRS-RSRP measurement.</p> <p>NOTE 2: A SRS resource occasion that overlaps with the slot is counted as one measurement resource in the slot.</p>	UE	CY	TDD only	No
<p><i>increasedNumberofCSIRSPerMO-r16</i> Indicates support of up to 192 CSI-RS resource for L3 mobility configuration per measurement object configured with <i>associatedSSB</i>.</p>	UE	No	No	Yes

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>maxNumberCSI-RS-RRM-RS-SINR Defines the maximum number of CSI-RS resources for RRM and RS-SINR measurement across all measurement frequencies per slot. If UE supports any of <i>csi-RSRP-AndRSRQ-MeasWithSSB</i>, <i>csi-RSRP-AndRSRQ-MeasWithoutSSB</i>, and <i>csi-SINR-Meas</i>, UE shall report this capability.</p> <p>NOTE: A slot is based on minimum SCS among all measurement frequencies configured for RRM and RS-SINR measurement.</p>	UE	CY	No	No
<p>maxNumberPerSlotCLI-SRS-RSRP-r16 Defines the maximum number of SRS-RSRP measurement resources per slot for SRS-RSRP measurement. If the UE supports <i>cli-SRS-RSRP-Meas-r16</i>, the UE shall report this capability.</p>	UE	CY	TDD only	No
<p>maxNumberResource-CSI-RS-RLM Defines the maximum number of CSI-RS resources within a slot per spCell for CSI-RS based RLM. If UE supports any of <i>csi-RS-RLM</i> and <i>ssb-AndCSI-RS-RLM</i>, UE shall report this capability.</p>	UE	CY	No	Yes
<p>ncsg-MeasGapNR-Patterns-r17 Indicates whether the UE supports NR-only NCSG patterns. The left most bit in the bitmap corresponds to NCSG pattern #0 and the right most bit in the bitmap corresponds to NCSG pattern #23. A bit in the bitmap is set to 1 if the corresponding pattern is supported by the UE. NCSG patterns #0 to #23 are as specified in TS38.133 [5].</p> <p>NCSG patterns #2 and #3 are mandatory (i.e. the corresponding bits in the bitmap is set to 1) if the UE includes this field. NCSG patterns #17 and #18 are mandatory (i.e. the corresponding bits in the bitmap is set to 1) if UE includes this field and supports a FR2 band. UEs supporting this shall indicate support of <i>nr-NeedForGapNCSG-Reporting-r17</i>.</p>	UE	No	No	No
<p>ncsg-MeasGapPatterns-r17 Indicates whether the UE supports NCSG patterns. The left most bit in the bitmap corresponds to NCSG pattern #0 and the right most bit in the bitmap corresponds to NCSG pattern #23. A bit in the bitmap is set to 1 if the corresponding pattern is supported by the UE. NCSG patterns #0 to #23 are as specified in TS38.133 [5].</p> <p>NCSG patterns #0 and #1 are mandatory (i.e. the corresponding bits in the bitmap is set to 1) if the UE includes this field. NCSG patterns #13 and #14 are mandatory (i.e. the corresponding bits in the bitmap is set to 1) if UE supports <i>ncsg-MeasGapPerFR-r17</i> or if the UE is NCSG capable and supports FR2 band in standalone mode. UEs supporting this shall indicate support of <i>nr-NeedForGapNCSG-Reporting-r17</i> or <i>eutra-NeedForGapNCSG-Reporting-r17</i>.</p>	UE	No	No	No
<p>ncsg-MeasGapPerFR-r17 Indicates whether the UE supports per-FR NCSG. UEs supporting this shall indicate support of <i>nr-NeedForGapNCSG-Reporting-r17</i>.</p>	UE	No	No	No
<p>ncsg-SymbolLevelScheduleRestrictionInter-r17 Indicates whether the UE supports performing measurement with NCSG based on flag <i>deriveSSB-IndexFromCell-inter</i> and meeting the following requirements that the scheduling restriction in FR2 serving cell during NCSG ML is on SSB symbol level. UEs supporting this shall indicate support of <i>nr-NeedForGapNCSG-Reporting-r17</i>.</p>	UE	No	No	FR2 only
<p>nr-AutonomousGaps-r16 Defines whether the UE supports, upon configuration of <i>useAutonomousGaps</i> by the network, acquisition of relevant information from a neighbouring NR cell by reading the SI of the neighbouring cell using autonomous gap and reporting the acquired information to the network as specified in TS 38.331 [9] when MR-DC is not configured. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.</p>	UE	No	No	Yes
<p>nr-AutonomousGaps-ENDC-r16 Defines whether the UE supports, upon configuration of <i>useAutonomousGaps</i> by the network, acquisition of relevant information from a neighbouring NR cell by reading the SI of the neighbouring cell using autonomous gap and reporting the acquired information to the network as specified in TS 38.331 [9] when (NG)ENDC is configured. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.</p>	UE	No	No	Yes
<p>nr-AutonomousGaps-NEDC-r16 Defines whether the UE supports, upon configuration of <i>useAutonomousGaps</i> by</p>	UE	No	No	Yes

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
the network, acquisition of relevant information from a neighbouring NR cell by reading the SI of the neighbouring cell using autonomous gap and reporting the acquired information to the network as specified in TS 38.331 [9] when NE-DC is configured. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.				
nr-AutonomousGaps-NRDC-r16 Defines whether the UE supports, upon configuration of <i>useAutonomousGaps</i> by the network, acquisition of relevant information from a neighbouring NR cell by reading the SI of the neighbouring cell using autonomous gap and reporting the acquired information to the network as specified in TS 38.331 [9] when NR-DC is configured. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.	UE	No	No	Yes
nr-CGI-Reporting Defines whether the UE supports acquisition of relevant CGI-information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when (NG)EN-DC and NE-DC are not configured or, when consistent DRX is configured in NR-DC. The consistent DRX configuration implies that MN and SN have the same DRX cycle and on-duration configured by MN completely contains on-duration configured by SN. It is optional for RedCap UEs.	UE	CY	No	No
nr-CGI-Reporting-ENDC Defines whether the UE supports acquisition of relevant CGI-information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the (NG)EN-DC is configured.	UE	Yes	No	No
reportAddNeighMeasForPeriodic-r16 Defines whether the UE supports periodic reporting of best neighbour cells per serving frequency, as defined in TS 38.331 [9]. It is optional for RedCap UEs.	UE	CY	No	No
nr-CGI-Reporting-NEDC Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NE-DC is configured.	UE	Yes	No	No
nr-CGI-Reporting-NPN-r16 Defines whether the UE supports acquisition of NPN-relevant CGI-information from a neighbouring intra-frequency or inter-frequency NR NPN cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9]. If UE supports NPN, UE shall report this capability. It is optional for RedCap UEs.	UE	CY	No	No
nr-CGI-Reporting-NRDC Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NR-DC is configured wherein MN and SN have different DRX cycles, or on-duration configured by MN does not contain on-duration configured by SN if the DRX cycles are the same.	UE	Yes	No	No
nr-NeedForGapNCSG-Reporting-r17 Indicates whether the UE supports reporting of the NCSG and measurement gap requirement information for SSB based measurement in the UE response to a network configuration RRC message as specified in TS 38.331 [9].	UE	No	No	No
nr-NeedForGap-Reporting-r16 Indicates whether the UE supports reporting the measurement gap requirement information for NR target in the UE response to a network configuration RRC message.	UE	No	No	No
parallelMeasurementGap-r17 Indicates whether the UE supports 2 parallel measurement gaps for NTN SSB based RRM measurements. If a UE does not include this field but includes <i>nonTerrestrialNetwork-r17</i> , the UE supports 1 measurement gap for NTN SSB based RRM measurements. If this parameter is indicated, a UE shall also support that two parallel measurement gaps with the same gap type can be associated to one frequency layer. A UE supporting this feature shall also indicate the support of <i>nonTerrestrialNetwork-r17</i> .	UE	No	FDD only	FR1 only

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
parallelSMTC-r17 Indicates whether the UE supports NTN SSB based RRM measurements on target cells belonging to 4 SMTC-s on a single frequency carrier. If a UE does not include this field but includes <i>nonTerrestrialNetwork-r17</i> , the UE supports NTN SSB based RRM measurements on target cells belonging to 2 SMTC-s on a single frequency carrier.	UE	No	FDD only	FR1 only
pcellT312-r16 Indicates whether the UE supports T312 based fast failure recovery for PCell.	UE	No	No	No
preconfiguredUE-AutonomousMeasGap-r17 Indicates whether the UE supports the preconfigured measurement gap with UE-autonomous mechanism for activation and deactivation as specified in TS 38.133 [5].	UE	No	No	No
preconfiguredNW-ControlledMeasGap-r17 Indicates whether the UE supports the preconfigured measurement gap with network-controlled mechanism for activation and deactivation as specified in TS 38.133 [5].	UE	No	No	No
serviceLinkPropDelayDiffReporting-r17 Indicates whether the UE supports the reporting of service link propagation delay difference between serving cell and neighbour cell(s). A UE supporting this feature shall also indicate the support of <i>nonTerrestrialNetwork-r17</i> .	UE	No	No	No
simultaneousRxDataSSB-DiffNumerology Indicates whether the UE supports concurrent intra-frequency measurement on serving cell or neighbouring cell and PDCCH or PDSCH reception from the serving cell with a different numerology as defined in clause 8 and 9 of TS 38.133 [5].	UE	No	No	Yes
simultaneousRxDataSSB-DiffNumerology-Inter-r16 Indicates whether the UE supports concurrent SSB based inter-frequency measurement without measurement gap on neighbouring cell and PDCCH or PDSCH reception from the serving cell with a different numerology as defined in clause 8 and 9 of TS 38.133 [5]. UE indicates support of this indicates support of <i>interFrequencyMeas-NoGap-r16</i> . If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range where the SSB and PDCCH/PDSCH are received.	UE	No	No	Yes
sftd-MeasPSCell Indicates whether the UE supports SFTD measurements between the PCell and a configured PSCell. If this capability is included in UE-MRDC-Capability, it indicates that the UE supports SFTD measurement between PCell and PSCell in (NG)EN-DC. If this capability is included in UE-NR-Capability, it indicates that the UE supports SFTD measurement between PCell and PSCell in NR-DC.	UE	No	Yes	No
sftd-MeasPSCell-NEDC Indicates whether the UE supports SFTD measurement between the NR PCell and a configured E-UTRA PSCell in NE-DC.	UE	No	Yes	No
sftd-MeasNR-Cell Indicates whether the SFTD measurement with and without measurement gaps between the EUTRA PCell and the NR cells is supported by the UE which is capable of EN-DC/NGEN-DC when EN-DC/NGEN-DC is not configured. The SFTD measurement without gaps can be used when the UE supports at least one EN-DC band combination consisting of the set of the current E-UTRA serving frequencies and the NR frequency where SFTD measurement is configured. In UE-NR-Capability, this field is not used, and UE does not include the field.	UE	No	Yes	No
sftd-MeasNR-Neigh Indicates whether the inter-frequency SFTD measurement with and without measurement gaps between the NR PCell and inter-frequency NR neighbour cells is supported by the UE when MR-DC is not configured. The SFTD measurement without gaps can be used when the UE supports at least one DC or CA band combination consisting of the set of the current NR serving frequencies and the NR frequency where SFTD measurement is configured.	UE	No	Yes	No
sftd-MeasNR-Neigh-DRX Indicates whether the inter-frequency SFTD measurement using DRX off period between the NR PCell and the inter-frequency NR neighbour cells is supported by the UE when MR-DC is not configured.	UE	No	Yes	No

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
ssb-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block as specified in TS 38.213 [11] and TS 38.133 [5]. This field shall be set to <i>supported</i> . This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>ssb-RLM-DynamicChAccess-r16</i> or <i>ssb-RLM-Semi-StaticChAccess-r16</i> applies.	UE	Yes	No	No
ssb-AndCSI-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block and CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5]. If the UE supports this feature, the UE needs to report <i>maxNumberResource-CSI-RS-RLM</i> . This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>ssb-AndCSI-RS-RLM-r16</i> applies.	UE	No	No	No
ss-SINR-Meas Indicates whether the UE can perform SS-SINR measurement as specified in TS 38.215 [13]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. This applies only to non-shared spectrum channel access. For shared spectrum channel access, <i>ss-SINR-Meas-r16</i> applies.	UE	No	No	Yes
supportedGapPattern Indicates measurement gap pattern(s) optionally supported by the UE for NR SA, for NR-DC, for NE-DC and for independent measurement gap configuration on FR2 in (NG)EN-DC. The leading / leftmost bit (bit 0) corresponds to the gap pattern 2, the next bit corresponds to the gap pattern 3, as specified in TS 38.133 [5] and so on. The UE shall set the bits corresponding to the measurement gap pattern 13, 14, 17, 18 and 19 to 1 if the UE is an NR standalone capable UE that supports a band in FR2 or if the UE is an (NG)EN-DC capable UE that supports <i>independentGapConfig</i> and supports a band in FR2.	UE	CY	No	No
supportedGapPattern-r16 Indicates measurement gap pattern(s) optionally supported by the UE for NR SA, for NR-DC for PRS measurement and NR/E-UTRA RRM measurement. The leading / leftmost bit (bit 0) corresponds to the gap pattern 24, the next bit corresponds to the gap pattern 25, as specified in TS 38.133 [5]. The applicability of the gap patterns 24 and 25 is defined in clause 9.1.2 of TS 38.133 [5]. A UE that indicates support of this capability shall indicate support of <i>NR-DL-PRS-ProcessingCapability-r16</i> defined in TS 37.355 [22].	UE	No	No	No
supportedGapPattern-NRonly-r16 Indicates measurement gap pattern(s) optionally supported by the UE for NR SA and NR-DC when the frequencies to be measured within this measurement gap are all NR frequencies. The leading / leftmost bit (bit 0) corresponds to the gap pattern 2, the next bit corresponds to the gap pattern 3 and so on. The UE shall set the bits corresponding to the measurement gap pattern 2, 3 and 11 to 1.	UE	FD	No	No
supportedGapPattern-NRonly-NE-DC-r16 Indicates whether the UE supports gap patterns 2, 3 and 11 in NE-DC when the frequencies to be measured within this measurement gap are all NR frequencies.	UE	No	No	No

4.2.9a MeasAndMobParametersMRDC

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
condHandoverWithSCG-ENDC-r17 Indicates whether the UE supports conditional handover with NR SCG configuration for EN-DC. The UE indicating support of this feature shall also indicate the support of <i>cho-r16</i> as specified in TS 36.306 [15] and at least one EN-DC band combination.	UE	No	No	No
condHandoverWithSCG-NEDC-r17 Indicates whether the UE supports conditional handover with E-UTRA SCG configuration for NE-DC. The UE indicating support of this feature shall also indicate the support of <i>condHandover-r16</i> and at least one NE-DC band combination.	UE	No	No	No
condPSCellChangeFDD-TDD-r16 Indicates whether the UE supports conditional PSCell change between FDD and TDD cells. The parameter can only be set if <i>condPSCellChange-r16</i> is set for both FDD and TDD.	UE	No	No	No
condPSCellChangeFR1-FR2-r16 Indicates whether the UE supports conditional PSCell change between FR1 and FR2. The parameter can only be set if <i>condPSCellChange-r16</i> is set for both FR1 and FR2.	UE	No	No	No
inter-SN-condPSCellChangeFDD-TDD-ENDC-r17 Indicates whether the UE supports inter SN conditional PSCell change between FDD and TDD cells in EN-DC. The parameter can only be set <ul style="list-style-type: none"> - if <i>mn-InitiatedCondPSCellChange-FR1FDD-ENDC-r17</i> is supported and at least one of <i>mn-InitiatedCondPSCellChange-FR1TDD-ENDC-r17</i> and <i>mn-InitiatedCondPSCellChange-FR2TDD-ENDC-r17</i> is supported; or - if <i>sn-InitiatedCondPSCellChange-FR1FDD-ENDC-r17</i> is supported and at least one of <i>sn-InitiatedCondPSCellChange-FR1TDD-ENDC-r17</i> and <i>sn-InitiatedCondPSCellChange-FR2TDD-ENDC-r17</i> is supported. 	UE	No	No	No
inter-SN-condPSCellChangeFDD-TDD-NRDC-r17 Indicates whether the UE supports inter SN conditional PSCell change between FDD and TDD cells in NR-DC. The parameter can only be set if <i>mn-InitiatedCondPSCellChangeNRDC-r17</i> is set for FDD band(s) and TDD band(s), or <i>sn-InitiatedCondPSCellChangeNRDC-r17</i> is set for FDD band(s) and TDD band(s).	UE	No	No	No
inter-SN-condPSCellChangeFR1-FR2-ENDC-r17 Indicates whether the UE supports inter SN conditional PSCell change between FR1 and FR2 cells in EN-DC. The parameter can only be set: <ul style="list-style-type: none"> - if <i>mn-InitiatedCondPSCellChange-FR2TDD-ENDC-r17</i> is supported and at least one of <i>mn-InitiatedCondPSCellChange-FR1TDD-ENDC-r17</i> and <i>mn-InitiatedCondPSCellChange-FR1FDD-ENDC-r17</i> is supported; or - if <i>sn-InitiatedCondPSCellChange-FR2TDD-ENDC-r17</i> is supported and at least one of <i>sn-InitiatedCondPSCellChange-FR1TDD-ENDC-r17</i> and <i>sn-InitiatedCondPSCellChange-FR1FDD-ENDC-r17</i> is supported. 	UE	No	No	No
inter-SN-condPSCellChangeFR1-FR2-NRDC-r17 Indicates whether the UE supports inter SN conditional PSCell change between FR1 and FR2 cells. The parameter can only be set if <i>mn-InitiatedCondPSCellChangeNRDC-r17</i> is set for FR1 band(s) and FR2 band(s), or <i>sn-InitiatedCondPSCellChangeNRDC-r17</i> is set for FR1 band(s) and FR2 band(s).	UE	No	No	No
mn-InitiatedCondPSCellChange-FR1FDD-ENDC-r17 Indicates whether the UE supports MN initiated conditional PSCell change within all supported FR1-FDD bands in EN-DC, which is configured by E-UTRA <i>conditionalReconfiguration</i> field using MN configured measurement as triggering condition. The UE supporting this feature shall also support 2 trigger events for same execution condition in MN initiated conditional PSCell change in EN-DC.	UE	No	No	No
mn-InitiatedCondPSCellChange-FR1TDD-ENDC-r17 Indicates whether the UE supports MN initiated conditional PSCell change within all supported FR1-TDD bands in EN-DC, which is configured by E-UTRA <i>conditionalReconfiguration</i> field using MN configured measurement as triggering condition. The UE supporting this feature shall also support 2 trigger events for same execution condition in MN initiated conditional PSCell change in EN-DC.	UE	No	No	No

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>condHandoverWithSCG-ENDC-r17</i> Indicates whether the UE supports conditional handover with NR SCG configuration for EN-DC. The UE indicating support of this feature shall also indicate the support of <i>cho-r16</i> as specified in TS 36.306 [15] and at least one EN-DC band combination.	UE	No	No	No
<i>condHandoverWithSCG-NE-DC-r17</i> Indicates whether the UE supports conditional handover with E-UTRA SCG configuration for NE-DC. The UE indicating support of this feature shall also indicate the support of <i>condHandover-r16</i> and at least one NE-DC band combination.	UE	No	No	No
<i>mn-InitiatedCondPSCellChange-FR2TDD-ENDC-r17</i> Indicates whether the UE supports MN initiated conditional PSCell change within all supported FR2-TDD bands in EN-DC, which is configured by E-UTRA <i>conditionalReconfiguration</i> field using MN configured measurement as triggering condition. The UE supporting this feature shall also support 2 trigger events for same execution condition in MN initiated conditional PSCell change in EN-DC.	UE	No	No	No
<i>pscellT312-r16</i> Indicates whether the UE supports T312 based fast failure recovery for PSCell.	UE	No	No	No
<i>sn-InitiatedCondPSCellChange-FR1FDD-ENDC-r17</i> Indicates whether the UE supports SN initiated inter-SN conditional PSCell change within all supported FR1-FDD bands in EN-DC, which is configured by E-UTRA <i>conditionalReconfiguration</i> field using SN configured measurement as triggering condition. The UE supporting this feature shall also support 2 trigger events for same execution condition in SN initiated inter-SN conditional PSCell change in EN-DC.	UE	No	No	No
<i>sn-InitiatedCondPSCellChange-FR1TDD-ENDC-r17</i> Indicates whether the UE supports SN initiated inter-SN conditional PSCell change within all supported FR1-TDD bands in EN-DC, which is configured by E-UTRA <i>conditionalReconfiguration</i> field using SN configured measurement as triggering condition. The UE supporting this feature shall also support 2 trigger events for same execution condition in SN initiated inter-SN conditional PSCell change in EN-DC.	UE	No	No	No
<i>sn-InitiatedCondPSCellChange-FR2TDD-ENDC-r17</i> Indicates whether the UE supports SN initiated inter-SN conditional PSCell change within all supported FR2-TDD bands in EN-DC, which is configured by E-UTRA <i>conditionalReconfiguration</i> field using SN configured measurement as triggering condition. The UE supporting this feature shall also support 2 trigger events for same execution condition in SN initiated inter-SN conditional PSCell change in EN-DC.	UE	No	No	No

4.2.10 Inter-RAT parameters

Definitions for parameters	Per	M	FDD-TDD DIFF
<i>mfb</i> -EUTRA Indicates whether the UE supports the mechanisms defined for cells broadcasting multi band information i.e. comprehending <i>multiBandInfoList</i> defined in TS 36.331 [17].	UE	Yes	No
<i>modifiedMPR-Behavior</i> EUTRA <i>modifiedMPR-Behavior</i> in 4.3.5.10, TS 36.306 [15].	UE	No	No
<i>multiNS-Pmax</i> -EUTRA <i>multiNS-Pmax</i> defined in 4.3.5.16, TS 36.306 [15].	UE	No	No
<i>ne-DC</i> Indicates whether the UE supports NE-DC as specified in TS 37.340 [7].	UE	No	No
<i>nr-HO-ToEN-DC-r16</i> Indicates whether the UE supports inter-RAT handover from NR to EN-DC while NR-DC or NE-DC is not configured as defined in TS 36.306 [15]. It is mandated if the UE supports EN-DC.	UE	CY	No
<i>rs-SINR-Meas</i> EUTRA <i>rs-SINR-Meas</i> in 4.3.6.13, TS 36.306 [15].	UE	No	No
<i>rsrqMeasWideband</i> EUTRA <i>rsrqMeasWideband</i> in 4.3.6.2, TS 36.306 [15]. If this parameter is indicated for FDD and TDD differently, each indication corresponds to the duplex mode of measured target cell.	UE	No	Yes
<i>supportedBandList</i> EUTRA <i>supportedBandListEUTRA</i> defined in 4.3.5.1, TS 36.306 [15].	UE	No	No
<i>supportedBandList</i> UTRA-FDD-r16 <i>Radio frequency bands</i> defined in 4.5.7, TS 25.306 [20].	UE	No	No

4.2.10.1 Void

4.2.10.2 Void

4.2.11 Void

4.2.12 Void

4.2.13 IMS Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>voiceFallbackIndication</i> EPS-r16 Indicates whether the UE supports <i>voiceFallbackIndication</i> in <i>RRCRelease</i> and <i>MobilityFromNRCommand</i> . If this field is included, the UE shall support IMS voice over NR and IMS voice over E-UTRA via EPC.	UE	No	No	No
<i>voiceOver</i> EUTRA-5GC Indicates whether the UE supports IMS voice over E-UTRA via 5GC. It is mandated to the UE if the UE is capable of IMS voice over E-UTRA via 5GC. Otherwise, the UE does not include this field. If this field is included and the UE is capable of E-UTRA with EPC, the UE shall support IMS voice over E-UTRA via EPC.	UE	No	No	No
<i>voiceOverNR, voiceOverNR-r17</i> Indicates whether the UE supports IMS voice over NR. It is mandated to the UE if the UE is capable of IMS voice over NR (including SNPN if the UE is SNPN capable). Otherwise, the UE does not include this field. If this field is included and the UE is capable of E-UTRA with EPC, the UE shall support IMS voice over E-UTRA via EPC.	UE	No	No	Yes (Incl FR2-2 DIFF)
<i>voiceOverSCG-Bearer</i> EUTRA-5GC Indicates whether the UE supports IMS voice over SCG bearer of NE-DC.	UE	No	No	N/A

NOTE: In this release of specification, IMS voice over split bearer is not supported for NR-DC and NE-DC.

4.2.14 RRC buffer size

The RRC buffer size is defined as the maximum overall RRC configuration size that the UE is required to store. The RRC buffer size is 45Kbytes.

4.2.15 IAB Parameters

4.2.15.1 Mandatory IAB-MT features

Table 4.2.15.1-1, Table 4.2.15.1-2 and Table 4.2.15.1-3 capture feature groups, which are mandatory for an IAB-MT. All other feature groups or components of the feature groups as captured in TR 38.822 [24] as well as capabilities specified in this specification are optional for an IAB-MT, unless indicated otherwise.

Table 4.2.15.1-1: Layer-1 mandatory features for IAB-MT

Release 17

Features	Index	Feature group	Components	Additional information
0. Waveform, modulation, subcarrier spacings, and CP	0-1	CP-OFDM waveform for DL and UL	1) CP-OFDM for DL 2) CP -OFDM for UL	
	0-3	DL modulation scheme	1) QPSK modulation 2) 16QAM modulation 3) 64QAM modulation for FR1	
	0-4	UL modulation scheme	1) QPSK modulation 2) 16QAM modulation	
1. Initial access and mobility	1-1	Basic initial access channels and procedures	1) RACH preamble format 2) SS block based RRM measurement 3) Broadcast SIB reception including RMSI/OSI and paging	Only 1 preamble for component 1), component 2), component 3) except paging
	1-3	SS block based RLM	SS-SINR measurement	
2. MIMO	2-1	Basic PDSCH reception	1) Data RE mapping 2) Single layer transmission 3) Support one TCI state	
	2-5	Basic downlink DMRS for scheduling type A	1) Support 1 symbol FL DMRS without additional symbol(s) 2) Support 1 symbol FL DMRS and 1 additional DMRS symbol 3) Support 1 symbol FL DMRS and 2 additional DMRS symbols for at least one port.	
	2-6	Basic downlink DMRS for scheduling type B	1) Support 1 symbol FL DMRS without additional symbol(s) 2) Support 1 symbol FL DMRS and 1 additional DMRS symbol	
	2-12	Basic PUSCH transmission	Data RE mapping Single layer (single Tx) transmission Single port, single resource SRS transmission (SRS set use is configured as for codebook)	
	2-16	Basic uplink DMRS (uplink) for scheduling type A	1) Support 1 symbol FL DMRS without additional symbol(s) 2) Support 1 symbol FL DMRS and 1 additional DMRS symbols 3) Support 1 symbol FL DMRS and 2 additional DMRS symbols	
	2-16a	Basic uplink DMRS for scheduling type B	1) Support 1 symbol FL DMRS without additional symbol(s) 2) Support 1 symbol FL DMRS and 1 additional DMRS symbol	
	2-22	Aperiodic beam report	Support aperiodic report on PUSCH	
	2-32	Basic CSI feedback	1) Type I single panel codebook based PMI (further discuss which mode or both to be supported as mandatory) 2) 2Tx codebook for FR1 and FR2 3) 4Tx codebook for FR1 4) 8Tx codebook for FR1 when configured as wideband CSI report 7) a-CSI on PUSCH (at least Z value ≥ 14 symbols, detail processing time to be discussed separately) further check a-CSI on p-CSI-RS and/or SP-CSI-RS from component-7	
	2-50	Basic TRS	1) Support of TRS (mandatory) 2) All the periodicity are supported.	
	2-52	Basic SRS	1) Support 1 port SRS transmission 2) Support periodic/aperiodic SRS transmission	
3. DL control channel and procedure	3-1	Basic DL control channel	1) One configured CORESET per BWP per cell in addition to CORESET0 - CORESET resource allocation of 6RB bit-map and duration of 1 – 3 OFDM symbols for FR1 - For type 1 CSS without dedicated RRC configuration and for type 0, 0A, and 2 CSSs, CORESET resource allocation of 6RB bit-map and duration 1-3 OFDM symbols for FR2 - For type 1 CSS with dedicated RRC configuration and for type 3 CSS, UE specific SS, CORESET resource allocation of 6RB bit-map and duration 1-2 OFDM symbols for FR2 - REG-bundle sizes of 2/3 RBs or 6 RBs - Interleaved and non-interleaved CCE-to-REG mapping - Precoder-granularity of REG-bundle size - PDCCH DMRS scrambling determination - TCI state(s) for a CORESET configuration 2) CSS and UE-SS configurations for unicast PDCCH	

Table 4.2.15.1-2: Layer-2 and Layer-3 mandatory features for IAB-MT

Features	Index	Feature group	Components	Additional information
0. General	N/A	IAB procedures	1) Routing using BAP protocol, as specified in TS 38.340 [23] 2) Bearer mapping using BAP protocol, as specified in TS 38.340 [23] 3) IAB-node IP address signalling over RRC, as specified in TS 38.331 [9]	
1. PDCP	1-0	Basic PDCP procedures	1) (de)Ciphering on SRB 2) Integrity protection on SRB 3) Timer based SDU discard 4) Re-ordering and in-order delivery 6) Duplicate discarding 7) 18bits SN	
2. RLC	2-0	Basic RLC procedures	1) RLC TM 2) RLC AM with 18bits SN 3) SDU discard	
	2-4	NR RLC SN size for SRB	NR RLC SN size for SRB	
3. MAC	3-0	Basic MAC procedures	1) RA procedure on PCell 2) IAB-MT initiated RA procedure (including for beam recovery purpose) 3) NW initiated RA procedure (i.e. based on PDCCH) 4) Support of ssb-Threshold and association between preamble/PRACH occasion and SSB 5) Preamble grouping 6) UL single TA maintenance 7) HARQ operation for DL and UL 8) LCH prioritization 9) Prioritized bit rate 10) Multiplexing 11) SR with single SR configuration 12) BSR 13) PHR 14) 8bits and 16bits L field	
9. RRC	9-1	RRC buffer size	Maximum overall RRC configuration size	45 Kbytes
	9-2	RRC processing time	1) RRC connection establishment 2) RRC connection resume without SCell addition/release and SCG establishment/modification/release 3) RRC connection reconfiguration without SCell addition/release and SCG establishment/modification/release 4) RRC connection re-establishment. 5) RRC connection reconfiguration with sync procedure 6) RRC connection reconfiguration with SCell addition/release or SCG establishment/modification/release 7) RRC connection resume 8) Initial security activation 9) Counter check 10) UE capability transfer	1) to 3) 10ms 4) 10ms 5): 10ms + additional delay (cell search time and synchronization) defined in TS 38.133 6) and 7) 16ms 7) 10 or 6ms (See details in clause 12, TS 38.331) 8) and 9) 5ms 10) 80ms

Table 4.2.15.1-3: RF/RRM mandatory features for IAB-MT

Features	Index	Feature group	Components	Additional information
1. System parameter	1-2	64QAM modulation for FR2 PDSCH	64QAM modulation for FR2 PDSCH	
	1-3	64QAM for PUSCH	64QAM for PUSCH	

4.2.15.2 General Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>bh-RLF-DetectionRecovery-Indication-r17</i> Indicates whether the IAB-MT supports BH RLF detection indication and BH RLF recovery indication handling as specified in TS 38.340 [23]	IAB-MT	No	No	No
<i>bh-RLF-Indication-r16</i> Indicates whether the IAB-MT supports BH RLF indication handling as specified in TS 38.331 [9] and in TS 38.340 [23]	IAB-MT	No	No	No
<i>directSN-AdditionFirstRRC-IAB-r16</i> Indicates whether the IAB-MT supports direct SN addition in the first RRC connection reconfiguration after RRC connection establishment.	IAB-MT	No	No	No

4.2.15.3 SDAP Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>sdap-QoS-IAB-r16</i> Indicates whether the IAB-MT supports flow-based QoS and multiple flows to 1 DRB mapping, as specified in TS 37.324 [25].	IAB-MT	No	No	No
<i>sdapHeaderIAB-r16</i> Indicates whether the IAB-MT supports UL SDAP header and SDAP End-marker, as specified in TS 37.324 [25].	IAB-MT	No	No	No

4.2.15.4 PDCP Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>drb-IAB-r16</i> Indicates whether the IAB-MT supports DRB configuration including split DRB with one UL path, (de)ciphering on DRB and PDCP status reporting.	IAB-MT	No	No	No
<i>non-DRB-IAB-r16</i> Indicates whether the IAB-MT supports SRB2 configuration without a DRB, as specified in TS 38.331 [9].	IAB-MT	No	No	No

4.2.15.5 BAP Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>bapHeaderRewriting-Rerouting-r17</i> Indicates whether the IAB-MT supports BAP header rewriting for inter-donor-DU rerouting, as specified in TS 38.340 [23] and TS 38.300 [28]. IAB-donor-DUs can belong to the same or different IAB-donor CUs.	IAB-MT	No	No	No
<i>bapHeaderRewriting-Routing-r17</i> Indicates whether the IAB-MT supports BAP header rewriting for inter-donor CU partial migration, inter-donor-CU RLF recovery and inter-donor-CU topology redundancy, as specified in TS 38.340 [23] and TS38.300 [28].	IAB-MT	No	No	No
<i>flowControlBH-RLC-ChannelBased-r16</i> Indicates whether the IAB-MT supports flow control procedures and flow control feedback per backhaul RLC channel, as specified in TS 38.340 [23].	IAB-MT	No	No	No
<i>flowControlRouting-ID-Based-r16</i> Indicates whether the IAB-MT supports flow control procedures and flow control feedback per Routing ID, as specified in TS 38.340 [23].	IAB-MT	No	No	No

4.2.15.6 MAC Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>lcg-ExtensionIAB-r17</i> Indicates whether the IAB-MT supports extended logical channel group as specified in TS 38.321 [8]. A UE supporting this feature shall also support Extended Buffer Status Report formats and Extended Pre-emptive BSR formats (if <i>preEmptiveBSR-r16</i> is supported).	IAB-MT	No	No	No
<i>lcid-ExtensionIAB-r16</i> Indicates whether the IAB-MT supports extended Logical Channel ID space using two-octet eLCID, as specified in TS 38.321 [8].	IAB-MT	No	No	No
<i>preEmptiveBSR-r16</i> Indicates whether the IAB-MT supports Pre-emptive BSR as specified in TS 38.321 [8].	IAB-MT	No	No	No

4.2.15.7 Physical layer parameters

4.2.15.7.1 BandNR parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>handoverIntraF-IAB-r16</i> Indicates whether the IAB-MT supports intra-frequency HO. It indicates the support for intra-frequency HO from the corresponding duplex mode if this capability is included in <i>fdd-Add-UE-NR-Capabilities</i> or <i>tdt-Add-UE-NR-Capabilities</i> . It indicates the support for intra-frequency HO in the corresponding frequency range if this capability is included in <i>fr1-Add-UE-NR-Capabilities</i> or <i>fr2-Add-UE-NR-Capabilities</i> . IAB-MT shall set the capability value consistently for all FDD-FR1 bands, all TDD-FR1 bands and all TDD-FR2 bands respectively.	Band	No	N/A	N/A
<i>multipleTCI</i> Indicates whether IAB-MT supports more than one TCI state configurations per CORESET. UE is only required to track one active TCI state per CORESET. UE is required to support minimum between 64 and number of configured TCI states indicated by <i>tci-StatePD SCH</i> .	Band	No	N/A	N/A
<i>rasterShift7dot5-IAB-r16</i> Indicates whether the IAB-MT supports 7.5kHz UL raster shift in the indicated band.	Band	No	N/A	N/A

Release 17

4.2.15.7.2

Phy-Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
case6-TimingAlignmentReception-IAB-r17 Indicates whether the IAB-MT supports case 6 timing alignment reception and signalling to the parent-node that case 6 timing mode is required for simultaneous transmission as specified in TS 38.213 [11].	IAB -MT	No	No	No
case7-TimingAlignmentReception-IAB-r17 Indicates whether the IAB-MT supports case 7 timing offset indication reception and case 7 timing at parent-node indication reception as specified in TS 38.213 [11].	IAB -MT	No	No	No
dft-S-OFDM-WaveformUL-IAB-r16 Indicates whether the IAB-MT supports DFT-S-OFDM waveform for UL and transform precoding for single-layer PUSCH.	IAB -MT	No	No	No
dci-25-AI-RNTI-Support-IAB-r16 Indicates the support of monitoring DCI Format 2_5 scrambled by AI-RNTI for indication of soft resource availability to an IAB node as specified in TS 38.212 [10].	IAB -MT	No	No	No
directionalCollisionDC-IAB-r17 Indicates the support for directional collision handling between MCG and SCG cell(s) of the dual parent nodes for simultaneous operation in inter-donor and/or intra-donor DC operation.	IAB -MT	No	No	No
dl-tx-PowerAdjustment-IAB-r17 Indicates the support of desired DL Tx power adjustment reporting and DL Tx power adjustment reception.	IAB -MT	No	No	No
desired-ul-tx-PowerAdjustment-r17 Indicates the support of Desired IAB-MT PSD range reporting.	IAB -MT	No	No	No
fdm-SoftResourceAvailability-DynamicIndication-r17 Indicates the support of monitoring DCI Format 2_5 scrambled by AI-RNTI for indication of FDM soft resource availability to an IAB-node.	IAB -MT	No	No	No
guardSymbolReportReception-IAB-r16 Indicates the support of DesiredGuardSymbols reporting and ProvidedGuardSymbols reception as specified in TS 38.213 [11].	IAB -MT	No	No	No
guardSymbolReportReception-IAB-r17 Indicates the support of extended DesiredGuardSymbols reporting and ProvidedGuardSymbols reception to new switching scenarios case#6 and case#7 as specified in TS38.213 [11]. UE indicating support of this feature shall also indicate support of one or more of <i>case6-TimingAlignmentReception-IAB-r17</i> and <i>case7-TimingAlignmentReception-IAB-r17</i> . NOTE: If an IAB node does not support a certain timing mode (Case 6, Case 7), the reported/provided values shall be ignored.	IAB -MT	No	No	No
pdsch-MappingTypeA Indicates whether the IAB-MT supports receiving PDSCH using PDSCH mapping type A with less than seven symbols.	IAB -MT	No	No	No
pucch-F2-WithFH Indicates whether the IAB-MT supports transmission of a PUCCH format 2 (2 OFDM symbols in total) with frequency hopping in a slot.	IAB -MT	No	No	Yes
pucch-F3-WithFH Indicates whether the IAB-MT supports transmission of a PUCCH format 3 (4~14 OFDM symbols in total) with frequency hopping in a slot.	IAB -MT	No	No	Yes
restricted-IAB-DU-BeamReception-r17 Indicates the support of restricted IAB-DU beam reception.	IAB -MT	No	No	No
recommended-IAB-MT-BeamTransmission-r17 Indicates the support of recommended IAB-MT beam transmission for DL and UL beam.	IAB -MT	No	No	No
separateSMTC-InterIAB-Support-r16 Indicates the support of up to 4 SMTCs configurations per frequency location, including IAB-specific SMTC window periodicities.	IAB -MT	No	No	No
separateRACH-IAB-Support-r16 Indicates the support of separate RACH configurations including new IAB-specific offset and scaling factors.	IAB -MT	No	No	No
t-DeltaReceptionSupport-IAB-r16 Indicates the support of T_delta reception for case 1 OTA timing alignment as specified in TS 38.213 [11].	IAB -MT	No	No	No
ul-flexibleDL-SlotFormatSemiStatic-IAB-r16 Indicates the support of semi-static configuration/indication of UL-Flexible-DL slot formats for IAB-MT resources.	IAB -MT	No	No	No
ul-flexibleDL-SlotFormatDynamics-IAB-r16	IAB	No	No	No

4.2.15.8 MeasAndMobParameters Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
eventA-MeasAndReport Indicates whether the IAB-MT supports NR measurements and events A triggered reporting as specified in TS 38.331 [9].	IAB-MT	Yes	Yes	No
handoverInterF Indicates whether the IAB-MT supports inter-frequency HO. It indicates the support for inter-frequency HO from the corresponding duplex mode if this capability is included in fdd-Add-UE-NR-Capabilities or tdd-Add-UE-NR-Capabilities. It indicates the support for inter-frequency HO from the corresponding frequency range if this capability is included in fr1-Add-UE-NR-Capabilities or fr2-Add-UE-NR-Capabilities.	IAB-MT	No	Yes	Yes
mbfi-IAB-r16 Indicates whether the IAB-MT supports multiple frequency band indication.	IAB-MT	No	No	No
intraAndInterF-MeasAndReport Indicates whether the IAB-MT supports NR intra-frequency and inter-frequency measurements and at least periodical reporting.	IAB-MT	Yes	Yes	No

4.2.15.9 MR-DC Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
f1c-OverEUTRA-r16 Indicates whether the IAB-MT supports F1-C signalling over <i>DLInformationTransfer</i> and <i>ULInformationTransfer</i> messages via MN when IAB-MT operates in EN-DC mode, as specified in TS 36.331 [17].	IAB-MT	No	No	No
scg-DRB-NR-IAB-r16 Indicates whether the IAB-MT supports SCG DRB with NR PDCP when IAB-MT operates in EN-DC mode.	IAB-MT	No	No	No
interNR-MeasEUTRA-IAB-r16 Indicates whether the IAB-MT supports NR measurement and reports while in EUTRA connected and event B1-based measurement and reports while in EUTRA connected.	IAB-MT	No	No	No

4.2.15.10 NRDC Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
f1c-OverNR-RRC-r17 Indicates whether the IAB-MT supports F1-C signalling over <i>DLInformationTransfer</i> and <i>ULInformationTransfer</i> messages via MN when IAB-MT operates in NR-DC and MN is the non-F1-termination node or via SN when IAB-MT operates in NR-DC and SN is the non-F1-termination node, as specified in TS 38.401 [33] and TS 37.340 [7].	IAB-MT	No	No	No
simultaneousRxTx-IAB-MultipleParents-r17 Indicates the support of simultaneous transmission and reception of an IAB-node from multiple parent nodes.	BC	No	No	No

4.2.16 Sidelink Parameters

4.2.16.1 Sidelink Parameters in NR

4.2.16.1.1 Sidelink General Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
accessStratumReleaseSidelink-r16 Indicates the access stratum release for NR sidelink communication the UE supports as specified in TS 38.331 [9].	UE	Yes	No	No
relayUE-Operation-L2-r17 Indicates whether NR L2 sidelink relay UE operation is supported by the UE.	UE	No	No	No
remoteUE-Operation-L2-r17 Indicates whether NR L2 sidelink remote UE operation is supported by the UE.	UE	No	No	No
remoteUE-PathSwitchToidleInactiveRelay-r17 Indicates whether L2 sidelink remote UE supports direct to indirect path switch with target relay in RRC_IDLE or RRC_INACTIVE state.	UE	No	No	No

4.2.16.1.2 Sidelink PDCP Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
outOfOrderDeliverySidelink-r16 Indicates whether UE supports out of order delivery of data to upper layers by PDCP for sidelink.	UE	No	No	No

4.2.16.1.3 Sidelink RLC Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
am-WithLongSN-Sidelink-r16 Indicates whether the UE supports AM DRB with 18 bit length of RLC sequence number for sidelink.	UE	No	No	No
um-WithLongSN-Sidelink-r16 Indicates whether the UE supports UM DRB with 12 bit length of RLC sequence number for sidelink.	UE	No	No	No

4.2.16.1.4 Sidelink MAC Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>drx-OnSidelink-r17</i> Indicates whether UE supports sidelink DRX for unicast, groupcast and broadcast.	UE	No	No	No
<i>lcp-RestrictionSidelink-r16</i> Indicates whether UE supports the selection of logical channels for each SL grant based on RRC configured restriction.	UE	No	No	No
<i>logicalChannelSR-DelayTimerSidelink-r16</i> Indicates whether the UE supports the logicalChannelSR-DelayTimer as specified in TS 38.321 [8] for sidelink logical channel(s).	UE	No	Yes	No
<i>multipleSR-ConfigurationsSidelink-r16</i> Indicates whether the UE supports 8 SR configurations per PUCCH cell group as specified in TS 38.321 [8] for sidelink.	UE	No	Yes	No
<i>multipleConfiguredGrantsSidelink-r16</i> Indicates whether UE supports 8 sidelink configured grant configurations (including both Type 1 and Type 2) in a resource pool. If absent, for each resource pool, the UE only supports one sidelink configured grant configuration.	UE	No	No	No

4.2.16.1.5 Other PHY parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>p0-OLPC-Sidelink-r17</i> Indicates whether the UE supports the use of P0 parameters (i.e. <i>dl-P0-PSSCH-PSCCH-r17</i> , <i>sl-P0-PSSCH-PSCCH-r17</i> , <i>dl-P0-PSBCH-r17</i> , <i>dl-P0-PSFCH-r17</i>) for sidelink open loop power control.	UE	No	No	No
<i>supportedBandCombinationListSidelinkEUTRA-NR-r16</i> Defines the supported NR sidelink communication and/or V2X sidelink communication band combinations by the UE. A fallback band combination resulting from the reported sidelink band combination shall be supported by the UE. The UE does not include this field if the UE capability is requested by E-UTRAN (see TS 36.331 [17]) and the network request includes the field <i>eutra-nr-only</i> .	UE	No	No	No
<i>supportedBandCombinationListSidelinkNR-r16</i> Defines the supported joint NR sidelink communication band combinations by the UE. A fallback band combination resulting from the reported sidelink band combination shall be supported by the UE.	UE	No	No	No
<i>supportedBandCombinationListSL-NonRelayDiscovery-r17</i> Defines the supported band combinations of NR sidelink non-relay discovery message transmission and reception by the UE.	UE	No	No	No
<i>supportedBandCombinationListSL-RelayDiscovery-r17</i> Defines the supported band combinations of NR sidelink relay discovery message transmission and reception by the UE. This parameter is used by the remote UE and relay UE, and for the case of L2 and L3 relay.	UE	No	No	No
<i>supportedBandListSidelink-r16</i> Indicates frequency bands supported for NR sidelink communications and parameters supported for each frequency band, as specified in 4.2.16.1.6. If a band is included in <i>supportedBandCombinationListSL-NonRelayDiscovery-r17</i> or <i>supportedBandCombinationListSL-RelayDiscovery-r17</i> , the band supports non-relay/relay NR sidelink discovery.	UE	No	No	No

Release 17

4.2.16.1.6

BandSidelink Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>sl-Reception-r16 Indicates whether receiving NR sidelink communication is supported. If supported, this parameter indicates the support of the capabilities and includes the parameters as follows:</p> <ul style="list-style-type: none"> - UE can receive NR PSCCH/PSSCH. - <i>harq-RxProcessSidelink</i>, which indicates the number of sidelink HARQ processes across all links that the UE supports for NR PSSCH reception. Value n16 corresponds to 16, n24 corresponds to 24, and so on. - <i>pssch-RxSidelink</i>, which indicates the number of PSSCH that the supports for reception in a slot. Value value1 corresponds to floor ($N_{RB} / 10$ RBs), value2 corresponds to $2 * \text{floor} (N_{RB} / 10 \text{ RBs})$; - UE can attempt to decode N_{RB} non-overlapping RBs per slot. - UE supports reception of PSSCH according to the 64QAM MCS table. - UE supports PT-RS reception in FR2. - <i>scs-CP-PatternRxSidelink</i>, which indicates the subcarrier spacing with normal CP and the corresponding channel bandwidth that the UE supports for NR sidelink communication reception. Value scs-15kHz corresponds to 15kHz, scs-30kHz corresponds to 30kHz, and so on. It is mandatory for UE to support reception using 30 kHz subcarrier spacing with normal CP in FR1, and 120 kHz subcarrier spacing with normal CP FR2. For FR1, the bits in scs-XXkHz starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60, 70, 80, 90 and 100MHz. For FR2, the bits in scs-XXkHz starting from the leading / leftmost bit indicate 50, 100 and 200MHz. This capability is not required to be signalled in a band indicated with only the PC5 interface in TS 38.101-1 [2], Table 5.2E.1-1. Otherwise, it is mandatory. For a band indicated with only the PC5 interface in 38.101-1 [2], Table 5.2E.1-1, UE supports reception using 30 kHz subcarrier spacing with normal CP in FR1, 120 kHz subcarrier spacing with normal CP in FR2. - <i>extendedCP-RxSidelink</i>, which indicates whether the UE supports 60 kHz subcarrier spacing with extended CP length for NR sidelink communication reception. This capability is not required to be signalled in a band indicated with only the PC5 interface in TS 38.101-1 [2], Table 5.2E.1-1. Otherwise, it is mandatory. - UE supports 14-symbol SL slot with all DMRS patterns corresponding to number of PSSCH symbols = {12, 9} for slots with and without PSFCH. If UE signals support of extended CP, support 12-symbol SL slot with all DMRS patterns corresponding to number of PSSCH symbols = {10,7} for slots with and without PSFCH. <p>NOTE 1: N_{RB} is the number of RBs defined per channel bandwidth by RAN4 in TS 38.101-1 [2], Table 5.3.2-1 for FR1 and TS 38.101-2 [3], Table 5.3.2.-1 for FR2.</p> <p>NOTE 2: Configuration by NR Uu is not required to be supported in a band indicated with only the PC5 interface in TS 38.101-1 [2] Table 5.2E.1-1.</p> <p>Support of this feature is mandatory if UE supports NR sidelink. If a band is included in <i>supportedBandCombinationListSL-NonRelayDiscovery-r17</i> or <i>supportedBandCombinationListSL-RelayDiscovery-r17</i>, it indicates whether receiving non-relay/relay NR sidelink discovery is supported.</p>	Band	CY	N/A	N/A
<p>sl-TransmissionMode1-r16 Indicates whether transmitting NR sidelink mode 1 scheduled by Uu is supported. If supported, this parameter indicates the support of the capabilities and includes the parameters as follows:</p> <ul style="list-style-type: none"> - UE can transmit PSCCH/PSSCH using configured grant type 1. For NR sidelink mode 1 scheduled by NR Uu, UE can additionally transmit PSCCH/ PSSCH using dynamic scheduling or configured grant type 2. Up to 8 configured grants can be configured for a UE. - <i>harq-TxProcessModeOneSidelink</i>, which indicates the number of sidelink HARQ processes across all links that the UE supports for NR PSSCH transmission using mode 1, including those for configured grants. Value n8 	Band	CY	N/A	N/A

Release 17

Release 17

4.2.16.1.7

BandCombinationListSidelinkEUTRA-NR Parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>tx-Sidelink-r16 Indicates whether the UE supports sidelink transmission on the band. For NR sidelink, this field is only applicable if the UE supports at least one of <i>sl-TransmissionMode1-r16</i> and <i>sl-TransmissionMode2-r16</i> on the band.</p>	Band	No	N/A	N/A
<p>rx-Sidelink-r16 Indicates whether the UE supports sidelink reception on the band. For NR sidelink, this field is only applicable if the UE supports <i>sl-Reception-r16</i> on the band.</p>	Band	No	N/A	N/A
<p>sl-CrossCarrierScheduling-r16 Indicates whether the UE supports monitoring DCI format 3_0 on a different carrier from sidelink for NR sidelink dynamic scheduling and configured grant type 2. If the UE indicates support for <i>sl-TransmissionMode1-r16</i> in a band indicated with only the PC5 interface in Table 5.2E.1-1 of TS 38.101-1 [2], the UE shall indicate that <i>sl-CrossCarrierScheduling-r16</i> is supported for a band combination with that band. For NR sidelink, this field is only applicable if the UE supports <i>sl-TransmissionMode1-r16</i> on the band.</p>	Band	No	N/A	N/A
<p>sl-TransmissionMode2-PartialSensing-r17 Indicates transmitting NR sidelink mode 2 with partial sensing is supported. If supported, this parameter indicates the support of the capabilities and includes the parameters as follows:</p> <ul style="list-style-type: none"> - UE can transmit PSCCH/PSSCH using NR sidelink mode 2 with partial sensing configured by NR Uu or preconfiguration. - <i>harq-TxProcessModeTwoSidelink-r17</i>, which indicates the number of sidelink HARQ processes across all links that the UE supports for NR PSSCH transmission using mode 2. Value n8 corresponds to 8, n16 corresponds to 16. - UE can transmit PSSCH according to the normal 64QAM MCS table. - UE supports PT-RS transmission in FR2. - UE can perform periodic-based partial sensing and resource allocation operation. - UE can perform contiguous partial sensing and resource allocation operation. - <i>scs-CP-PatternTxSidelinkModeTwo-r17</i>, the subcarrier spacing with normal CP and the corresponding bandwidth that the UE supports for NR sidelink communication transmission using NR sidelink mode 2 with partial sensing. Value <i>scs-15kHz</i> corresponds to 15kHz, <i>scs-30kHz</i> corresponds to 30kHz, and so on. For FR1, the bits in <i>scs-XXkHz</i> starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60, 70, 80, 90 and 100MHz. For FR2, the bits in <i>scs-XXkHz</i> starting from the leading / leftmost bit indicate 50, 100 and 200MHz. This capability is not required to be signalled in a band indicated with only the PC5 interface in TS 38.101-1 [2], Table 5.2E.1-1. Otherwise, it is mandatory. For a band indicated with only the PC5 interface in TS 38.101-1 [2], Table 5.2E.1-1, UE supports transmission using 30 kHz subcarrier spacing with normal CP in FR1, 120 kHz subcarrier spacing with normal CP in FR2. - <i>extendedCP-Mode2PartialSensing-r17</i>, which indicates whether the UE supports 60 kHz subcarrier spacing with extended CP length for NR sidelink communication transmission using mode 2 with partial sensing. - UE supports 14-symbol SL slot with all DMRS patterns corresponding to the number of PSSCH symbols = {12, 9} for slots with and without PSFCH. If UE signals support of extended CP, support 12-symbol SL slot with all DMRS patterns corresponding to the number of PSSCH symbols = {10,7} for slots with and without PSFCH. - <i>dl-openLoopPC-Sidelink-r17</i>, which indicates whether UE supports DL pathloss based open loop power control when mode 2 is configured by NR Uu, if the band is indicated with only the PC5 interface in TS 38.101-1 [2], Table 5.2E.1-1. Otherwise, it is mandatory. <p>UE supporting this feature shall support receiving NR sidelink of S-SSB or indicate support of <i>sync-Sidelink-r16</i> or <i>sync-Sidelink-v1710</i>. If a band combination is included in <i>supportedBandCombinationListSL-NonRelayDiscovery-r17</i> or <i>supportedBandCombinationListSL-RelayDiscovery-r17</i>, it indicates whether transmitting NR sidelink mode 2 with partial sensing is supported for non-relay/relay NR sidelink discovery.</p>	FS	No	N/A	N/A
NOTE 1: Configuration by NR Uu is not required to be supported in a band				

4.2.16.2 Sidelink Parameters in E-UTRA

Descriptions for parameters	Per	M	FDD-TDD DIFF
supportedBandListSidelinkEUTRA-r16 Indicates E-UTRA frequency bands supported for V2X sidelink communications and parameters supported for each frequency band, as specified in 4.2.16.2.1.	UE	No	No

4.2.16.2.1 BandSideLinkEUTRA parameters

Descriptions for parameters	Per	M	FDD-TDD DIFF
gnb-ScheduledMode3SidelinkEUTRA-r16 Indicates whether transmitting V2X sidelink communication mode 3 scheduled by NR Uu is supported. If supported, this parameter indicates the support of the capabilities and includes the parameters as follows: <ul style="list-style-type: none"> - the UE can be scheduled by gNB using DCI format 3_1 for V2X sidelink mode 3 transmission. - <i>gnb-ScheduledMode3DelaySidelinkEUTRA</i>, which indicates the minimum value UE supports for the additional time indicated in the NR DCI scheduling V2X sidelink mode 3. Value ms0 corresponds to 0 ms, ms0dot25 corresponds to 0.25 ms, and so on. This field is only applicable if the UE supports V2X sidelink communication.	Band	No	N/A
gnb-ScheduledMode4SidelinkEUTRA-r16 Indicates whether the UE can be scheduled by gNB for V2X sidelink mode 4 transmission. This field is only applicable if the UE supports V2X sidelink communication.	Band	No	N/A

4.2.17 SON parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
onDemandSI-Report-r17 Indicates whether the UE supports delivery of on-Demand SI information upon request from the network as specified in TS 38.331 [9].	UE	No	No	No
pscell-MHI-Report-r17 Indicates whether the UE supports the storage of PSCell mobility history information and the reporting in <i>UEInformationResponse</i> message as specified in TS 38.331 [9].	UE	No	No	No
rach-Report-r16 Indicates whether the UE supports delivery of RA report upon request from the network.	UE	No	No	No
rlfReportCHO-r17 Indicates whether the UE supports RLF-Report for conditional handover.	UE	No	No	No
rlfReportDAPS-r17 Indicates whether the UE supports RLF-Report for DAPS handover.	UE	No	No	No
success-HO-Report-r17 Indicates whether the UE supports the storage and delivery of Successful Handover Report upon request from the network as specified in TS 38.331 [9].	UE	No	No	No
twoStepRACH-Report-r17 Indicates whether the UE supports the storage and delivery of 2-step RACH related information upon request from the network as specified in TS 38.331 [9].	UE	No	No	No

4.2.18 UE-based performance measurement parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
barometerMeasReport-r16 Indicates whether the UE supports uncompensated barometric pressure measurement reporting upon request from the network.	UE	No	No	No
earlyMeasLog-r17 Indicates whether the UE supports the storage of Early Measurement Logging in logged measurements and the reporting upon request from the network as specified in TS 38.331 [9].	UE	No	No	No
excessPacketDelay-r17 Indicates whether the UE supports the UL PDCP excess packet delay measurement per DRB as specified in TS 38.314 [26]. A UE that supports the UL PDCP excess packet delay measurement shall also support the measurement configuration and reporting as specified in TS 38.331 [9].	UE	No	No	No
gnss-Location-r16 Indicates whether the UE is equipped with a GNSS or A-GNSS receiver that may be used to provide detailed location information along with SON, MDT, and NTN related measurements in RRC_CONNECTED, RRC_IDLE and RRC_INACTIVE state. A UE shall set this field to <i>supported</i> if it indicates the support of <i>nonTerrestrialNetwork-r17</i> .	UE	CY	No	No
immMeasBT-r16 Indicates whether the UE supports Bluetooth measurements in RRC_CONNECTED state.	UE	No	No	No
immMeasWLAN-r16 Indicates whether the UE supports WLAN measurements in RRC_CONNECTED state.	UE	No	No	No
loggedMeasBT-r16 Indicates whether the UE supports Bluetooth measurements in RRC_IDLE and RRC_INACTIVE state.	UE	No	No	No
loggedMeasurements-r16 Indicates whether the UE supports logged measurements in RRC_IDLE and RRC_INACTIVE state. A UE that supports logged measurements shall support both periodical logging and event-triggered logging. The minimum memory size of MDT logged measurements is 64KB.	UE	No	No	No
loggedMeasWLAN-r16 Indicates whether the UE supports WLAN measurements in RRC_IDLE and RRC_INACTIVE state.	UE	No	No	No
multipleCEF-Report-r17 Indicates whether the UE supports the storage and delivery of multiple CEF reports upon request from the network as specified in TS 38.331 [9].	UE	No	No	No
orientationMeasReport-r16 Indicates whether the UE supports orientation information reporting upon request from the network.	UE	No	No	No
sigBasedLogMDT-OverrideProtect-r17 Indicates whether the UE supports the override protection of the signalling based logged measurements configured in NR.	UE	No	No	No
speedMeasReport-r16 Indicates whether the UE supports speed information reporting upon request from the network.	UE	No	No	No
ulPDCP-Delay-r16 Indicates whether the UE supports UL PDCP Packet Average Delay measurement (as specified in TS 38.314 [26]) and reporting in RRC_CONNECTED state.	UE	No	No	No

4.2.19 High speed parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<p>demodulationEnhancement-r16 Indicates whether the UE supports the enhanced demodulation processing for HST-SFN joint transmission scheme with velocity up to 500km/h as specified in TS 38.101-4 [18]. This field applies to MN configured demodulation enhancement when MR-DC is not configured and SN configured demodulation enhancement when (NG)EN-DC is configured.</p>	UE	No	No	FR1 only
<p>intraNR-MeasurementEnhancement-r16 Indicates whether the UE supports the enhanced intra-NR RRM requirements to support high speed up to 500 km/h as specified in TS 38.133 [5]. This field applies to MN configured measurement enhancement when MR-DC is not configured and SN configured measurement enhancement when (NG)EN-DC is configured. The UE can include this field only if the UE does not indicate the support of <i>measurementEnhancement-r16</i> and <i>interRAT-MeasurementEnhancement-r16</i>. Otherwise, the UE does not include this field.</p>	UE	No	No	FR1 only
<p>interRAT-MeasurementEnhancement-r16 Indicates whether the UE supports the enhanced inter-RAT E-UTRAN RRM requirements to support high speed up to 500 km/h as specified in TS 38.133 [5]. This field applies to MN configured measurement enhancement. The UE can include this field only if the UE does not indicate the support of <i>measurementEnhancement-r16</i> and <i>intraNR-MeasurementEnhancement-r16</i>. Otherwise, the UE does not include this field.</p>	UE	No	No	FR1 only
<p>measurementEnhancement-r16 Indicates whether the UE supports the enhanced intra-NR and inter-RAT E-UTRAN RRM requirements for MN configured measurement enhancement when MR-DC is not configured, and the enhanced intra-NR RRM requirements for SN configured measurement enhancement when (NG)EN-DC is configured, to support high speed up to 500 km/h as specified in TS 38.133 [5].</p>	UE	No	No	FR1 only
<p>measurementEnhancementCA-r17 Indicates whether the UE supports the enhanced RRM requirements for carrier aggregation to support high speed up to 500 km/h as specified in TS 38.133 [5]. UE indicating support of this feature shall indicate support of <i>measurementEnhancement-r16</i> or <i>intraNR-MeasurementEnhancement-r16</i>.</p>	UE	No	No	FR1 only
<p>measurementEnhancementInterFreq-r17 Indicates whether the UE supports the enhanced RRM requirements for inter-frequency measurements in connected mode to support high speed up to 500 km/h as specified in TS 38.133 [5]. UE indicating support of this feature shall indicate support of <i>measurementEnhancement-r16</i> or <i>intraNR-MeasurementEnhancement-r16</i>.</p>	UE	No	No	FR1 only

4.2.20 Application layer measurement parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>qoe-Streaming-MeasReport-r17</i> Indicates whether the UE supports NR QoE Measurement Collection for streaming services, see TS 26.247 [29].	UE	No	No	No
<i>qoe-MTSI-MeasReport-r17</i> Indicates whether the UE supports NR QoE Measurement Collection for MTSI services, see TS 26.114 [30].	UE	No	No	No
<i>qoe-VR-MeasReport-r17</i> Indicates whether the UE supports NR QoE Measurement Collection for VR services, see TS 26.118 [31].	UE	No	No	No
<i>ran-VisibleQoE-Streaming-MeasReport-r17</i> Indicates whether the UE supports RAN visible QoE Measurement Collection for streaming services. A UE supporting this feature shall also support <i>qoe-Streaming-MeasReport-r17</i> .	UE	No	No	No
<i>ran-VisibleQoE-VR-MeasReport-r17</i> Indicates whether the UE supports RAN visible QoE Measurement Collection for VR services. A UE supporting this feature shall also support <i>qoe-VR-MeasReport-r17</i> .	UE	No	No	No
<i>ul-MeasurementReportAppLayer-Seg-r17</i> Indicates whether the UE supports RRC segmentation of the MeasurementReportAppLayer message in UL, as specified in TS 38.331 [9].	UE	No	No	No

4.2.21 RedCap Parameters

4.2.21.1 Definition of RedCap UE

RedCap UE is the UE with reduced capability:

- The maximum bandwidth is 20 MHz for FR1, and is 100 MHz for FR2. UE features and corresponding capabilities related to UE bandwidths wider than 20 MHz in FR1 or wider than 100 MHz in FR2 are not supported by RedCap UEs;
- The maximum mandatory supported DRB number is 8;
- The mandatory supported PDCP SN length is 12 bits while 18 bits being optional;
- The mandatory supported RLC AM SN length is 12 bits while 18 bits being optional;
- For FR1, 1 DL MIMO layer if 1 Rx branch is supported, and 2 DL MIMO layers if 2 Rx branches are supported; for FR2, either 1 or 2 DL MIMO layers can be supported, while 2 Rx branches are always supported. For FR1 and FR2, UE features and corresponding capabilities related to more than 2 UE Rx branches or more than 2 DL MIMO layers, as well as UE features and capabilities related to more than 1 UE Tx branch or more than 1 UL MIMO layer are not supported by RedCap UEs;
- CA, MR-DC, DAPS, CPAC and IAB (i.e., the RedCap UE is not expected to act as IAB node) related UE features and corresponding capabilities are not supported by RedCap UEs. All other feature groups or components of the feature groups as captured in TR 38.822 [24] as well as capabilities specified in this specification remain applicable for RedCap UEs same as non-RedCap UEs, unless indicated otherwise.

4.2.21.2 General parameters

Definitions for parameters	Per	M	FDD-TDD DIFF
<i>ncd-SSB-ForRedCapInitialBWP-SDT-r17</i> Indicates that the UE supports using RedCap-specific initial DL BWP associated with NCD-SSB for SDT. If absent, the UE only supports SDT in an initial DL BWP that includes the CD-SSB. UE supporting this feature shall indicate support of <i>supportOfRedCap-r17</i> and <i>ra-SDT-r17</i> and/or <i>cg-SDT-r17</i> .	UE	No	No
<i>supportOf16DRB-RedCap-r17</i> Indicates whether the RedCap UE supports 16 DRBs. This capability is only applicable for RedCap UEs.	UE	No	No
<i>supportOfRedCap-r17</i> Indicates that the UE is a RedCap UE with comprised of at least the following functional components: <ul style="list-style-type: none"> - Maximum FR1 RedCap UE bandwidth is 20 MHz; - Maximum FR2 RedCap UE bandwidth is 100 MHz; - Support of RedCap early indication based on Msg1, MsgA (if UE indicated support of <i>twoStepRACH-r16</i>) and Msg3 for random access; - Separate initial UL BWP for RedCap UEs; <ul style="list-style-type: none"> - It includes the configuration(s) needed for RedCap UE to perform random access - Enabling/disabling of frequency hopping for common PUCCH resources - Separate initial DL BWP for RedCap UEs; <ul style="list-style-type: none"> - It includes CSS/CORESET for random access - For separate initial DL BWP used for paging, CD-SSB is included - For separate initial DL BWP only used for RACH, SSB may or may not be included - For separate initial DL BWP used in connected mode as BWP#0 configuration option 1, CD-SSB is included - 1 UE-specific RRC configured DL BWP per carrier; - 1 UE-specific RRC configured UL BWP per carrier; - UE-specific RRC-configured DL BWP with CD-SSB or NCD-SSB; - NCD-SSB based measurements in RRC-configured DL BWP. A RedCap UE shall set the field to <i>supported</i> .	UE	CY	No

4.2.21.3 PDCP parameters

Definitions for parameters	Per	M	FDD-TDD DIFF
<i>longSN-RedCap-r17</i> Indicates whether the RedCap UE supports 18 bit length of PDCP sequence number. This capability is only applicable for RedCap UEs.	UE	No	No

4.2.21.4 RLC parameters

Definitions for parameters	Per	M	FDD-TDD DIFF
<i>am-WithLongSN-RedCap-r17</i> Indicates whether the RedCap UE supports AM DRB with 18 bit length of RLC sequence number. This capability is only applicable for RedCap UEs.	UE	No	No

4.2.21.5 MeasAndMobParameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>rrm-RelaxationRRC-ConnectedRedCap-r17</i> Indicates whether UE supports Rel-17 relaxed RRM measurements in RRC_CONNECTED as specified in TS 38.331 [9].	UE	No	No	No

4.2.21.6 Physical layer parameters

4.2.21.6.1 BandNR parameters

Definitions for parameters	Per	M	FDD-TDD DIFF	FR1-FR2 DIFF
<i>bwp-WithoutCD-SSB-OrNCD-SSB-RedCap-r17</i> Indicates support of RRC-configured DL BWP without CD-SSB or NCD-SSB. The UE can include this field only if the UE supports <i>supportOfRedCap-r17</i> .	Band	No	N/A	N/A
<i>halfDuplexFDD-TypeA-RedCap-r17</i> Indicates support of Half-duplex FDD operation (instead of full-duplex FDD operation) type A for RedCap UE. The UE can include this field only if the UE supports <i>supportOfRedCap-r17</i> .	Band	No	FDD only	FR1 only

5 Optional features without UE radio access capability parameters

5.1 PWS features

Definitions for feature
CMAS It is optional for UE to support CMAS reception as specified in TS 38.331 [9]. It is optional for a CMAS-capable UE to support Geofencing information (<i>warningAreaCoordinates</i>) as specified in TS 38.331 [9].
ETWS It is optional for UE to support ETWS reception as specified in TS 38.331 [9].
KPAS It is optional for UE to support Korean Public Alert System (KPAS) reception as specified in TS 38.331 [9]. KPAS uses the same AS mechanisms as defined for CMAS. Therefore a KPAS-capable UE shall support all behaviour that is included in TS 38.331 [9] and TS 38.304 [21] for a CMAS-capable UE.
EU-Alert It is optional for UE to support EU-Alert reception as specified in TS 38.331 [9]. EU-Alert uses the same AS mechanisms as defined for CMAS. Therefore a EU-Alert-capable UE shall support all behaviour that is included in TS 38.331 [9] and TS 38.304 [21] for a CMAS-capable UE.

5.2 UE receiver features

Definitions for feature
SU-MIMO Interference Mitigation advanced receiver <ul style="list-style-type: none"> - R-ML (reduced complexity ML) receivers with enhanced inter-stream interference suppression for SU-MIMO transmissions with rank 2 with 2 RX antennas - R-ML (reduced complexity ML) receivers with enhanced inter-stream interference suppression for SU-MIMO transmissions with rank 2, 3, and 4 with 4 RX antennas UE supporting the feature is required to meet the Enhanced Receiver Type requirements in TS 38.101-4 [18].

5.3 RRC connection

Definitions for feature
<p>RRC connection release with deprioritisation It is optional for UE to support <i>RRCRelease</i> with <i>deprioritisationReq</i> as specified in TS 38.331 [9].</p>
<p>RRC connection establishment failure with temporary offset It is optional for UE to support RRC connection establishment failure with temporary offset (<i>Qoffsettemp</i>) as specified in TS 38.331 [9].</p>
<p>Selection of acceptable E-UTRA cell upon HO failure during EPS fallback for emergency call It is optional for UE to support selecting an acceptable E-UTRA cell supporting emergency call if no suitable E-UTRA cell is available upon handover failure during EPS fallback when the UE has an ongoing emergency call as specified in TS 38.331 [9].</p>
<p>E-UTRA cell selection upon HO failure during EPS services fallback It is optional for UE to support selecting a suitable E-UTRA cell, and support selecting an acceptable E-UTRA cell supporting emergency call if no suitable E-UTRA cell is available upon handover failure when the UE is performing emergency services fallback as specified in TS 38.331 [9].</p>

5.4 Other features

Definitions for feature
<p>eCall over IMS It is optional for UE to support eCall over IMS as specified in TS 38.331 [9].</p>
<p>Access Category 1 selection assistance information enhancement It is optional for UE that is configured for delay tolerant service to support Access Category 1 selection assistance information enhancement, according to <i>uac-AC1-SelectAssistInfo-r16</i> as specified in TS 38.331 [9].</p>
<p>Random access prioritization for MPS and MCS It is optional for UE that is configured for MPS or MCS to support random access prioritization for Access Identity 1 or 2 as specified in TS 38.321 [8].</p>
<p>HSDN cell reselection It is optional for UE to support HSDN cell reselection priority handling in RRC_IDLE/RRC_INACTIVE as specified in TS 38.304 [21] and TS 38.331 [9].</p>
<p>TRS occasions for idle mode and RRC_INACTIVE UEs It is optional for UE to support reading TRS configuration from SIB and receiving L1 indication for TRS availability.</p> <p>NOTE: Receiving L1 indication via DCI format 2_7 is supported only if the UE supports receiving DCI format 2_7.</p>
<p>Minimization of service interruption It is optional for UE to support minimization of service interruption including reporting to NAS of disaster roaming information for available PLMNs and Access Barring check for Access Identity 3, as specified in TS 38.331 [9].</p>
<p>Random access prioritisation for Slicing It is optional for UE to support slice-based prioritisation for random access as specified in TS 38.321 [8].</p>
<p>Random access partitioning for Slicing It is optional for UE to support slice-based RACH partitioning as specified in TS 38.321 [8].</p>
<p>Relaxed cell reselection on GEO It is optional for UE to support the relaxed cell reselection on GEO.</p>
<p>Support of polarization signalling in NR NTN It is optional for UE to support the polarization signalling in NR NTN comprised of the following functional components:</p> <ul style="list-style-type: none"> - Support polarization indication reception in SIB indicating DL and/or UL polarization information using respective polarization type parameters to indicate: RHCP or LHCP or linear; - Support polarization signalling for target serving cell in handover command message; - Support polarization signalling for non-serving cell in RRM measurement configuration.

5.5 Sidelink Features

Definitions for feature
<p>Short-term time-scale TDM for in-device coexistence It is optional for UE to support prioritization between LTE sidelink transmission/reception and NR sidelink transmission/reception. This field is only applicable if the UE supports at least one of <i>sl-Reception-r16</i>, <i>sl-TransmissionMode1-r16</i> and <i>sl-TransmissionMode2-r16</i>, and if the UE supports V2X sidelink communication in the band combination.</p>
<p>Rank 2 PSSCH transmission It is optional for UE to support rank 2 PSSCH transmission. This field is only applicable if the UE supports <i>csi-ReportSidelink-r16</i> with <i>csi-RS-PortsSidelink</i> = p2.</p>
<p>Receiving NR sidelink of S-SSB It is optional for UE to receive S-SSB in NR sidelink and support synchronisation to a reference UE.</p>

5.6 RRM measurement features

Definitions for feature
<p>High speed inter-frequency IDLE/INACTIVE measurements It is optional for UE to support high speed inter-frequency measurements in RRC_IDLE/RRC_INACTIVE as specified in TS 38.133 [5].</p>
<p>Location-based measurement initiation It is optional for the UE in RRC_IDLE/RRC_INACTIVE to support location based RRM measurements of neighbour cells in NTN quasi-Earth fixed system as specified in TS 38.304 [21].</p>
<p>Relaxed measurement It is optional for UE to support relaxed RRM measurements of neighbour cells in RRC_IDLE/RRC_INACTIVE as specified in TS 38.304 [21].</p>
<p>Rel-17 relaxed measurement for RRC_IDLE/RRC_INACTIVE It is optional for RedCap UE to support Rel-17 relaxed RRM measurements of neighbour cells in RRC_IDLE/RRC_INACTIVE as specified in TS 38.304 [21].</p>
<p>Enhanced RRM requirements for measurements in IDLE and INACTIVE modes It is optional for UE to support enhanced RRM requirements for measurements for NTN bands (FR1 only and FDD only) in RRC_IDLE/RRC_INACTIVE as specified in TS 38.133 [5]. If UE does not support this feature, other NTN measurement requirements (as specified in TS 38.133 [5], clause 4.2C.2 for RRC_IDLE and clause 5.1C.2 for RRC_INACTIVE) are applied for both LEO and GEO.</p>
<p>Time-based measurement initiation It is optional for the UE in RRC_IDLE/RRC_INACTIVE to support time based RRM measurements of neighbour cells in NTN quasi-Earth fixed system as specified in TS 38.304 [21].</p>

5.7 MDT and SON features

Definitions for feature
<p>Mobility history information storage It is optional for UE to support the storage of PCell mobility history information and the reporting in <i>UEInformationResponse</i> message as specified in TS 38.331 [9].</p>
<p>Cross RAT RLF Report It is optional for UE to support the delivery of EUTRA RLF report to an NR node upon request from the network.</p>
<p>Radio Link Failure Report for inter-RAT MRO EUTRA It is optional for UE to support:</p> <ul style="list-style-type: none"> - Inclusion of EUTRA CGI and associated TAC, if available, and otherwise to include the physical cell identity and carrier frequency of the target PCell of the failed handover as <i>failedPCellId</i> in <i>RLF-Report</i> upon request from the network as specified in TS 38.331 [9]. - Inclusion of EUTRA CGI and associated TAC as <i>previousPCellId</i> in <i>RLF-Report</i> as specified in TS 38.331 [9]. - Inclusion of <i>eutraReconnectCellId</i> in <i>reconnectCellId</i> in the <i>RLF-Report</i> as specified in TS 38.331 [9] upon UE has radio link failure or handover failure and successfully re-connected to an E-UTRA cell.
<p>SCG Failure Report for MRO It is optional for UE to support the delivery of the SCG failure related parameters for MRO in <i>SCGFailureInformation</i> message to the network.</p>
<p>SpCell ID indication It is optional for UE to support the delivery of the <i>spCellId-r17</i> in the RA-Report, if the RA procedure is performed in a SCell of the MCG/SCG.</p>

5.8 Extended DRX features

Definitions for feature
<p>Rel-17 extended DRX in RRC_IDLE It is optional for UE to support Rel-17 extended DRX cycle up to 10485.76 seconds and paging in extended DRX in RRC_IDLE as specified in TS 38.331 [9] and TS 38.304 [21]. A UE that supports extended DRX shall also support <i>inactiveStatePO-Determination-r17</i>.</p>

5.9 Sidelink Relay Features

Definitions for feature
<p>L3 sidelink relay UE operation It is optional for UE to support L3 sidelink relay UE operation as specified in TS 38.331 [9].</p>
<p>L3 sidelink remote UE operation It is optional for UE to support L3 sidelink remote UE operation as specified in TS 38.331 [9].</p>

5.10 MBS features

Definitions for feature

Broadcast reception

It is optional for UE to support broadcast reception as specified in TS 38.331 [9]. A UE that supports the feature shall also support:

- Group-common PDCCH/PDSCH for broadcast with CRC scrambled by MCCH-RNTI;
- Group-common PDCCH/PDSCH for broadcast with CRC scrambled by G-RNTI(s) for MTCH;
- CFR configuration for broadcast;
- CORESET and common search space for broadcast;
- DCI format 4_0 with CRC scrambled with G-RNTI/MCCH-RNTI for broadcast;
- Inter-slot TDM between unicast PDSCH and MCCH group-common PDSCH or MTCH group-common PDSCH, or between MCCH group-common PDSCH and MTCH group-common PDSCH, or among unicast PDSCH and MCCH group-common PDSCH and MTCH group-common PDSCH in different slots;
- MCCH change notification indication via DCI;
- RRC configured slot-level repetition up to 8 for MTCH;
- One G-RNTI per UE is supported for broadcast reception;
- Support of FD-Med MCCH and PBCH;
- Support of up to 64QAM for FR1/FR2;
- 4 broadcast MRBs as the minimum number;
- PDCP 12 bits SN;
- ROHC with profiles 0x0000, 0x0001 and 0x0002;
- 4 ROHC context sessions;
- RLC UM with 6 bits SN;
- RLC UM with 12 bits SN;
- DRX with long DRX cycle for MBS broadcast as specified in TS 38.321 [8].

5.11 Idle/inactive measurement for voice fallback features

Definitions for feature

Idle/Inactive measurement for voice fallback

It is optional for UE to support the idle/inactive measurement for EPS fallback in RRC_IDLE/RRC_INACTIVE as specified in TS 38.331 [9].

6 Conditionally mandatory features without UE radio access capability parameters

Features	Condition
Acquisition of SI messages with explicit SI window positions	It is mandatory to support acquisition of SI messages with explicit SI window positions for UEs which support the SIB types in <i>schedulingInfoList2</i> as specified in TS 38.331 [9].
AS layer memory size for QoE paused measurement reports	It is mandatory to support the minimum AS layer memory size of 64KB for QoE paused measurement reports for UEs which support <i>qoe-Streaming-MeasReport-r17</i> , <i>qoe-MTSI-MeasReport-r17</i> or <i>qoe-VR-MeasReport-r17</i> .
Downlink SDAP header	Either NAS reflective QoS or <i>as-ReflectiveQoS</i> is supported.
Extended values for <i>drx-HARQ-RTT-TimerDL/UL</i>	It is mandatory for UEs which support FR2-2 bands with SCS 480kHz and/or 960kHz.
IMS emergency call	It is mandatory to support IMS emergency call over PLMN for UEs which are IMS voice capable in NR. It is mandatory to support IMS emergency call over SNPN for UEs that are SNPN capable and IMS voice capable over SNPNS.
Logged measurements suspension due to IDC interference	It is mandatory to support Logged measurements suspension due to IDC interference for UEs which are supporting logged measurements in RRC_IDLE and RRC_INACTIVE upon request from the network and in-device coexistence indication as specified in TS 38.331 [9].
MAC subheaders with one-octet eLCID field	It is mandatory to support MAC subheaders with one-octet eLCID field for UEs/IAB-MTs supporting MAC CEs using extended LCID values as specified in TS 38.321 [8].
Paging cause in RAN paging message	It is mandatory for a UE to support paging cause in RAN paging if UE supports paging cause in CN paging.
Skipping UL configured grant if no data to transmit, as specified in release-15 version of TS 38.321 [8].	Either <i>configuredUL-GrantType1</i> or <i>configuredUL-GrantType1-v1650</i> or <i>configuredUL-GrantType2</i> or <i>configuredUL-GrantType2-v1650</i> is supported.
TA reporting during initial access	It is mandatory to support TA reporting during initial access for UEs supporting <i>uplink-TA-Reporting-r17</i> as specified in TS 38.321 [8].

7 Void

8 UE Capability Constraints

The following table lists constraints indicating the UE capabilities that the UE shall support.

Release 17

Parameter	Description	Value
#DRBs	The number of DRBs that a UE shall support.	8 per UE, for RedCap UEs. 16 per UE, otherwise. NOTE 1 NOTE 3 NOTE 4
#minCellperMeasObjectNR	The minimum number of neighbour cells (excluding exclude-list cells) that a UE shall be able to store associated with a MeasObjectNR.	32 NOTE 2
#minExcludedCellRangesperMeasObjectNR	The minimum number of exclude-list cell PCI ranges that a UE shall be able to store associated with a MeasObjectNR.	8
#minExcludedCellperMeasObjectEUTRA	The minimum number of exclude-list cells that a UE shall be able to store associated with a MeasObjectEUTRA.	32
#minCellperMeasObjectEUTRA	The minimum number of neighbour cells that a UE shall be able to store associated with a MeasObjectEUTRA.	32 NOTE 2
#minCellTotal	The minimum number of neighbour cells (excluding exclude-list cells) that UE shall be able to store in total from all measurement objects configured.	256 with counting CSI-RS and SSB as 2.
#maxDeprioritisationFreq	The UE shall be able to store a deprioritisation request for up to 8 frequencies (applicable when receiving another frequency specific deprioritisation request via <i>RRCRelease</i> before T325 expiry).	8
#minCellperMeasObjectUTRA-FDD	The minimum number of neighbour cells that a UE shall be able to store associated with a MeasObjectUTRA-FDD.	32
<p>NOTE 1: For one MAC entity, the maximum number of DRBs configured with PDCP duplication and with RLC entity(ies) associated with this MAC entity is 8.</p> <p>NOTE 2: In case of CGI reporting, the limit regarding the cells configured includes the cell for which the UE is requested to report CGI i.e. the amount of neighbour cells that can be included is at most (# minCellperMeasObjectRAT - 1), where RAT represents NR and EUTRA.</p> <p>NOTE 3: This requirement is applicable in NR SA, NR-DC and NE-DC.</p> <p>NOTE 4: The value of parameter #DRBs defines the total number of multicast MRBs and DRBs, and each split-MRB is counted as two RBs.</p>		

Annex A (normative): Differentiation of capabilities

A.1: TDD/FDD differentiation of capabilities in TDD-FDD CA

Annex A.1 specifies for which TDD and FDD serving cells a UE supporting TDD/FDD CA shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for TDD/FDD CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for FDD and TDD, the UE shall support the feature on the PCell and/or SCell(s), as specified in tables A.1-1 in accordance to the following rules:
 - PCell: the UE shall support the feature for the PCell, if the UE indicates support of the feature for the PCell duplex mode;
 - PSCell: the UE shall support the feature for the PSCell, if the UE indicates support of the feature for the PSCell duplex mode;
 - Per serving cell: the UE shall support the feature for a serving cell if the UE indicates support of the feature for the serving cell's duplex mode;
 - All serving cells: UE shall support the feature for all serving cells in a CG if the UE indicates support of the feature for both TDD and FDD duplex modes;
 - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for all associated serving cells's duplex modes;
- For the fields where the UE is not allowed to indicate different support for FDD and TDD, the UE shall support the feature for PCell and SCell(s) if the UE indicates support of the feature via the common capability bit.

Table A.1-1: UE capabilities for which FDD/TDD differentiation is allowed

UE-NR-Capability or UE-MRDC-Capability	Classification
eventA-MeasAndReport	PSCell
dl-SchedulingOffset-PDSCH-TypeA (Note3)	Associated serving cells
dl-SchedulingOffset-PDSCH-TypeB (Note3)	Associated serving cells
dynamicSFI (Note3)	Associated serving cells
handoverInterF	PCell
handoverLTE-EPC	PCell
handoverLTE-5GC	PCell
intraAndInterF-MeasAndReport	PSCell
logicalChannelSR-DelayTimer(Note2)	Associated serving cells
longDRX-Cycle	All serving cells
multipleConfiguredGrants(Note1)	Associated serving cells
multipleSR-Configurations	Per serving cell
secondaryDRX-Group-r16	All serving cells
sftd-MeasNR-Cell	PCell
sftd-MeasNR-Neigh	PCell
sftd-MeasNR-Neigh-DRX	PCell
sftd-MeasPSCell	PCell
sftd-MeasPSCell-NEDC	PCell
shortDRX-Cycle	All serving cells
skipUplinkTxDynamic	Per serving cell
twoDifferentTPC-Loop-PUCCH (Note3)	Associated serving cells
twoDifferentTPC-Loop-PUSCH (Note3)	Associated serving cells
ul-SchedulingOffset (Note3)	Associated serving cells
NOTE 1: The associated serving cells including the serving cell(s) configured with configured grant.	
NOTE 2: For a given logical channel, the associated serving cells including the PUCCH cell(s) associated with this logical channel (via <i>schedulingRequestID</i>).	
NOTE 3: The associated serving cells including both the cell sending the command and the cell applying the command.	

A.2: FR1/FR2 differentiation of capabilities in FR1-FR2 CA

Annex A.2 specifies for which FR1 and FR2 serving cells a UE supporting FR1/FR2 CA shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for FR1/FR2 CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for FR1 and FR2, the UE shall support the feature on the PCell and/or SCell(s), as specified in tables A.2-1 in accordance to the following rules:
 - PCell: the UE shall support the feature for the PCell, if the UE indicates support of the feature for the PCell FR mode;
 - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for associated serving cells's FR modes;
- For the fields where the UE is not allowed to indicate different support for FR1 and FR2, the UE shall support the feature for PCell and SCell(s) if the UE indicates support of the feature via the common capability bit.

Table A.2-1: UE capabilities for which FR1/FR2 differentiation is allowed

UE-NR-Capability	Classification
absoluteTPC-Command (Note2)	Associated serving cells
dl-SchedulingOffset-PDSCH-TypeA (Note2)	Associated serving cells
dl-SchedulingOffset-PDSCH-TypeB (Note2)	Associated serving cells
drx-Adaptation-r16	PCell
dynamicSFI (Note2)	Associated serving cells
handoverInterF	PCell
handoverLTE-EPC	PCell
handoverLTE-5GC	PCell
tpc-PUCCH-RNTI (Note2)	Associated serving cells
tpc-PUSCH-RNTI (Note2)	Associated serving cells
tpc-SRS-RNTI (Note2)	Associated serving cells
twoDifferentTPC-Loop-PUCCH (Note2)	Associated serving cells
twoDifferentTPC-Loop-PUSCH (Note2)	Associated serving cells
ul-SchedulingOffset (Note2)	Associated serving cells
voiceOverNR (Note1)	Associated serving cells.
NOTE 1: For a UE that does not support <i>lch-ToSCellRestriction</i> capability, the associated serving cells includes all serving cells in the CG; for a UE that supports <i>lch-ToSCellRestriction</i> capability, the associated serving cells includes the serving cells indicated by <i>allowedServingCells</i> for the LCH.	
NOTE 2: The associated serving cells including both the cell sending the command and the cell applying the command.	

A.3: TDD/FDD differentiation of capabilities for sidelink

Annex A.3 specifies for which TDD and FDD serving cells for Uu interface and carrier for PC5 interface a UE supporting sidelink shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for sidelink:

- For the fields for which the UE is allowed to indicate different support for FDD and TDD, the UE shall support the feature on the PCell and/or SCell(s) for Uu interface, as specified in tables A.3-1 in accordance to the following rules:
 - Per serving cell: the UE shall support the feature for a serving cell if the UE indicates support of the feature for the serving cell's duplex mode;
 - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for all associated serving cells's duplex modes;
- For the fields where the UE is not allowed to indicate different support for FDD and TDD, the UE shall support the feature for PCell and SCell(s) for Uu interface and carrier for PC5 interface if the UE indicates support of the feature via the common capability bit.

Table A.3-1: Rel-16 UE capabilities for which FDD/TDD differentiation is allowed

Sidelink Parameter	Classification
logicalChannelSR-DelayTimerSidelink(Note1)	Associated serving cells
multipleSR-ConfigurationsSidelink	Per serving cell
NOTE 1: For a given logical channel, the associated serving cells including the PUCCH cell(s) associated with this logical channel (via <i>schedulingRequestID</i>).	

A.4: Sidelink capabilities applicable to Uu and PC5

Annex A.4 specifies for each sidelink related capability, in which interface (i.e., *UECapabilityInformation* in Uu RRC and *UECapabilityInformationSidelink* in PC5 RRC) a UE supporting sidelink shall report the concerned capability:

- *UECapabilityInformation*: the concerned sidelink capability is reported within *UECapabilityInformation*;
- *UECapabilityInformationSidelink*: the concerned sidelink capability is reported within *UECapabilityInformationSidelink*;

**Table A.4-1: Sidelink capability reported in *UECapabilityInformation*/
*UECapabilityInformationSidelink***

Release 17

Sidelink Parameter	UECapabilityInformation	UECapabilityInformationSidelink
accessStratumReleaseSidelink		X
outOfOrderDeliverySidelink		X
am-WithLongSN-Sidelink	X	X
um-WithLongSN-Sidelink	X	X
lcp-RestrictionSidelink	X	
logicalChannelSR-DelayTimerSidelink	X	
multipleSR-ConfigurationsSidelink	X	
multipleConfiguredGrantsSidelink	X	
supportedBandCombinationListSidelinkEUTRA-NR	X	
supportedBandCombinationListSidelinkNR		X
gnb-ScheduledMode3SidelinkEUTRA	X	
gnb-ScheduledMode4SidelinkEUTRA	X	
sl-Reception	X	X
sl-TransmissionMode1	X	
sl-TransmissionMode2	X	
sl-TransmissionMode2-PartialSensing	X	
sl-TransmissionMode2-RandomResourceSelection	X	
sync-Sidelink	X	
congestionControlSidelink	X	
sl-Tx-256QAM	X	X
sl-Rx-256QAM	X	X
psfch-FormatZeroSidelink	X	
lowSE-64QAM-MCS-TableSidelink	X	X
csi-ReportSidelink		X
enb-sync-Sidelink	X	
rankTwoReception		X
fewerSymbolSlotSidelink	X	
sl-openLoopPC-RSRP-ReportSidelink	X	X
rx-IUC-Scheme1-PreferredMode2Sidelink	X	X
rx-IUC-Scheme1-NonPreferredMode2Sidelink	X	X
rx-IUC-Scheme2-Mode2Sidelink	X	X
rx-IUC-Scheme1-SCI	X	X
tx-Sidelink	X	
rx-Sidelink	X	
ue-PowerClassSidelink	X	
drx-OnSidelink	X	X
enhancedUuDRX-forSidelink	X	
relayUE-Operation-L2	X	
remoteUE-Operation-L2	X	
remoteUE-PathSwitchToldInactiveRelay	X	

Release 17

supportedBandCombinationListSL-RelayDiscovery	X	
supportedBandCombinationListSL-NonRelayDiscovery	X	
rx-IUC-Scheme1-SCI-ExplicitReq	X	X
scheme2-ConflictDeterminationRSP		X
tx-IUC-Scheme2-Mode2Sidelink	X	X
tx-IUC-Scheme1-Mode2Sidelink	X	X
rx-sidelinkPSFCH	X	
p0-OLPC-Sidelink	X	

A.5: General differentiation of capabilities in Cross-Carrier operation

Annex A.5 specifies for which multiple serving cells a UE supporting cross-carrier operation shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for cross-carrier operation in CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for different bands, the UE shall support the feature on the PCell and/or SCell(s) in cross-carrier operation, as specified in table A.5-1 in accordance to the following rules:
 - Triggered serving cell: the UE shall support the feature if the UE indicates support of the feature for the band of the scheduled/triggered/indicated serving cell;
 - Triggering&Triggered serving cells: UE shall support the feature if the UE indicates support of the feature for the band of both the scheduling/triggering/indicating serving cell and the scheduled/triggered/indicated serving cell;

Table A.5-1: General UE capabilities for which differentiation is allowed

UE-NR-Capability	Classification
activeConfiguredGrant-r16	Triggered serving cell
aperiodicTRS	Triggered serving cell
beamSwitchTiming, beamSwitchTiming-r16	Triggered serving cell
bwp-DiffNumerology (NOTE 1)	Triggering&Triggered serving cells
bwp-SameNumerology (NOTE 1)	Triggering&Triggered serving cells
crossCarrierScheduling-SameSCS	Triggering&Triggered serving cells
crossCarrierSchedulingProcessing-DiffSCS-r16 (NOTE 2)	Triggering&Triggered serving cells
dynamicSFI-r16	Triggering&Triggered serving cells
jointReleaseConfiguredGrantType2-r16	Triggered serving cell
jointReleaseSPS-r16	Triggered serving cell
pdccch-MonitoringAnyOccasionsWithSpanGap (NOTE 3)	Triggering&Triggered serving cells
sps-r16	Triggered serving cell
ue-SpecificUL-DL-Assignment	Triggering&Triggered serving cells
ul-CancellationCrossCarrier-r16	Triggering&Triggered serving cells
<p>NOTE 1: For <i>bwp-DiffNumerology</i> and <i>bwp-SameNumerology</i>, the supported number of BWPs for each band is still based on the indicated number for this band regardless of whether it is a scheduling cell or scheduled cell.</p> <p>NOTE 2: For <i>crossCarrierSchedulingProcessing-DiffSCS-r16</i>, if reported value is different between the band of the scheduled/triggered/indicated cell and the band of the scheduling/triggering/indicating cell, the value reported for the scheduling/triggering/indicating cell is applied.</p> <p>NOTE 3: Applicable for cross carrier scheduling with the same SCS in the scheduling cell and the scheduled cell. If the reported value is different between the band of the scheduled/triggered/indicated cell and the band of the scheduling/triggering/indicating cell, the value reported for the scheduling/triggering/indicating cell is applied.</p>	

Annex B (informative): UE capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations

Annex B clarifies the UE capability indication for the case where the UE is allowed to support different functionality between FDD and TDD, and between FR1 and FR2. Table B-1 clarifies the setting of UE capability fields for cases where the UE supports the corresponding feature in different combinations of duplex mode and frequency range. There are two possible ways of UE capability indication in Case 3 and Case 8.

Table B-1: UE capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations

Support for the feature		Setting of UE capability fields					
		Common UE capability (with suffix '-XDD-Diff')	Common UE capability (with suffix '-FRX-diff')	fdd-Add-UE-NR/MRDC-Capabilities	tdd-Add-UE-NR/MRDC-Capabilities	fr1-Add-UE-NR/MRDC-Capabilities	fr2-Add-UE-NR/MRDC-Capabilities
Case 1	FR1 FDD: 'supported' FR1 TDD: 'supported' FR2 TDD: 'supported'	Included	Included	Not included	Not included	Not included	Not included
Case 2	FR1 FDD: 'not supported' FR1 TDD: 'not supported' FR2 TDD: 'not supported'	Not included	Not included	Not included	Not included	Not included	Not included
Case 3	FR1 FDD: 'not supported' FR1 TDD: 'supported' FR2 TDD: 'supported'	Not included	Included	Not included	Included	Not included	Not included
		Not included	Not included	Not included	Included	Not included	Not included
Case 4	FR1 FDD: 'not supported' FR1 TDD: 'not supported' FR2 TDD: 'supported'	Not included	Not included	Not included	Included	Not included	Included
Case 5	FR1 FDD: 'not supported' FR1 TDD: 'supported' FR2 TDD: 'not supported'	Not included	Not included	Not included	Included	Included	Not included
Case 6	FR1 FDD: 'supported' FR1 TDD: 'not supported' FR2 TDD: 'supported'	The current UE capability signalling does not support the UE capability indication for this case.					
Case 7	FR1 FDD: 'supported' FR1 TDD: 'not supported' FR2 TDD: 'not supported'	Not included	Not included	Included	Not included	Included	Not included
Case 8	FR1 FDD: 'supported' FR1 TDD: 'supported' FR2 TDD: 'not supported'	Included	Not included	Not included	Not included	Included	Not included
		Not included	Not included	Not included	Not included	Included	Not included

NOTE 1: For a UE capability which cannot be differentiated between FR2-1 and FR2-2, 'FR2 TDD' in Table B-1 includes both 'FR2-1 TDD' and 'FR2-2 TDD'.

NOTE 2: For a UE capability which can be differentiated between FR2-1 and FR2-2, 'FR2 TDD' in Table B-1 only means 'FR2-1 TDD'.

Annex C (informative): Change history

Change history							
Date	Meeting	TDoc	CR	Rev	Cat	Subject/Comment	New version
06/2017	RAN2#98	R2-1704810				First version	0.0.1
06/2017	RAN2#NR2	R2-1707386					0.0.2
08/2017	RAN2#99	R2-1708750					0.0.3
12/2017	RAN2#100	R2-1712587					0.0.4
12/2017	RAN2#100	R2-1714141					0.0.5
12/2017	RAN2#100	R2-1714271					0.1.0
12/2017	RP-78	RP-172521				Submitted to RAN#78 for approval	1.0.0
12/2017	RP-78					Upgraded to Rel-15	15.0.0
03/2018	RP-79	RP-180440	0003	3	F	Updates on UE capabilities	15.1.0
06/2018	RP-80	RP-181216	0009	2	B	Introduce ANR in NR	15.2.0
	RP-80	RP-181216	0012	1	F	Miscellaneous corrections	15.2.0
	RP-80	RP-181216	0013	-	B	Delay budget report and MAC CE adaptation for NR for TS 38.306	15.2.0
09/2018	RP-81	RP-181940	0008	4	F	Correction on total layer2 buffer size	15.3.0
	RP-81	RP-181942	0024	1	F	Introduction of UE capability constraints	15.3.0
	RP-81	RP-181942	0030	-	F	38.306 corrections and cleanup	15.3.0
12/2018	RP-82	RP-182651	0016	4	F	Clarification for Interruption-based and gap-based SFTD measurement	15.4.0
	RP-82	RP-182653	0033	1	F	Timer based BWP switching	15.4.0
	RP-82	RP-182652	0035	2	F	Additional UE capabilities for NR standalone	15.4.0
	RP-82	RP-182651	0037	1	F	Clarification to UE capability of independentGapConfig for inter-RAT NR measurement not yet configured with EN-DC	15.4.0
	RP-82	RP-182661	0038	2	F	Update of L2 capability parameters	15.4.0
	RP-82	RP-182660	0047	2	F	Clarification on physical layer parameters of UE capability	15.4.0
	RP-82	RP-182666	0050	3	F	Introduce RRC buffer size in NR	15.4.0
	RP-82	RP-182664	0051	2	F	Clarification of multipleConfiguredGrants	15.4.0
	RP-82	RP-182664	0052	2	F	CR to 38.306 for PDCP CA duplication for SRB	15.4.0
	RP-82	RP-182661	0054	1	F	UE capability handling for FDD/TDD and FR1/FR2	15.4.0
	RP-82	RP-182663	0057	1	F	Clarify for per CC UL/DL modulation order capabilities	15.4.0
	RP-82	RP-182664	0058	1	F	Inter-frequency handover capability	15.4.0
	RP-82	RP-182665	0060	3	F	UE capability on PA architecture	15.4.0
	RP-82	RP-182661	0062	1	F	CR on signaling contiguous and non-contiguous EN-DC capability	15.4.0
	RP-82	RP-182813	0063	6	F	Update of UE capabilities	15.4.0
	RP-82	RP-182662	0065	2	F	Introduction of SRS switching capability	15.4.0
	RP-82	RP-182667	0068	2	B	CR on introduction of UE overheating support in NR SA scenario	15.4.0
	RP-82	RP-182664	0071	-	F	Introduction of SRS switching capability	15.4.0
03/2019	RP-83	RP-190634	0073	1	F	Capability for aperiodic CSI-RS triggering with different numerology between PDCCH and CSI-RS	15.5.0
	RP-83	RP-190542	0074	1	F	Layer-1 capability update	15.5.0
	RP-83	RP-190545	0075	2	F	CR to 38.306 on introducing nr-CGI-Reporting-ENDC	15.5.0

	RP-83	RP-190545	0086	2	F	CR to clarify intra-NR handover capabilities	15.5.0
	RP-83	RP-190546	0088	3	F	Clarification for PDSCHs and PUSCHs per slot for different TBs for UE capable of processing time capability 1	15.5.0
	RP-83	RP-190542	0092	2	F	Correction to mandatory supported capability signaling	15.5.0
	RP-83	RP-190542	0097	2	F	Miscellaneous corrections	15.5.0
	RP-83	RP-190545	0098	2	F	Correction on supportedBandwidthCombinationSetEUTRA-v1530 usage	15.5.0
	RP-83	RP-190543	0099	-	F	Clarification on signaling the bandwidth class	15.5.0
	RP-83	RP-190545	0100	1	F	Clarification on Frequency Separation Class	15.5.0
	RP-83	RP-190544	0101	-	F	CR on Processing delay requirements for RRC Resume procedures in TS 38.306	15.5.0
06/2019	RP-84	RP-191375	0094	1	F	CR to clarify ul-TimingAlignmentEUTRA-NR	15.6.0
	RP-84	RP-191373	0108	-	F	Layer-1, RF and RRM capability updates	15.6.0
	RP-84	RP-191373	0109	-	F	Clarification on UE capability of lch-ToSCellRestriction	15.6.0
	RP-84	RP-191379	0110	2	F	Correction on description of additionalActiveSpatialRelationPUCCH	15.6.0
	RP-84	RP-191378	0111	1	F	Clarification on csi-RS-CFRA-ForHO	15.6.0
	RP-84	RP-191379	0114	2	F	CR on capability of maxUplinkDutyCycle for FR2	15.6.0
	RP-84	RP-191380	0115	2	F	38.306 miscellaneous corrections	15.6.0
	RP-84	RP-191378	0116	1	B	38.306 CR for late drop	15.6.0
	RP-84	RP-191381	0118	4	F	Clarification on supported modulation order capability	15.6.0
	RP-84	RP-191374	0119	-	F	Correction to PDCP parameters	15.6.0
	RP-84	RP-191381	0121	3	F	Corrections to UE Capability definitions	15.6.0
	RP-84	RP-191378	0122	1	F	38.306 Clarification on multiple TA capabilities	15.6.0
	RP-84	RP-191379	0123	2	F	CR to clarify non-codebook based PUSCH transmission	15.6.0
	RP-84	RP-191380	0124	3	F	Clarification on pdsch-ProcessingType2	15.6.0
	RP-84	RP-191378	0125	1	F	Clarification on present of tci-StatePDSCH	15.6.0
	RP-84	RP-191378	0126	1	F	Clarification on SA fallback BC support	15.6.0
	RP-84	RP-191375	0128	-	F	Correction to Beam Correspondence for CA	15.6.0
	RP-84	RP-191379	0130	2	F	Correction on the number of DRB in UE Capability Constraints	15.6.0
	RP-84	RP-191379	0132	1	F	CR to capture UE supported DL/UL bandwidths	15.6.0
	RP-84	RP-191376	0133	-	F	UE capability signalling for FD-MIMO processing capabilities for EN-DC	15.6.0
	RP-84	RP-191376	0134	-	F	Modified UE capability on different numerologies within the same PUCCH group	15.6.0
	RP-84	RP-191554	0135	-	F	Removal of "Capability for aperiodic CSI-RS triggering with different numerology between PDCCH and CSI-RS"	15.6.0
09/2019	RP-85	RP-192196	0136	1	C	Additional capability signalling for 1024QAM support	15.7.0
	RP-85	RP-192191	0142	1	B	Introduction of SFTD measurement to neighbour cells for NR SA	15.7.0
	RP-85	RP-192193	0146	1	F	MR-DC measurement gap pattern capability	15.7.0
	RP-85	RP-192194	0151	3	F	Clarifying UE capability freqHoppingPUCCH-F0-2 and freqHoppingPUCCH-F1-3-4	15.7.0
	RP-85	RP-192190	0152	-	F	Clarification to dynamic power sharing capability	15.7.0
	RP-85	RP-192192	0153	2	F	Miscellaneous corrections	15.7.0
	RP-85	RP-192190	0154	-	F	Capability of measurement gap patterns	15.7.0
	RP-85	RP-192193	0155	2	F	Correction to IMS capability	15.7.0
	RP-85	RP-192194	0156	3	F	UE Capabilities covering across all serving cells	15.7.0
	RP-85	RP-192190	0167	-	F	Clarification on UE capability on different numerologies within the	15.7.0

					same PUCCH group	
--	--	--	--	--	------------------	--

	RP-85	RP-192193	0168	1	F	Correction on CA parameters in NR-DC	15.7.0
	RP-85	RP-192346	0169	-	C	Introduction of UE capability for NR-DC with SFN synchronization between PCell and PSCell	15.7.0
12/2019	RP-86	RP-192934	0185	1	F	Clarification on the restriction of maximum SRS resource sets configuration for uplink beam management.	15.8.0
	RP-86	RP-192936	0186	3	F	Miscellaneous corrections on UE capability fields	15.8.0
	RP-86	RP-192935	0191	1	F	Corrections on PDCCH blind decoding in NR-DC	15.8.0
	RP-86	RP-192937	0200	1	F	Clarification on ne-DC capability	15.8.0
	RP-86	RP-192935	0202	1	F	Correction to channelBWs	15.8.0
	RP-86	RP-192936	0204	1	F	Use of splitSRB-WithOneUL-Path capability (38.306)	15.8.0
	RP-86	RP-192935	0205	-	F	Correction to pdsch-RepetitionMultiSlots and pusch-RepetitionMultiSlots	15.8.0
	RP-86	RP-192937	0215	1	F	Correction on initial BWP bandwidth capabilities	15.8.0
	RP-86	RP-192937	0216	1	F	NE-DC dynamic power sharing capability	15.8.0
	RP-86	RP-192935	0219	-	F	Clarification on crossCarrierScheduling-OtherSCS in R15	15.8.0
	RP-86	RP-192937	0220	-	F	Correction on ambiguity of UE FDD/TDD FR1/FR2 capabilities	15.8.0
03/2020	RP-87	RP-200334	0194	2	F	Correction on parameter description of beamManagementSSB-CSI-RS	15.9.0
	RP-87	RP-200335	0208	3	F	CR on BWCS for inter-ENDC BC with intra-ENDC BC (38.306)	15.9.0
	RP-87	RP-200335	0209	5	F	CR to 38.306 on support of 70MHz channel bandwidth	15.9.0
	RP-87	RP-200334	0236	-	F	Correction on SRB capability in NR-DC	15.9.0
	RP-87	RP-200335	0248	2	F	Data rate for the case of single carrier standalone operation	15.9.0
	RP-87	RP-200334	0254	1	F	CR on the maximum stored number of deprioritisation frequencies	15.9.0
	RP-87	RP-200335	0255	2	F	Miscellaneous Corrections to UE capability parameters	15.9.0
	RP-87	RP-200335	0259	1	F	UE capability of intra-band requirements for inter-band EN-DC/NE-DC	15.9.0
03/2020	RP-87	RP-200356	0145	1	F	CR on capability of maxUplinkDutyCycle for inter-band EN-DC PC2 UE	16.0.0
	RP-87	RP-200335	0214	2	F	Correction on beamSwitchTiming values of 224 and 336	16.0.0
	RP-87	RP-200335	0223	1	C	Inclusion of 90MHz UE Bandwidth	16.0.0
	RP-87	RP-200358	0226	2	B	Introducing autonomous gap in CGI reporting	16.0.0
	RP-87	RP-200357	0229	-	B	UE capability for IDC	16.0.0
	RP-87	RP-200340	0230	-	B	Introduction of Cross Link Interference (CLI) handling and Remote Interference Management (RIM)	16.0.0
	RP-87	RP-200358	0233	1	C	Introduction of EPS voice fallback enhancement	16.0.0
	RP-87	RP-200350	0235	-	B	Introduction of SRVCC from 5G to 3G	16.0.0
	RP-87	RP-200358	0243	1	B	Introduction of DL RRC segmentation	16.0.0
	RP-87	RP-200358	0258	1	B	Introduction of downgraded configuration for SRS antenna switching	16.0.0
	RP-87	RP-200359	0260	-	B	Recommended Bit Rate/Query for FLUS and MTSI	16.0.0
	RP-87	RP-200358	0261	-	B	Introduction of UE capability indicator of supporting inter-RAT handover from NR to EN-DC in 38.306.	16.0.0
07/2020	RP-88	RP-201163	0288	2	A	Correction to the serving cell number for ENDC power class	16.1.0
	RP-88	RP-201187	0289	3	A	CR on introduction of BCS to asymmetric channel bandwidths (38.306)	16.1.0
	RP-88	RP-201160	0295	1	A	SRS Capability report for SRS only Scell	16.1.0
	RP-88	RP-201159	0299	-	A	Clarification on L1 feature of NGEN-DC and NE-DC	16.1.0
	RP-88	RP-201161	0304	2	A	Default values for UE capability	16.1.0
	RP-88	RP-201163	0312	1	A	Invalidating bandwidth class F for FR1	16.1.0
	RP-88	RP-201163	0318	1	A	Missing "Optional features without UE radio access capability	16.1.0

					parameters"	
--	--	--	--	--	-------------	--

	RP-88	RP-201163	0320	1	A	Missing UE capability requirements	16.1.0
	RP-88	RP-201198	0321	1	C	Introduction of secondary DRX group CR 38.306	16.1.0
	RP-88	RP-201164	0324	2	A	Correction on UE capability constraints	16.1.0
	RP-88	RP-201183	0328	2	B	UE capability of supporting UL Tx switching	16.1.0
	RP-88	RP-201217	0329	2	B	Release-16 UE capabilities based on RAN1, RAN4 feature lists and RAN2	16.1.0
	RP-88	RP-201163	0330	1	A	Corrections on the number of DRBs	16.1.0
	RP-88	RP-201166	0333	1	F	On the capability of Basic CSI feedback (2-32)	16.1.0
	RP-88	RP-201162	0339	1	A	Clarification on the support of IMS voice over split bearer for NR-DC and NE-DC	16.1.0
	RP-88	RP-201162	0343	1	A	Clarification on maximum number of supported PDSCH Resource Element mapping patterns	16.1.0
	RP-88	RP-201164	0344	2	A	Introduction of CGI reporting capabilities	16.1.0
	RP-88	RP-201165	0346	2	A	UE Capability Enhancement for FR1(TDD/FDD) / FR2 CA and DC	16.1.0
	RP-88	RP-201161	0353	-	A	CR on unnecessary XDD FRX differentiation	16.1.0
	RP-88	RP-201162	0355	-	A	Clarification to maxUplinkDutyCycle-FR2	16.1.0
	RP-88	RP-201162	0357	-	A	Clarification on L2 and RAN4 feature of NGEN-DC and NE-DC	16.1.0
	RP-88	RP-201163	0360	1	A	Correction on UE capability signalling for simultaneous SRS antenna and carrier switching	16.1.0
	RP-88	RP-201163	0362	-	A	Correction on UE capabilities with xDD and FRx differentiations	16.1.0
	RP-88	RP-201166	0363	-	C	Missing reportAddNeighMeas in periodic measurement reporting	16.1.0
09/2020	RP-89	RP-201932	0370	2	B	Release-16 UE capabilities based on RAN1, RAN4 feature lists and RAN2 corrections	16.2.0
	RP-89	RP-201938	0378	1	A	Corrections on UE capability constraints	16.2.0
	RP-89	RP-201932	0382	1	F	Correction on beamSwitchTiming values of 224 and 336	16.2.0
	RP-89	RP-201924	0383	2	F	Update to IAB-MT capabilities	16.2.0
	RP-89	RP-201937	0387	1	F	Clarification on PDSCH rate-matching capabilities	16.2.0
	RP-89	RP-201937	0389	2	A	Corrections on the capabilities associated with multiple bands/Cells	16.2.0
	RP-89	RP-201989	0393	2	F	Correction on PRS measurement gap capability	16.2.0
	RP-89	RP-201938	0402	2	F	Clarification on the extended capability of NGEN-DC	16.2.0
	RP-89	RP-201962	0407	1	F	Miscellaneous corrections on UL Tx switching	16.2.0
	RP-89	RP-201922	0408	-	F	NR-DC UE capabilities	16.2.0
12/2020	RP-90	RP-202790	0419	2	A	CR to clarify UE capability in case of Cross-Carrier operation	16.3.0
	RP-90	RP-202778	0422	1	B	Release-16 UE capabilities based on RAN1, RAN4 feature lists and RAN2 corrections	16.3.0
	RP-90	RP-202767	0424	3	F	Correction on description for extendedRAR-Window	16.3.0
	RP-90	RP-202789	0439	1	F	Clarification on the inter-frequency handover capability	16.3.0
	RP-90	RP-202789	0441	-	A	Clarification on NE-DC for bandwidth combination set	16.3.0
	RP-90	RP-202790	0453	1	A	Removing contradiction on number of FSpUCC and FSpDCC	16.3.0
	RP-90	RP-202789	0461	-	F	Clarification on UE capabilities with FDD/TDD differentiation	16.3.0
	RP-90	RP-202771	0472	4	F	Introduction of capability bit for multi-CC simultaneous TCI activation with multi-TRP	16.3.0
	RP-90	RP-202770	0476	-	A	Dummify UE capability of crossCarrierScheduling-OtherSCS	16.3.0
	RP-90	RP-202789	0479	1	A	Clarification for multipleCORESET	16.3.0
	RP-90	RP-202882	0481	-	A	CR to 38.306 on handling of fallbacks for FR2 CA	16.3.0
03/2021	RP-91	RP-210689	0482	-	F	Update on V2X UE capability	16.4.0
	RP-91	RP-210693	0483	1	F	CR for the supported max data rate for uplink Tx switching	16.4.0

	RP-91	RP-210697	0485	-	F	UE capability of NR to UTRA-FDD CELL_DCH CS handover	16.4.0
	RP-91	RP-210697	0489	2	A	Correction on beamSwitchTiming capability	16.4.0
	RP-91	RP-210697	0490	1	F	Correction on beamSwitchTiming-r16 capability	16.4.0
	RP-91	RP-210697	0491	1	F	Correction on TPMI grouping capability	16.4.0
	RP-91	RP-210692	0501	-	F	Dummifying intraFreqMultiUL-TransmissionDAPS-r16 capability	16.4.0
	RP-91	RP-210694	0502	1	F	Corrections on UE capability for NR-U	16.4.0
	RP-91	RP-210703	0503	2	F	Release with Redirect for connection resume triggered by NAS	16.4.0
	RP-91	RP-210703	0505	2	A	Clarification to LCP restrictions	16.4.0
	RP-91	RP-210691	0506	1	F	Introduction of the UE Capability for SpCell BFR Enhancement	16.4.0
	RP-91	RP-210697	0509	2	F	Clarification on UE capabilities with FDD/TDD differentiation	16.4.0
	RP-91	RP-210805	0512	3	B	Support of 35 MHz and 45 MHz channel bandwidth for FR1	16.4.0
	RP-91	RP-210697	0513	1	F	Clarification on UE capabilities for enhanced MIMO	16.4.0
	RP-91	RP-210703	0516	2	A	CR on the SupportedBandwidth and channelBWs(R16)	16.4.0
	RP-91	RP-210695	0520	2	F	Correction to PUSCH skipping with UCI without LCH-based prioritization	16.4.0
	RP-91	RP-210697	0521	1	F	CR on the Capability of PUCCH Transmissions for HARQ-ACK-38306	16.4.0
	RP-91	RP-210703	0523	2	F	Clarification on FDD-TDD differentiation for SUL band	16.4.0
	RP-91	RP-210702	0525	1	A	Clarification on single uplink operation capability report	16.4.0
	RP-91	RP-210697	0528	-	F	Addition of TEI16 features	16.4.0
	RP-91	RP-210702	0529	-	A	CR to clarify the definition of fallback per CC feature set	16.4.0
	RP-91	RP-210697	0530	-	F	Capability for dormant BWP switching of multiple SCells	16.4.0
	RP-91	RP-210702	0533	-	A	Dummy the capability bit v2x-EUTRA	16.4.0
	RP-91	RP-210703	0534	2	A	Clarification on the capability of supportedNumberTAG	16.4.0
	RP-91	RP-210701	0537	1	A	Clarification on the supportedBandwidthCombinationSetIntraENDC capability	16.4.0
	RP-91	RP-210697	0538	-	B	Release-16 UE capabilities based on updated RAN1 and RAN4 feature lists	16.4.0
	RP-91	RP-210693	0539	-	B	Uplink Tx DC location reporting for two carrier uplink CA	16.4.0
06/2021	RP-92	RP-211487	0526	5	C	Redirection with MPS Indication [Redirect_MPS_]]	16.5.0
	RP-92	RP-211480	0541	4	F	Miscellaneous corrections to Rel-16 UE capabilities	16.5.0
	RP-92	RP-211475	0542	3	F	Correction on Capability of two PUCCH transmission	16.5.0
	RP-92	RP-211470	0543	3	F	Correction on V2X UE capability	16.5.0
	RP-92	RP-211483	0545	2	A	CR on UE capability in case of Cross-Carrier operation	16.5.0
	RP-92	RP-211470	0547	2	F	Addition of total L2 buffer size and RLC RTT for NR SL	16.5.0
	RP-92	RP-211483	0550	2	A	Correction to BWP capabilities	16.5.0
	RP-92	RP-211482	0566	2	A	CR on the supportedBandwidthCombinationSet-R16	16.5.0
	RP-92	RP-211477	0568	3	A	CR on the 35M45M supporting-R16	16.5.0
	RP-92	RP-211484	0571	2	F	UL Config Grant capability differentiation for FR1(TDD/FDD) / FR2	16.5.0
	RP-92	RP-211474	0572	2	F	Corrections on the UE capability of indication on supporting the extension of SRS resourceID	16.5.0
	RP-92	RP-211478	0573	3	B	Release-16 UE capabilities based on RAN1 and RAN4 feature lists	16.5.0
	RP-92	RP-211480	0575	3	F	Corrections to directional collision handling in half-duplex operation	16.5.0
	RP-92	RP-211478	0578	1	F	Introduction of the intra-NR and inter-RAT HST Capabilities	16.5.0
	RP-92	RP-211483	0594	-	A	Correction to the use of simultaneous CSI-RS resources	16.5.0
	RP-92	RP-211478	0596	1	A	Clarification on BCS of a fallback band combination	16.5.0
	RP-92	RP-211478	0599	1	A	Further clarification on supportedNumberTAG	16.5.0

	RP-92	RP-211478	0608	1	A	Clarification on maximum number of TCI-state for PDSCH	16.5.0
	RP-92	RP-211475	0609	-	F	Capability bit for extending search space switching trigger configuration	16.5.0
	RP-92	RP-211471	0610	1	C	NR-DC Cell Group capability filtering	16.5.0
09/2021	RP-93	RP-212439	0518	4	A	CR on the Intra-band and Inter-band EN-DC Capabilities -R16	16.6.0
	RP-93	RP-212439	0562	3	A	Clarification on the simultaneousRxTxInterBandCA capability in NR-DC	16.6.0
	RP-93	RP-212438	0613	1	A	Correction to the description of additionalActiveTCI-StatePDCCH	16.6.0
	RP-93	RP-212439	0619	1	A	Definition of fallback per CC feature set	16.6.0
	RP-93	RP-212443	0626	1	F	Miscellaneous corrections to UE capability descriptions	16.6.0
	RP-93	RP-212439	0631	1	A	Support of newly introduced 100M bandwidth for band n40	16.6.0
	RP-93	RP-212438	0633	-	A	Correction on fallback band combination for SUL	16.6.0
	RP-93	RP-212440	0641	-	F	FR1/FR2 differentiation for enhanced UL grant skipping capabilities	16.6.0
	RP-93	RP-212597	0643	2	C	Distinguishing support of extended band n77	16.6.0
12/2021	RP-94	RP-213341	0640	2	A	Simultaneous Rx/Tx UE capability per band pair	16.7.0
	RP-94	RP-213344	0645	2	F	Updates based on RAN1 NR positioning features list	16.7.0
	RP-94	RP-213342	0646	1	C	Duty cycle signalling for power class 1.5	16.7.0
	RP-94	RP-213343	0647	1	F	Correction on R16 UE capability of supportedSINR-meas-r16	16.7.0
	RP-94	RP-213341	0656	1	A	Clarification on intraAndInterF-MeasAndReport capability	16.7.0
	RP-94	RP-213341	0658	-	A	Miscellaneous corrections for Rel-15 UE capabilities	16.7.0
	RP-94	RP-213346	0659	-	F	Miscellaneous corrections for Rel-16 UE capabilities	16.7.0
	RP-94	RP-213345	0660	1	C	CR on 38.306 for introducing UE capability of txDiversity	16.7.0
	RP-94	RP-213346	0661	1	F	Clarification on UL MIMO layer reporting for 1Tx-2Tx switching	16.7.0
	RP-94	RP-213346	0664	-	F	Correction on two HARQ-ACK codebooks capability	16.7.0
03/2022	RP-95	RP-220835	0635	3	F	Adding UE capability of UL MIMO coherence for UL Tx switching	16.8.0
	RP-95	RP-220473	0677	1	F	Correction on DAPS capability	16.8.0
	RP-95	RP-220473	0688	1	F	Introduction of sidelink power class capability indication	16.8.0
	RP-95	RP-220473	0695	1	F	Correction on ssb-csirs-SINR-measurement-r16 capability	16.8.0
03/2022	RP-95	RP-220499	0532	2	C	Remove the maximum number of MIMO layers restrictions for SUL	17.0.0
	RP-95	RP-220837	0650	2	B	Introduction of mobility-state-based cell reselection for NR HSDN [NR_HSDN]	17.0.0
	RP-95	RP-220921	0667	2	C	Pi/2-BPSK specification updates for the merger of 5Gi into 3GPP	17.0.0
	RP-95	RP-220472	0679	1	F	Correction on PO determination for UE in inactive state	17.0.0
	RP-95	RP-220838	0685	1	B	Release-17 UE capabilities based on R1 and R4 feature lists (TS38.306)	17.0.0
	RP-95	RP-220506	0686	1	D	Inclusive Language Review for TS 38.306	17.0.0
	RP-95	RP-220510	0698	1	B	Capability for Explicit Indication of SI Scheduling window position [SI-SCHEDULING]	17.0.0
06/2022	RP-96	RP-221721	0690	2	B	CR on the CBM/IBM reporting-38306	17.1.0
	RP-96	RP-221756	0703	2	B	Release-17 UE capabilities based on R1 and R4 feature lists (TS38.306)	17.1.0
	RP-96	RP-221756	0710	1	A	Clarification on simultaneous Rx/Tx capability per band pair	17.1.0
	RP-96	RP-221736	0714	2	C	Distinguishing support of band n77 restrictions in Canada [n77 Canada]	17.1.0
	RP-96	RP-221756	0715	1	F	Correction on the UE capability of extension of TDRA indication for Configured UL Grant type 1	17.1.0
	RP-96	RP-221756	0716	1	A	Correction on the UE capability description of the overlapping PDSCH	17.1.0

	RP-96	RP-221756	0731	1	C	Adding UE capability of CSI reporting cross PUCCH SCell group	17.1.0
	RP-96	RP-221756	0733	1	A	Clarification on miscellaneous UE capabilities	17.1.0
	RP-96	RP-221756	0741	1	A	Clarification on the applicability of mixed numerology on UE capability maxNumberCSI-RS-RRM-RS-SINR	17.1.0
	RP-96	RP-221756	0743	-	A	Correction to multi-DCI multi-TRP and new UE capability to limit PDCCH monitoring	17.1.0
	RP-96	RP-221756	0744	-	A	Clarification on configuredUL-GrantType1-v1650	17.1.0
	RP-96	RP-221756	0746	1	C	Introduction UE capability for CHO with SCG configuration [CHOwithDCKept]	17.1.0
	RP-96	RP-221736	0747	1	B	Introduction of gNB ID length reporting in the NR CGI report [gNB_ID_Length]	17.1.0
	RP-96	RP-221756	0750	-	C	Introduction of uplink RRC Segmentation capability	17.1.0
	RP-96	RP-221756	0751	-	A	bwp-SwitchingDelay conditionally mandatory capability	17.1.0
	RP-96	RP-221792	0756	2	A	HARQ-ACK multiplexing on PUSCH in the absence of PUCCH	17.1.0
09/2022	RP-97	RP-222519	0761	1	A	Clarification on power sharing UE capability	17.2.0
	RP-97	RP-222527	0764	1	B	Release-17 UE capabilities based on R1 and R4 feature lists (TS38.306)	17.2.0
	RP-97	RP-222526	0769	-	F	Corrections to the description of gNB ID length reporting capabilities [gNB_ID_Length]	17.2.0
	RP-97	RP-222526	0774	1	B	38306 CR for Early measurement for EPS fallback [IdleMeaEPSFB]	17.2.0
	RP-97	RP-222521	0781	1	A	Correction for the capability of SRS-PeriodicityAndOffset	17.2.0
	RP-97	RP-222519	0786	1	A	Correction on crossCarrierA-CSI-trigDiffSCS-r16 (38.306)	17.2.0
	RP-97	RP-222526	0788	1	F	Ensuring consistent support of capability bits and associated NS-values in n77 in USA and Canada	17.2.0
	RP-97	RP-222520	0790	1	A	Correction on PDCCH blind detection capability in CA	17.2.0
	RP-97	RP-222520	0792	1	A	Clarification on pusch-RepetitionTypeA-r16 capability	17.2.0
	RP-97	RP-222518	0798	2	A	Correction on sidelink capability	17.2.0
	RP-97	RP-222526	0802	-	B	Start drx-HARQ-RTT-TimerUL after last repetition [ulHARQ_RTT_Timer]	17.2.0
	RP-97	RP-222522	0803	-	F	Corrections on CRS-IM network assistance information	17.2.0
	RP-97	RP-222552	0805	1	B	38.306 CR for introduction of MBS PDSCH FDM capabilities	17.2.0
12/2022	RP-98	RP-223408	0699	2	A	Corrections to SON/MDT capabilities	17.3.0
	RP-98	RP-223413	0811	1	A	Correction to definition of dualPA-Architecture capability indication	17.3.0
	RP-98	RP-223414	0822	2	C	Introduction of capabilities for emergency service related fallback [CellSelection_EmergencyFallback]	17.3.0
	RP-98	RP-223415	0831	2	B	Release-17 UE capabilities based on R1 and R4 feature lists (TS38.306)	17.3.0
	RP-98	RP-223417	0840	1	C	Higher granularity for per-FR gap capability [MaxCCPerFRGap]	17.3.0
	RP-98	RP-223404	0845	1	A	Clarification on 400MHz channel bandwidth	17.3.0
	RP-98	RP-223409	0852	-	F	Correction to support repetition on PDSCH time domain resource allocation for DCI format 1-2	17.3.0
03/2023	RP-99	RP-230687	0847	3	A	Clarification on capabilities reported in different granularity with prerequisite	17.4.0
	RP-99	RP-230690	0853	1	F	IOT bit for inter satellite measurement (38.306)	17.4.0
	RP-99	RP-230690	0856	-	F	Correction to Enhanced RRM requirements for NTN measurements in IDLE and INACTIVE	17.4.0
	RP-99	RP-230688	0859	2	F	Release-17 UE capabilities updates/corrections based on latest R1	17.4.0

						and R4 feature lists (TS38.306)	
	RP-99	RP-230691	0860	1	F	Correction on the capability for 1024QAM	17.4.0
	RP-99	RP-230685	0863	-	A	Correction on Duty Cycle capability for PC1.5	17.4.0
	RP-99	RP-230691	0868	2	F	Clarification on BWP capabilities of RedCap UEs	17.4.0
	RP-99	RP-230686	0870	1	A	Clarification on supportedCellGrouping capability	17.4.0
	RP-99	RP-230685	0873	1	A	CR on the intraBandFreqSeparationUL-AggBW-GapBW-r16_R17	17.4.0
	RP-99	RP-230690	0877	-	F	Correction on NCSG gap pattern capability	17.4.0
	RP-99	RP-230694	0879	2	F	Band differentiation for capability pusch-RepetitionTypeA-r16	17.4.0
	RP-99	RP-230689	0882	1	F	Correction on codebook mode configuration for Rel-17 NCJT CSI measurement	17.4.0
	RP-99	RP-230694	0885	-	F	Introducing deriveSSB-IndexFromCellInter capability for non-NCSG UEs	17.4.0
	RP-99	RP-230693	0886	3	F	UE capability for NCD SSB for REDCAP for SDT	17.4.0
	RP-99	RP-230690	0887	-	B	Release-17 MBS UE capabilities based on latest R1 feature list (TS 38.306)	17.4.0
06/2023	RP-100	RP-231418	0888	1	F	Correction on NR NTN UE capabilities	17.5.0
	RP-100	RP-231413	0893	1	F	Corrections on the eIAB related capabilities	17.5.0
	RP-100	RP-231418	0894	4	F	Correction on missing referencing of the NTN spec in 38.306	17.5.0
	RP-100	RP-231409	0897	2	A	Miscellaneous Correction on UE capability-R17	17.5.0
	RP-100	RP-231410	0899	1	A	Correction on PDCCH Blind Detection-R17	17.5.0
	RP-100	RP-231418	0900	2	F	Miscellaneous Correction on UE capability-R17	17.5.0
	RP-100	RP-231410	0902	1	A	Correction on pusch-RepetitionTypeB capability	17.5.0
	RP-100	RP-231410	0904	1	A	Corrections on NR-DC capabilities	17.5.0
	RP-100	RP-231414	0908	1	F	Correction on MBS capabilities	17.5.0
	RP-100	RP-231417	0914	-	F	Corrections to signaling of Rel-17 channel bandwidths in FR1	17.5.0
	RP-100	RP-231415	0916	1	F	Correction on the capability of RedCap UE	17.5.0
	RP-100	RP-231409	0919	1	A	Clarification on SRS Tx switching capability	17.5.0
	RP-100	RP-231418	0921	1	F	Missing reference to cell reselection requirements for NTN UEs in RRC INACTIVE	17.5.0
	RP-100	RP-231414	0925	-	F	Alignment with RAN1 feature list update on MBS	17.5.0
	RP-100	RP-231417	0930	1	F	UE capability for releasing crossCarrierSchedulingConifig	17.5.0